

Agenda Item: Ad hoc 14

Source : LGIC, Samsung, GBT, Lucent

Title : CRs to 25.211 and 25.214 for the start of the message indicator for CPCH

Document for : Approval

1. Introduction

At CPCH informal meeting in San Diego, a new idea, the start of the message indicator was proposed for solving false mobile problem. The key concept of this idea is that a specific pattern is transmitted during the first a few frames of DL DPCH after Power Control preamble in order to indicate the starting point of DL DPCH. This method can prevent a false mobile from using a wrong CPCH channel. Therefore, UE can know whether it uses right or wrong CPCH channel using this information.

2. Details about the start of the message indicator for CPCH

- This message is always transmitted during the first $N_{\text{Start_Message}}$ frames of DL DPCH for CPCH after Power Control preamble.
- Higher layers provide the value of $N_{\text{Start_Message}}$ frames.
- This message does not require a request from higher layers.
- A predefined pattern, [1010], is repeatedly mapped onto the data field of DL DPCH during the first $N_{\text{Start_Message}}$ frames after Power Control preamble.

3. Conclusion

We recommend that the CR be adopted as a specification for CPCH.

CHANGE REQUEST		Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.
25.211	CR	042r1
GSM (AA.BB) or 3G (AA.BBB) specification number ↑		↑ CR number as allocated by MCC support team
For submission to: TSG-RAN #7	for approval <input checked="" type="checkbox"/>	Current Version: 3.1.1
list expected approval meeting # here ↑	for information <input type="checkbox"/>	strategic <input type="checkbox"/> (for SMG use only)
		non-strategic <input type="checkbox"/>

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
 (at least one should be marked with an X)

Source: LGIC, Samsung, GBT, Lucent **Date:** 2000-02-29

Subject: The start of the message indicator

Work item:

Category:	F Correction <input type="checkbox"/> A Corresponds to a correction in an earlier release <input type="checkbox"/> B Addition of feature <input checked="" type="checkbox"/> C Functional modification of feature <input type="checkbox"/> D Editorial modification <input type="checkbox"/>	Release:	Phase 2 <input type="checkbox"/> Release 96 <input type="checkbox"/> Release 97 <input type="checkbox"/> Release 98 <input type="checkbox"/> Release 99 <input checked="" type="checkbox"/> Release 00 <input type="checkbox"/>
------------------	--	-----------------	--

(only one category shall be marked with an X)

Reason for change: To solve false mobile problem

Clauses affected: 5.3.2.3

Other specs affected:	Other 3G core specifications <input type="checkbox"/> Other GSM core specifications <input type="checkbox"/> MS test specifications <input type="checkbox"/> BSS test specifications <input type="checkbox"/> O&M specifications <input type="checkbox"/>	→ List of CRs: → List of CRs: → List of CRs: → List of CRs: → List of CRs:	
------------------------------	---	--	--

Other comments:



<----- double-click here for help and instructions on how to create a CR.

5.3.2.3 DL-DPCCH for CPCH

The spreading factor for the UL-DPCCH (message control part) is 256. The spreading factor for the DL-DPCCH (message control part) is 512. The following table 15 shows the DL-DPCCH fields (message control part) and DL-DPDCH fields, which are identical to the first row of table 11 in section 5.3.2.

Table 15: DPDCH and DPCCH fields for CPCH message transmission

Slot Format #	Channel Bit Rate (kbps)	Channel Symbol Rate (ksps)	SF	Bits/Frame			Bits/Slot	DPDCH Bits/Slot		DPCCH Bits/Slot		
				DPDCH	DPCCH	TOT		NData1	NData2	NTFCI	NTPC	NPilot
0	15	7.5	512	60	90	150	10	20	24	0	2	4

The start of the message indicator shall be transmitted during the first $N_{\text{Start Message}}$ frames of DL DPCCH after Power Control preamble. [1010] pattern is mapped onto N_{Data2} field for the start of the message indicator. The value of $N_{\text{Start Message}}$ shall be provided by higher layers.

CHANGE REQUEST		Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.
25.214	CR	063
GSM (AA.BB) or 3G (AA.BBB) specification number ↑		↑ CR number as allocated by MCC support team
For submission to: TSG-RAN #7	for approval <input checked="" type="checkbox"/>	Current Version: 3.1.1
list expected approval meeting # here ↑	for information <input type="checkbox"/>	strategic <input type="checkbox"/> (for SMG use only)
		non-strategic <input type="checkbox"/>

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
(at least one should be marked with an X)

Source: LGIC, Samsung, GBT, Lucent **Date:** 2000-02-29

Subject: The start of the message indicator

Work item:

Category:	F Correction <input type="checkbox"/> A Corresponds to a correction in an earlier release <input type="checkbox"/> B Addition of feature <input checked="" type="checkbox"/> C Functional modification of feature <input type="checkbox"/> D Editorial modification <input type="checkbox"/>	Release:	Phase 2 <input type="checkbox"/> Release 96 <input type="checkbox"/> Release 97 <input type="checkbox"/> Release 98 <input type="checkbox"/> Release 99 <input checked="" type="checkbox"/> Release 00 <input type="checkbox"/>
------------------	--	-----------------	--

(only one category shall be marked with an X)

Reason for change: To solve false mobile problem

Clauses affected: 6.2

Other specs affected:	Other 3G core specifications <input type="checkbox"/> Other GSM core specifications <input type="checkbox"/> MS test specifications <input type="checkbox"/> BSS test specifications <input type="checkbox"/> O&M specifications <input type="checkbox"/>	→ List of CRs: → List of CRs: → List of CRs: → List of CRs: → List of CRs:	
------------------------------	---	--	--

Other comments:



<----- double-click here for help and instructions on how to create a CR.

6.2 CPCH Access Procedures

For each CPCH physical channel in a CPCH set allocated to a cell the following physical layer parameters are included in the System Information message:

- UL Access Preamble (AP) scrambling code.
- UL Access Preamble signature set
- The Access preamble slot sub-channels group
- AP- AICH preamble channelization code.
- UL Collision Detection(CD) preamble scrambling code.
- CD Preamble signature set
- CD preamble slot sub-channels group
- CD-AICH preamble channelization code.
- CPCH UL scrambling code.
- CPCH UL channelization code. (variable, data rate dependant)
- DPCCH DL channelization code.([512] chip)

NOTE: There may be some overlap between the AP signature set and CD signature set if they correspond to the same scrambling code.

The following are access, collision detection/resolution and CPCH data transmission parameters:

Power ramp-up, Access and Timing parameters (Physical layer parameters)

- 1) $N_{AP_retrans_max}$ = Maximum Number of allowed consecutive access attempts (retransmitted preambles) if there is no AICH response. This is a CPCH parameter and is equivalent to $Preamble_Retrans_Max$ in RACH.
[RACH/CPCH parameter]
- 2) $P_{RACH} = P_{CPCH}$ = Initial open loop power level for the first CPCH access preamble sent by the UE.
[RACH/CPCH parameter]
- 3) ΔP_0 = Power step size for each successive CPCH access preamble.
[RACH/CPCH parameter]
- 4) ΔP_1 = Power step size for each successive RACH/CPCH access preamble in case of negative AICH. A timer is set upon receipt of a negative AICH. This timer is used to determine the period after receipt of a negative AICH when ΔP_1 is used in place of ΔP_0 .
[RACH/CPCH parameter]
- 5) T_{cph} = CPCH transmission timing parameter: This parameter is identical to PRACH/AICH transmission timing parameter.
[RACH/CPCH parameter]
- 6) $L_{pc-preamble}$ = Length of power control preamble (0 or 8 slots)
[CPCH parameter]
- 7) $N_{Start_Message}$ = Number of frames for the transmission of the 'start of the message indicator' in DL-DPDCH

NOTE: It is FFS if ΔP_0 for the CPCH access may be different from ΔP_0 for the RACH access as defined in section 6.1.

The CPCH -access procedure in the physical layer is:

- 1) The UE MAC function selects a CPCH transport channel from the channels available in the assigned CPCH set. The CPCH channel selection includes a dynamic persistence algorithm (similar to RACH) for the selected CPCH channel.
- 2) The UE MAC function builds a transport block set for the next TTI using transport formats which are assigned to the logical channel with data to transmit. The UE MAC function sends this transport block set to the UE PHY function for CPCH access and uplink transmission on the selected CPCH transport channel.
- 3) The UE sets the preamble transmit power to the value P_{CPCH} which is supplied by the MAC layer for initial power level for this CPCH access attempt.
- 4) The UE sets the AP Retransmission Counter to $N_{AP_Retrans_Max}$ (value TBD).
- 5) The UE randomly selects a CPCH-AP signature from the signature set for this selected CPCH channel. The random function is TBD.
- 6) The UE Derives the available CPCH-AP access slots in the next two frames, defined by SFN and SFN+1 in the AP access slot sub-channel group with the help of SFN and table 7 in section 6.1. The UE randomly selects one access slot from the available access slots in the next frame, defined by SFN, if there is one available. If there is no access slot available in the next frame, defined by SFN then, randomly selects one access slot from the available access slots in the following frame, defined by SFN+1. Random function is TBD
- 7) The UE transmits the AP using the MAC supplied uplink access slot, signature, and initial preamble transmission power.
- 8) If the UE does not detect the positive or negative acquisition indicator corresponding to the selected signature in the downlink access slot corresponding to the selected uplink access slot, the UE:
 - a) Selects the next uplink access slot from among the access slots in the CPCH-AP sub-channel group, as selected in 4.1. There must be a minimum distance of three or four access slots from the uplink access slot in which the last preamble was transmitted depending on the CPCH/AICH transmission timing parameter. [NOTE: Use of random function here to select access slot is FFS for RACH and CPCH.].
 - b) Increases the preamble transmission power with the specified offset ΔP . Power offset ΔP_0 is used unless the negative AICH timer is running, in which case ΔP_1 is used instead..
 - c) Decrease the Preamble Retransmission Counter by one.
 - d) If the Preamble Retransmission Counter < 0 , the UE aborts the access attempt and sends a failure message to the MAC layer.
- 9) If the UE detects the AP-AICH_nak (negative acquisition indicator) corresponding to the selected signature in the downlink access slot corresponding to the selected uplink access slot, the UE aborts the access attempt and sends a failure message to the MAC layer. The UE sets the negative AICH timer to indicate use of ΔP_1 use as the preamble power offset until timer expiry
- 10) Upon reception of AP-AICH, the access segment ends and the contention resolution segment begins. In this segment, the UE randomly selects a CD signature from the signature set and also select one-CD access slot sub-channel from the CD sub-channel group supported in the cell and transmits a CD Preamble, then waits for a CD-AICH from the Node B.
- 11) If the UE does not receive a CD-AICH in the designated slot, the UE aborts the access attempt and sends a failure message to the MAC layer.
- 12) If the UE receives a CD-AICH in the designated slot with a signature that does not match the signature used in the CD Preamble, the UE aborts the access attempt and sends a failure message to the MAC layer.

~~13) 13)~~ If the UE receives a CD-AICH with a matching signature, the UE transmits the power control preamble $\tau_{cd-p-pc-p}$ ms later as measured from initiation of the CD Preamble. The transmission of the message portion of the burst starts immediately after the power control preamble.

14) The UE shall test the value of the ‘start of the message indicator’ received from DL-DPDCH during the first $N_{Start_Message}$ frames after Power Control preamble. The ‘start of the message indicator’ is a known sequence repeated on a frame by frame basis. The value of $N_{Start_Message}$ shall be provided by higher layers.

| ~~4~~15) During CPCH Packet Data transmission, the UE and UTRAN perform inner-loop power control on both the CPCH UL and the DPCCH DL.

| ~~4~~516) If the UE detects loss of DPCCH DL during transmission of the power control preamble or the packet data, the UE halts CPCH UL transmission, aborts the access attempt and sends a failure message to the MAC layer.

| ~~4~~617) If the UE completes the transmission of the packet data, the UE sends a success message to the MAC layer.