CR-Form-v7

CHANGE REQUEST

# TS	S 33.220 CR CRNum #rev - # (Current version: V 0.2.0 第
For <u>HELP</u> on using this form, see bottom of this page or look at the pop-up text over the % symbols.		
Proposed change	### Affects: UICC apps第 ME Radio Acc	cess Network X Core Network
Title:	The NAF id in bootstrapping procedure	
	- The first of the second principle of the second prin	
Source:	Huawei Technologies Co., Ltd.	
Work item code:	€ GBA	<i>Date:</i>
0-1		Dalana a 98 Dal C
Category:		Release: # Rel-6
	Use <u>one</u> of the following categories: F (correction)	Use <u>one</u> of the following releases: 2 (GSM Phase 2)
	A (corresponds to a correction in an earlier release)	
	B (addition of feature),	R97 (Release 1997)
	C (functional modification of feature)	R98 (Release 1998)
	D (editorial modification)	R99 (Release 1999)
	Detailed explanations of the above categories can	Rel-4 (Release 4)
	be found in 3GPP TR 21.900.	Rel-5 (Release 5)
		Rel-6 (Release 6)
Reason for chang	The section 4.2.2.1 of TS 33.220 includes the applicability of the key material to a defined se procedure, the step 8, the ok message will supparameter n to UE. the UE and BSF use parameter NAF_id_n to the key derivation. If the no key derivation is performed. In the bootstraprovide the information of NAF that it wants to which NAF will be applied and, then BSF can'there also is an incorrct reference in step 8.	t of NAFs". In bootstrapping oply the Transaction Identifier and meter <i>n</i> to decide the inputing he parameter <i>n</i> is not supplied then upping procedure, the UE doesn't talk to, so the BSF doesn't know
Summary of char	ge: In bootstrapping procedure, the UE provides wants to connect to.	BSF with the Identity of NAF that it
Consequences if not approved:	# The BSF can't determine the parameter n for	key derivation
Clauses affected:	₩ 4.3.2	
Other specs Affected:	Y N X Other core specifications	
Other comments:	\mathbf{x}	

4.3.2 Bootstrapping procedures

When a UE wants to interact with an NAF, and it knows that bootstrapping procedure is needed, it shall first perform a bootstrapping authentication (see Figure 1)

Editor's notes: Zh interface related procedure will be added here in future development. It may re-use Cx interface that is specified in TS 29.228.

Otherwise, the UE shall perform a bootstrapping authentication only when it has received bootstrapping initiation required message or a key update indication from the NAF (cf. subclause 4.3.3).




Figure 1: The bootstrapping procedure

- 1. The UE sends an HTTP request towards the BSF. The request message includes the user identity and the NAF identity to which the UE wants to connect.
- 2. BSF retrieves the user profile and a challenge, i.e. the Authentication Vector (AV, AV = RAND||AUTN||XRES||CK||IK) over Zh interface from the HSS.
- 3. Then BSF forwards the RAND and AUTN to the UE in the 401 message (without the CK, IK and XRES). This is to demand the UE to authenticate itself.
- 4. The UE calculates the message authentication code (MAC) so as to verify the challenge from authenticated network; the UE also calculates CK, IK and RES. This will result in session keys IK and CK in both BSF and UE.
- 5. The UE sends request again, with the Digest AKA RES as the response to the BSF.
- 6. If the RES equals to the XRES that is in the AV, the UE is authenticated.

- 7. BSF generates key material Ks by concatenating CK and IK. Ks is used to derive the key material Ks NAF. Ks NAF is used for securing the Ua interface.
- 8. The BSF shall send 200 OK message and shall supply a transaction identifier to the UE to indicate the success of the authentication. The BSF may also supply the parameter *n* used to determine the NAF_Id_n (cf. previous following bullet) to the UE over the Ub interface. The BSF should determine the parameter n according the NAF identity and the defined set of NAFs. If the parameter *n* is not supplied then no key derivation is performed, i.e. Ks = Ks_NAF.
- 9. The key material Ks is generated in UE by concatenating CK and IK. The Ks is used to derive the key material Ks_NAF. Ks_NAF is used for securing the Ua interface.

Ks_NAF is computed as Ks_NAF = KDF (Ks, key derivation parameters), where KDF is a suitable key derivation function, and the key derivation parameters include the user's IMSI, the NAF_Id_n and RAND. The NAF_Id_n consists of the n rightmost domain labels in the DNS name of the NAF, separated by dots (n=1,...,7). For n=0, NAF_Id_n equals the full DNS name of the NAF. The next bullet specifies how the UE obtains n.

NOTE: This note gives an example how to obtain the NAF_Id_n: if the DNS name of the NAF is "server1.presence.bootstrap.operator.com", and n = 3, then NAF_Id_n = "bootstrap.operator.com".

Editor's note: the definition of the KDF and the possible inclusion of further key derivation parameters is left to ETSI SAGE.