

TSG RAN Meeting #16
Biarritz, France
3rd-6th September 2002

RP-020631

Title CRs (R'99 and Rel-4/Rel-5 Category A) to TS 25.331
Source Alcatel
Agenda Item 7.2.3

RAN2 Tdoc	Spec	Curr Ver	New Ver	CR		Cat	Ph	Title	Acronym
	25.331	3.b.0	3.c.0	1671	2	F	R99	SRNS relocation with integrity	TEI
	25.331	4.5.0	4.6.0	1672	1	A	Rel-4	SRNS relocation with integrity	TEI
	25.331	5.1.0	5.2.0	1673	1	A	Rel-5	SRNS relocation with integrity	TEI

CHANGE REQUEST

⌘ **25.331 CR 1671** ⌘ rev **2** ⌘ Current version: **3.b.0** ⌘

For **HELP** on using this form, see bottom of this page or look at the pop-up text over the ⌘ symbols.

Proposed change affects: UICC apps ME Radio Access Network Core Network

Title:	⌘ SRNS relocation with integrity		
Source:	⌘ Alcatel		
Work item code:	⌘ TEI	Date:	⌘ 09/8/2002
Category:	⌘ F	Release:	⌘ R99
	Use <u>one</u> of the following categories: F (correction) A (corresponds to a correction in an earlier release) B (addition of feature), C (functional modification of feature) D (editorial modification) Detailed explanations of the above categories can be found in 3GPP TR 21.900.		Use <u>one</u> of the following releases: 2 (GSM Phase 2) R96 (Release 1996) R97 (Release 1997) R98 (Release 1998) R99 (Release 1999) Rel-4 (Release 4) Rel-5 (Release 5) Rel-6 (Release 6)

Reason for change:	⌘ With the current standard the IE "integrity check info" is supposed to be calculated by the source SRNC in the case of a SRNS relocation "UE involved". However the source SRNC is not always able to calculate this if the target SRNC uses a message format that the source SRNC does not understand (i.e. Rel 4 message, or a non critical extension that is not known by the source SRNC). Also the target SRNC could choose an integrity protection algorithm that is not implemented by the source SRNC.
Summary of change:	⌘ A TargetSRNC to SourceSRNC Transparent Container Extension is defined that carries the calculated MAC-I, the RB Id the RRC SN and the amount of padding that exists in the RRC container defined in RANAP A spare entry in the RRC IE "Target RNC to Source RNC Transparent Container" which includes the entirely compiled downlink message. An additional optional IE giving the RB Id on which the relocation message will be transmitted to the UE is added to the IE "SRNS RELOCATION INFO". Absence of this IE indicates that the source SRNC expects a formerly defined entry and it will calculate the MAC-I itself (if possible). Presence means that the target RNC should use the new defined entry "DL DCCH message"
	Impact analysis: The problem resolved is the SRNS relocation with integrity active between two RNCs that use different versions of the protocol for the case of "UE involved". There is no backwards incompatibility problems between two RNCs where one implements the change and the other one doesn't. The changes only affect the RNC and the CN.
Consequences if not approved:	⌘ It is not possible to apply integrity protection in the case of SRNS relocation of the type "UE involved" in case the target and the source RNC do not support the

same messages, and though the SRNS relocation is not possible in all cases.

Clauses affected:	⌘	11.5, 14.12.2, 14.12.4.2										
Other specs affected:	⌘	<table border="1"><tr><td>Y</td><td>N</td></tr><tr><td><input type="checkbox"/></td><td><input checked="" type="checkbox"/></td></tr><tr><td><input type="checkbox"/></td><td><input checked="" type="checkbox"/></td></tr><tr><td><input type="checkbox"/></td><td><input checked="" type="checkbox"/></td></tr></table>	Y	N	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Other core specifications	⌘
	Y	N										
	<input type="checkbox"/>	<input checked="" type="checkbox"/>										
<input type="checkbox"/>	<input checked="" type="checkbox"/>											
<input type="checkbox"/>	<input checked="" type="checkbox"/>											
		Test specifications										
		O&M Specifications										
Other comments:	⌘											

How to create CRs using this form:

Comprehensive information and tips about how to create CRs can be found at <http://www.3gpp.org/specs/CR.htm>. Below is a brief summary:

- 1) Fill out the above form. The symbols above marked ⌘ contain pop-up help information about the field that they are closest to.
- 2) Obtain the latest version for the release of the specification to which the change is proposed. Use the MS Word "revision marks" feature (also known as "track changes") when making the changes. All 3GPP specifications can be downloaded from the 3GPP server under <ftp://ftp.3gpp.org/specs/> For the latest version, look for the directory name with the latest date e.g. 2001-03 contains the specifications resulting from the March 2001 TSG meetings.
- 3) With "track changes" disabled, paste the entire CR form (use CTRL-A to select it) into the specification just in front of the clause containing the first piece of changed text. Delete those parts of the specification which are not relevant to the change request.

11.5 RRC information between network nodes

```

Internode-definitions DEFINITIONS AUTOMATIC TAGS ::=
BEGIN

IMPORTS

    HandoverToUTRANCommand,
    MeasurementReport,
    PhysicalChannelReconfiguration,
    RadioBearerReconfiguration,
    RadioBearerRelease,
    RadioBearerSetup,
    RRC-FailureInfo,
    TransportChannelReconfiguration
FROM PDU-definitions

-- Core Network IEs :
    CN-DomainIdentity,
    CN-DomainInformationList,
    CN-DRX-CycleLengthCoefficient,
    NAS-SystemInformationGSM-MAP,
-- UTRAN Mobility IEs :
    CellIdentity,
    URA-Identity,
-- User Equipment IEs :
    C-RNTI,
    DL-PhysChCapabilityFDD-v380ext,
    FailureCauseWithProtErr,
    RRC-MessageSequenceNumber,
    STARTList,
    STARTSingle,
    START-Value,
    U-RNTI,
    UE-RadioAccessCapability,
    UE-RadioAccessCapability-v370ext,
    UE-RadioAccessCapability-v380ext,
    UE-RadioAccessCapability-v3a0ext,
-- Radio Bearer IEs :
    PredefinedConfigStatusList,
    PredefinedConfigValueTag,
    RAB-InformationSetupList,
    RB-Identity,
    SRB-InformationSetupList,
-- Transport Channel IEs :
    CPCH-SetID,
    DL-CommonTransChInfo,
    DL-AddReconfTransChInfoList,
    DRAC-StaticInformationList,
    UL-CommonTransChInfo,
    UL-AddReconfTransChInfoList,
-- Measurement IEs :
    MeasurementIdentity,
    MeasurementReportingMode,
    MeasurementType,
    AdditionalMeasurementID-List,
    PositionEstimate,
-- Other IEs :
    InterRAT-UE-RadioAccessCapabilityList
FROM InformationElements

    maxCNdomains,
    maxNoOfMeas,
    maxRB,
    maxSRBsetup
FROM Constant-definitions;

-- Part 1: Class definitions similar to what has been defined in 11.1 for RRC messages
-- Information that is transferred in the same direction and across the same path is grouped
-- *****
--
-- RRC information, to target RNC
--

```

```

-- *****
-- RRC Information to target RNC sent either from source RNC or from another RAT

ToTargetRNC-Container ::= CHOICE {
    interRATHandover          InterRATHandoverInfoWithInterRATCapabilities,
    srncRelocation            SRNC-RelocationInfo,
    extension                 NULL
}

-- *****
--
-- RRC information, target RNC to source RNC
--
-- *****

TargetRNC-ToSourceRNC-Container ::= CHOICE {
    radioBearerSetup          RadioBearerSetup,
    radioBearerReconfiguration RadioBearerReconfiguration,
    radioBearerRelease        RadioBearerRelease,
    transportChannelReconfiguration TransportChannelReconfiguration,
    physicalChannelReconfiguration PhysicalChannelReconfiguration,
    rrc-FailureInfo           RRC-FailureInfo,
    dL-DCCHmessage           OCTET STRINGextension NULL
}

-- Part2: Container definitions, similar to the PDU definitions in 11.2 for RRC messages
-- In alphabetical order

-- *****
--
-- Handover to UTRAN information
--
-- *****

InterRATHandoverInfoWithInterRATCapabilities ::= CHOICE {
    r3                        SEQUENCE {
        -- IE InterRATHandoverInfoWithInterRATCapabilities-r3-IEs also
        -- includes non critical extensions
        interRATHandoverInfo-r3 InterRATHandoverInfoWithInterRATCapabilities-r3-IEs,
        v390NonCriticalExtensions SEQUENCE {
            interRATHandoverInfoWithInterRATCapabilities-v390ext
        }
        InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs,
        -- Reserved for future non critical extension
        nonCriticalExtensions SEQUENCE {} OPTIONAL
    },
    criticalExtensions SEQUENCE {}
}

InterRATHandoverInfoWithInterRATCapabilities-r3-IEs ::= SEQUENCE {
    -- The order of the IEs may not reflect the tabular format
    -- but has been chosen to simplify the handling of the information in the BSC
    -- Other IEs
    ue-RATSpecificCapability InterRAT-UE-RadioAccessCapabilityList OPTIONAL,
    -- interRATHandoverInfo, Octet string is used to obtain 8 bit length field prior to
    -- actual information. This makes it possible for BSS to transparently handle information
    -- received via GSM air interface even when it includes non critical extensions.
    -- The octet string shall include the InterRATHandoverInfo information
    -- The BSS can re-use the 04.18 length field received from the MS
    interRATHandoverInfo OCTET STRING (SIZE (0..255))
}

InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs ::= SEQUENCE {
    -- User equipment IEs
    failureCauseWithProtErr FailureCauseWithProtErr OPTIONAL
}

-- *****
--
-- SRNC Relocation information
--
-- *****

SRNC-RelocationInfo ::= CHOICE {
    r3 SEQUENCE {

```

```

sRNC-RelocationInfo-r3          SRNC-RelocationInfo-r3-IEs,
v380NonCriticalExtensions      SEQUENCE {
  sRNC-RelocationInfo-v380ext  SRNC-RelocationInfo-v380ext-IEs,
  -- Reserved for future non critical extension
  v390NonCriticalExtensions    SEQUENCE {
    sRNC-RelocationInfo-v390ext  SRNC-RelocationInfo-v390ext-IEs,
    v3a0NonCriticalExtensions    SEQUENCE {
      sRNC-RelocationInfo-v3a0ext  SRNC-RelocationInfo-v3a0ext-IEs,
      v3b0NonCriticalExtensions    SEQUENCE {
        sRNC-RelocationInfo-v3b0ext  SRNC-RelocationInfo-v3b0ext-IEs,
        v3c0NonCriticalExtensions    SEQUENCE {
          SRNC-RelocationInfo-v3c0ext  SRNC-RelocationInfo-v3c0ext-IEs,
          -- Reserved for future non critical extension
        }
      }
    }
  }
}
OPTIONAL
}
OPTIONAL
}
OPTIONAL
},
criticalExtensions             SEQUENCE {}
}

```

```

SRNC-RelocationInfo-r3-IEs ::= SEQUENCE {
  -- Non-RRC IEs
  stateOfRRC                      StateOfRRC,
  stateOfRRC-Procedure             StateOfRRC-Procedure,
  -- Ciphering related information IEs
  -- If the extension v380 is included use the extension for the ciphering status per CN domain
  cipheringStatus                  CipheringStatus,
  calculationTimeForCiphering      CalculationTimeForCiphering      OPTIONAL,
  cipheringInfoPerRB-List          CipheringInfoPerRB-List          OPTIONAL,
  count-C-List                     COUNT-C-List                     OPTIONAL,
  integrityProtectionStatus        IntegrityProtectionStatus,
  srb-SpecificIntegrityProtInfoList SRB-SpecificIntegrityProtInfoList,
  implementationSpecificParams      ImplementationSpecificParams      OPTIONAL,
  -- User equipment IEs
  u-RNTI                           U-RNTI,
  c-RNTI                           C-RNTI                           OPTIONAL,
  ue-RadioAccessCapability         UE-RadioAccessCapability,
  ue-Positioning-LastKnownPos      UE-Positioning-LastKnownPos      OPTIONAL,
  -- Other IEs
  ue-RATSpecificCapability         InterRAT-UE-RadioAccessCapabilityList  OPTIONAL,
  -- UTRAN mobility IEs
  ura-Identity                     URA-Identity                     OPTIONAL,
  -- Core network IEs
  cn-CommonGSM-MAP-NAS-SysInfo     NAS-SystemInformationGSM-MAP,
  cn-DomainInformationList         CN-DomainInformationList         OPTIONAL,
  -- Measurement IEs
  ongoingMeasRepList               OngoingMeasRepList               OPTIONAL,
  -- Radio bearer IEs
  predefinedConfigStatusList        PredefinedConfigStatusList,
  srb-InformationList               SRB-InformationSetupList,
  rab-InformationList               RAB-InformationSetupList         OPTIONAL,
  -- Transport channel IEs
  ul-CommonTransChInfo             UL-CommonTransChInfo             OPTIONAL,
  ul-TransChInfoList               UL-AddReconfTransChInfoList     OPTIONAL,
  modeSpecificInfo                 CHOICE {
    fdd                             SEQUENCE {
      cpch-SetID                    CPCH-SetID                      OPTIONAL,
      transChDRAC-Info               DRAC-StaticInformationList     OPTIONAL
    },
    tdd                             NULL
  },
  dl-CommonTransChInfo             DL-CommonTransChInfo             OPTIONAL,
  dl-TransChInfoList               DL-AddReconfTransChInfoList     OPTIONAL,
  -- Measurement report
  measurementReport                 MeasurementReport                 OPTIONAL
}

```

```

SRNC-RelocationInfo-v380ext-IEs ::= SEQUENCE {
  -- Ciphering related information IEs
  cn-DomainIdentity                 CN-DomainIdentity,
  cipheringStatusList               CipheringStatusList
}

```

```

SRNC-RelocationInfo-v390ext-IEs ::= SEQUENCE {
  cn-DomainInformationList-v390ext  CN-DomainInformationList-v390ext  OPTIONAL,

```

```

    ue-RadioAccessCapability-v370ext    UE-RadioAccessCapability-v370ext    OPTIONAL,
    ue-RadioAccessCapability-v380ext    UE-RadioAccessCapability-v380ext    OPTIONAL,
    dl-PhysChCapabilityFDD-v380ext      DL-PhysChCapabilityFDD-v380ext,
    failureCauseWithProtErr            FailureCauseWithProtErr            OPTIONAL
}

SRNC-RelocationInfo-v3a0ext-IEs ::= SEQUENCE {
    cipheringInfoForSRB1-v3a0ext        CipheringInfoPerRB-List-v3a0ext,
    ue-RadioAccessCapability-v3a0ext    UE-RadioAccessCapability-v3a0ext    OPTIONAL,
    -- cn-domain identity for IE startValueForCiphering-v3a0ext is specified
    -- in subsequent extension (SRNC-RelocationInfo-v3b0ext-IEs)
    startValueForCiphering-v3a0ext      START-Value
}

SRNC-RelocationInfo-v3b0ext-IEs ::= SEQUENCE {
    -- cn-domain identity for IE startValueForCiphering-v3a0ext included in previous extension
    cn-DomainIdentity                  CN-DomainIdentity,
    -- the remaining start values are contained in IE startValueForCiphering-v3b0ext
    startValueForCiphering-v3b0ext      STARTList2                            OPTIONAL
}

SRNC-RelocationInfo-v3c0ext-IEs ::= SEQUENCE {
    -- RB Identity on which the source SRNC will send the message contained in the
    -- IE "TargetRNC-ToSourceRNC-Container". Only included if type is "UE involved"
    rb-Identity                        RB-Identity                            OPTIONAL
}

STARTList2 ::= SEQUENCE (SIZE (2..maxCNdomains)) OF
    STARTSingle

CipheringInfoPerRB-List-v3a0ext ::= SEQUENCE {
    dl-UM-SN                            BIT STRING (SIZE (7))
}

CipheringStatusList ::= SEQUENCE (SIZE (1..maxCNdomains)) OF
    CipheringStatusCNdomain

CipheringStatusCNdomain ::= SEQUENCE {
    cn-DomainIdentity                  CN-DomainIdentity,
    cipheringStatus                    CipheringStatus
}

-- IE definitions

CalculationTimeForCiphering ::= SEQUENCE {
    cell-Id                            CellIdentity,
    sfn                                INTEGER (0..4095)
}

CipheringInfoPerRB ::= SEQUENCE {
    dl-HFN                              BIT STRING (SIZE (20..25)),
    ul-HFN                              BIT STRING (SIZE (20..25))
}

-- TABULAR: CipheringInfoPerRB-List, multiplicity value numberOfRadioBearers
-- has been replaced with maxRB.
CipheringInfoPerRB-List ::= SEQUENCE (SIZE (1..maxRB)) OF
    CipheringInfoPerRB

CipheringStatus ::= ENUMERATED {
    started, notStarted }

CN-DomainInformation-v390ext ::= SEQUENCE {
    cn-DRX-CycleLengthCoeff            CN-DRX-CycleLengthCoefficient
}

CN-DomainInformationList-v390ext ::= SEQUENCE (SIZE (1..maxCNdomains)) OF
    CN-DomainInformation-v390ext

COUNT-C-List ::= SEQUENCE (SIZE (1..maxCNdomains)) OF
    COUNT-CSingle

COUNT-CSingle ::= SEQUENCE {
    cn-DomainIdentity                  CN-DomainIdentity,
    count-C                            BIT STRING (SIZE (32))
}

```

```

ImplementationSpecificParams ::= BIT STRING (SIZE (1..512))

IntegrityProtectionStatus ::= ENUMERATED {
    started, notStarted }

MeasurementCommandWithType ::= CHOICE {
    setup          MeasurementType,
    modify         NULL,
    release        NULL
}

OngoingMeasRep ::= SEQUENCE {
    measurementIdentity          MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType
    measurementCommandWithType MeasurementCommandWithType,
    measurementReportingMode   MeasurementReportingMode           OPTIONAL,
    additionalMeasurementID-List AdditionalMeasurementID-List     OPTIONAL
}

OngoingMeasRepList ::= SEQUENCE (SIZE (1..maxNoOfMeas)) OF
    OngoingMeasRep

SRB-SpecificIntegrityProtInfo ::= SEQUENCE {
    ul-RRC-HFN          BIT STRING (SIZE (28)),
    dl-RRC-HFN          BIT STRING (SIZE (28)),
    ul-RRC-SequenceNumber RRC-MessageSequenceNumber,
    dl-RRC-SequenceNumber RRC-MessageSequenceNumber
}

SRB-SpecificIntegrityProtInfoList ::= SEQUENCE (SIZE (4..maxSRBsetup)) OF
    SRB-SpecificIntegrityProtInfo

StateOfRRC ::= ENUMERATED {
    cell-DCH, cell-FACH,
    cell-PCH, ura-PCH }

StateOfRRC-Procedure ::= ENUMERATED {
    awaitNoRRC-Message,
    awaitRRC-ConnectionRe-establishmentComplete,
    awaitRB-SetupComplete,
    awaitRB-ReconfigurationComplete,
    awaitTransportCH-ReconfigurationComplete,
    awaitPhysicalCH-ReconfigurationComplete,
    awaitActiveSetUpdateComplete,
    awaitHandoverComplete,
    sendCellUpdateConfirm,
    sendUraUpdateConfirm,
    sendRrcConnectionReestablishment,
    otherStates
}

UE-Positioning-LastKnownPos ::= SEQUENCE {
    sfn          INTEGER (0..4095),
    cell-id      CellIdentity,
    positionEstimate PositionEstimate
}

END
*****Next modified section*****

```

14.12.2 RRC information, target RNC to source RNC

There are 2 possible cases for RNC relocation:

1. The UE is already under control of target RNC; and
2. The SRNC Relocation with Hard Handover (UE still under control of SRNC), but UE is moving to a location controlled by the target RNC (based on measurement information).

In case 1 the relocation is transparent to the UE and there is no "reverse" direction container. The SRNC just assigns the 'serving' function to the target RNC, which then becomes the Serving RNC.

In case 2 the relocation is initiated by SRNC, which also provides the RRC Initialisation Information to the target RNC. Base on this information, the target RNC prepares the Hard Handover Message ("Physical channel reconfiguration" (subclause 8.2.6), "radio bearer establishment" (subclause 8.2.1), "Radio bearer reconfiguration" (subclause 8.2.2), "Radio bearer release" (subclause 8.2.3) or "Transport channel reconfiguration" (subclause 8.2.4).

In case 2 two possibilities are defined in order to transmit the relocation message from the target RNC to the source RNC which can be chosen by the source RNC by including or not including the IE "RB Id for handover message" in the IE "SRNS Relocation Info".

In case the IE "RB Id for handover message" has been received by the target RNC in the IE "SRNS Relocation Info", the target RNC should choose IE "DL DCCH message" and include the DL DCCH message that should be transmitted transparently to the UE by the source RNC. In that case, the target RNC is integrity protecting the message if applicable.

If the target RNC did not receive the IE "RB Id for handover message" in the IE "SRNS Relocation Info" the target RNC should use another choice. In that case, the source RNC should integrity protect the message before transmitting it to the UE if applicable.

The source RNC then transmits the Handover Message to the UE, which then performs the handover.

In the successful case, the UE transmits an XXX COMPLETE message, using the new configuration, to the target RNC.

In case of failure, the UE transmits an XXX FAILURE, using the old configuration, to the source RNC and the RRC context remains unchanged (has to be confirmed and checked with the SRNS relocation procedure).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE <i>RRC message</i>	MP			At least one spare choice, Criticality: Reject, is needed
>RADIO BEARER SETUP			RADIO BEARER SETUP 10.2.31	
>RADIO BEARER RECONFIGURATION			RADIO BEARER RECONFIGURATION 10.2.25	
>RADIO BEARER RELEASE			RADIO BEARER RELEASE 10.2.28	
>TRANSPORT CHANNEL RECONFIGURATION			TRANSPORT CHANNEL RECONFIGURATION 10.2.51	
>PHYSICAL CHANNEL RECONFIGURATION			PHYSICAL CHANNEL RECONFIGURATION 10.2.20	
>RRC FAILURE INFO			RRC FAILURE INFO 10.2.41 a	
>DL DCCH message			OCTET STRING	

*****Next modified section*****

14.12.4.2 SRNS RELOCATION INFO

This RRC message is sent between network nodes when preparing for an SRNS relocation.

With the presence or absence of the IE “RB identity for Hard Handover message” the source RNC indicates to the target SRNC whether the source RNC expects to receive the choice “DL DCCH message” in the IE “RRC information, target RNC to source RNC” in case the SRNS relocation is of type “UE involved”. Furthermore the target RNC uses this information for the calculation of the MAC-I

Direction: source RAT→target RNC

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
Non RRC IEs				
<u>RB identity for Handover message</u>	<u>OP</u>		<u>RB identity 10.3.4.16</u>	<u>Gives the id of the radio bearer on which the source RNC will transmit the RRC message in the case the relocation is of type “UE involved”.</u>
>State of RRC	MP		RRC state indicator, 10.3.3.35a	
>State of RRC procedure	MP		Enumerated (await no RRC message, Complete, await RB Setup Complete, await RB Reconfiguration Complete, await RB Release Complete, await Transport CH Reconfiguration Complete, await Physical CH Reconfiguration Complete, await Active Set Update Complete, await Handover Complete, send Cell Update Confirm, send URA Update Confirm, , others)	
Ciphering related information				
>Ciphering status for each CN domain	MP	<1 to maxCNDo mains>		
>>CN domain identity	MP		CN domain identity 10.3.1.1	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>Ciphering status	MP		Enumerated(Not started, Started)	
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.
>Latest configured CN domain	MP		CN domain identity 10.3.1.1	Value contained in the variable of the same name.
>Calculation time for ciphering related information	CV- <i>Ciphering</i>			Time when the ciphering information of the message were calculated, relative to a cell of the target RNC
>>Cell Identity	MP		Cell Identity 10.3.2.2	Identity of one of the cells under the target RNC and included in the active set of the current call
>>SFN	MP		Integer(0..4095)	
>COUNT-C list	CV- <i>Ciphering</i>	1 to <maxCNdo mains>		COUNT-C values for radio bearers using transparent mode RLC
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>COUNT-C	MP		Bit string(32)	
>Ciphering info per radio bearer	OP	1 to <maxRB>		For signalling radio bearers this IE is mandatory.
>>RB identity	MP		RB identity 10.3.4.16	
>>Downlink HFN	MP		Bit string(20..25)	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
>>Downlink SN	CV- <i>SRB1</i>		Bit String(7)	VT(US) of RLC UM
>>Uplink HFN	MP		Bit string(20..25)	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
Integrity protection related information				
>Integrity protection status	MP		Enumerated(Not started, Started)	
>Signalling radio bearer specific integrity protection information	CV- <i>IP</i>	4 to <maxSRBs etup>		
>>Uplink RRC HFN	MP		Bit string (28)	
>>Downlink RRC HFN	MP		Bit string (28)	
>>Uplink RRC Message sequence number	MP		Integer (0..15)	
>>Downlink RRC Message sequence number	MP		Integer (0..15)	
>Implementation specific parameters	OP		Bit string (1..512)	
RRC IEs				
UE Information elements				
>U-RNTI	MP		U-RNTI 10.3.3.47	
>C-RNTI	OP		C-RNTI 10.3.3.8	
>UE radio access Capability	MP		UE radio access capability 10.3.3.42	
>UE radio access capability	OP		UE radio	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
extension			access capability extension 10.3.3.42a	
>Last known UE position	OP			
>>SFN	MP		Integer (0..4095)	Time when position was estimated
>>>Cell ID	MP		Cell identity; 10.3.2.2	Indicates the cell, the SFN is valid for.
>>>CHOICE <i>Position estimate</i>	MP			
>>>>Ellipsoid Point			Ellipsoid Point; 10.3.8.4a	
>>>>Ellipsoid point with uncertainty circle			Ellipsoid point with uncertainty circle 10.3.8.4d	
>>>>Ellipsoid point with uncertainty ellipse			Ellipsoid point with uncertainty ellipse 10.3.8.4e	
>>>>Ellipsoid point with altitude			Ellipsoid point with altitude 10.3.8.4b	
>>>>Ellipsoid point with altitude and uncertainty ellipsoid			Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c	
Other Information elements				
>UE system specific capability	OP	1 to <maxSystemCapability>		
>>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	
UTRAN Mobility Information elements				
>URA Identifier	OP		URA identity 10.3.2.6	
CN Information Elements				
>CN common GSM-MAP NAS system information	MP		NAS system information (GSM-MAP) 10.3.1.9	
>CN domain related information	OP	1 to <MaxCNdomains>		CN related information to be provided for each CN domain
>>CN domain identity	MP			
>>>CN domain specific GSM-MAP NAS system info	MP		NAS system information (GSM-MAP) 10.3.1.9	
>>>CN domain specific DRX cycle length coefficient	MP		CN domain specific DRX cycle length coefficient, 10.3.3.6	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
Measurement Related Information elements				
>For each ongoing measurement reporting	OP	1 to <MaxNoOf Meas>		
>>Measurement Identity	MP		Measurement identity 10.3.7.48	
>>Measurement Command	MP		Measurement command 10.3.7.46	
>>Measurement Type	CV-Setup		Measurement type 10.3.7.50	
>>Measurement Reporting Mode	OP		Measurement reporting mode 10.3.7.49	
>>Additional Measurements list	OP		Additional measurements list 10.3.7.1	
>>CHOICE <i>Measurement</i>	OP			
>>>Intra-frequency				
>>>>Intra-frequency cell info	OP		Intra-frequency cell info list 10.3.7.33	
>>>>Intra-frequency measurement quantity	OP		Intra-frequency measurement quantity 10.3.7.38	
>>>>Intra-frequency reporting quantity	OP		Intra-frequency reporting quantity 10.3.7.41	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Intra-frequency measurement reporting criteria			Intra-frequency measurement reporting criteria 10.3.7.39	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Inter-frequency				
>>>>Inter-frequency cell info	OP		Inter-frequency cell info list 10.3.7.13	
>>>>Inter-frequency measurement quantity	OP		Inter-frequency measurement quantity	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			10.3.7.18	
>>>>Inter-frequency reporting quantity	OP		Inter-frequency reporting quantity 10.3.7.21	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Inter-frequency measurement reporting criteria			Inter-frequency measurement reporting criteria 10.3.7.19	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Inter-RAT				
>>>>Inter-RAT cell info	OP		Inter-RAT cell info list 10.3.7.23	
>>>>Inter-RAT measurement quantity	OP		Inter-RAT measurement quantity 10.3.7.29	
>>>>Inter-RAT reporting quantity	OP		Inter-RAT reporting quantity 10.3.7.32	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Inter-RAT measurement reporting criteria			Inter-RAT measurement reporting criteria 10.3.7.30	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Traffic Volume				
>>>>Traffic volume measurement Object	OP		Traffic volume measurement object 10.3.7.70	
>>>>Traffic volume measurement quantity	OP		Traffic volume measurement quantity 10.3.7.71	
>>>>Traffic volume reporting	OP		Traffic	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
quantity			volume reporting quantity 10.3.7.74	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Traffic volume measurement reporting criteria			Traffic volume measurement reporting criteria 10.3.7.72	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Quality				
>>>>Quality measurement Object	OP		Quality measurement object	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Quality measurement reporting criteria			Quality measurement reporting criteria 10.3.7.58	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>UE internal				
>>>>UE internal measurement quantity	OP		UE internal measurement quantity 10.3.7.79	
>>>>UE internal reporting quantity	OP		UE internal reporting quantity 10.3.7.82	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>UE internal measurement reporting criteria			UE internal measurement reporting criteria 10.3.7.80	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>UE positioning				
>>>>LCS reporting quantity	OP		LCS reporting quantity 10.3.7.111	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>LCS reporting criteria			LCS reporting criteria 10.3.7.110	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>>>No reporting				
Radio Bearer Information Elements				
>Predefined configuration status information	OP		Predefined configuration status information 10.3.4.5a	
>Signalling RB information list	MP	1 to <maxSRBs etup>		For each signalling radio bearer
>>Signalling RB information	MP		Signalling RB information to setup 10.3.4.24	
>RAB information list	OP	1 to <maxRABs etup>		Information for each RAB
>>RAB information	MP		RAB information to setup 10.3.4.10	
Transport Channel Information Elements				
Uplink transport channels				
>UL Transport channel information common for all transport channels	OP		UL Transport channel information common for all transport channels 10.3.5.24	
>UL transport channel information list	OP	1 to <MaxTrCH >		
>>UL transport channel information	MP		Added or reconfigured UL TrCH information 10.3.5.2	
>CHOICE <i>mode</i>	OP			
>>FDD				
>>>CPCH set ID	OP		CPCH set ID 10.3.5.5	
>>>Transport channel information for DRAC list	OP	1 to <MaxTrCH >		
>>>>DRAC static information	MP		DRAC static information 10.3.5.7	
>>TDD				(no data)
Downlink transport channels				
>DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6	
>DL transport channel information list	OP	1 to <MaxTrCH >		
>>DL transport channel information	MP		Added or reconfigured	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			DL TrCH information 10.3.5.1	
>Measurement report	OP		MEASUREMENT REPORT 10.2.17	
Other Information elements				
Failure cause	OP		Failure cause 10.3.3.13	Diagnostics information related to an earlier SRNC Relocation request (see NOTE 2 in 14.12.0a)
Protocol error information	CV-ProtErr		Protocol error information 10.3.8.12	

Multi Bound	Explanation
MaxNoOfMeas	Maximum number of active measurements, upper limit 16

Condition	Explanation
<i>Setup</i>	The IE is mandatory present when the IE Measurement command has the value "Setup", otherwise the IE is not needed.
<i>Ciphering</i>	The IE is mandatory present when the IE Ciphering Status has the value "started" and the ciphering counters need not be reinitialised, otherwise the IE is not needed.
<i>IP</i>	The IE is mandatory present when the IE Integrity protection status has the value "started" and the integrity protection counters need not be reinitialised, otherwise the IE is not needed.
<i>ProtErr</i>	This IE is mandatory present if the IE "Protocol error indicator" is included and has the value "TRUE". Otherwise it is not needed.
<i>SRB1</i>	The IE is mandatory present for RB1. Otherwise it is not needed.

CHANGE REQUEST

⌘ **25.331 CR 1672** ⌘ rev **1** ⌘ Current version: **4.5.0** ⌘

For HELP on using this form, see bottom of this page or look at the pop-up text over the ⌘ symbols.

Proposed change affects: UICC apps ME Radio Access Network Core Network

Title:	⌘ SRNS relocation with integrity		
Source:	⌘ Alcatel		
Work item code:	⌘ TEI	Date:	⌘ 09/8/2002
Category:	⌘ A	Release:	⌘ Rel-4
	Use <u>one</u> of the following categories:		Use <u>one</u> of the following releases:
	<i>F</i> (correction)	2	(GSM Phase 2)
	<i>A</i> (corresponds to a correction in an earlier release)	R96	(Release 1996)
	<i>B</i> (addition of feature),	R97	(Release 1997)
	<i>C</i> (functional modification of feature)	R98	(Release 1998)
	<i>D</i> (editorial modification)	R99	(Release 1999)
	Detailed explanations of the above categories can be found in 3GPP TR 21.900.	Rel-4	(Release 4)
		Rel-5	(Release 5)
		Rel-6	(Release 6)

Reason for change:	⌘ With the current standard the IE "integrity check info" is supposed to be calculated by the source SRNC in the case of a SRNS relocation "UE involved". However the source SRNC is not always able to calculate this if the target SRNC uses a message format that the source SRNC does not understand (i.e. Rel 4 message, or a non critical extension that is not known by the source SRNC). Also the target SRNC could choose an integrity protection algorithm that is not implemented by the source SRNC.
Summary of change:	⌘ A spare entry in the RRC IE "Target RNC to Source RNC Transparent Container" which includes the entirely compiled downlink message. An additional optional IE giving the RB Id on which the relocation message will be transmitted to the UE is added to the IE "SRNS RELOCATION INFO". Absence of this IE indicates that the source SRNC expects a formerly defined entry and it will calculate the MAC-I itself (if possible). Presence means that the target RNC should use the new defined entry "DL DCCH message" <u>Impact analysis:</u> The problem resolved is the SRNS relocation with integrity active between two RNCs that use different versions of the protocol. There is no backwards incompatibility problems between two RNCs where one implements the change and the other one doesn't.
Consequences if not approved:	⌘ It is not possible to apply integrity protection in the case of SRNS relocation of the type "UE involved" in case the target and the source RNC do not support the same messages, and though the SRNS relocation is not possible in all cases.

Clauses affected:	⌘ 11.5, 14.12.2, 14.12.4.2							
Other specs	⌘	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="text-align: center;">Y</td> <td style="text-align: center;">N</td> </tr> <tr> <td style="text-align: center;"><input type="checkbox"/></td> <td style="text-align: center;"><input checked="" type="checkbox"/></td> </tr> </table>	Y	N	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Other core specifications	⌘
Y	N							
<input type="checkbox"/>	<input checked="" type="checkbox"/>							

affected:

<input checked="" type="checkbox"/>	Test specifications
<input checked="" type="checkbox"/>	O&M Specifications

Other comments: ☹

How to create CRs using this form:

Comprehensive information and tips about how to create CRs can be found at <http://www.3gpp.org/specs/CR.htm>.

Below is a brief summary:

- 1) Fill out the above form. The symbols above marked ☹ contain pop-up help information about the field that they are closest to.
- 2) Obtain the latest version for the release of the specification to which the change is proposed. Use the MS Word "revision marks" feature (also known as "track changes") when making the changes. All 3GPP specifications can be downloaded from the 3GPP server under <ftp://ftp.3gpp.org/specs/> For the latest version, look for the directory name with the latest date e.g. 2001-03 contains the specifications resulting from the March 2001 TSG meetings.
- 3) With "track changes" disabled, paste the entire CR form (use CTRL-A to select it) into the specification just in front of the clause containing the first piece of changed text. Delete those parts of the specification which are not relevant to the change request.

11.5 RRC information between network nodes

```
Internode-definitions DEFINITIONS AUTOMATIC TAGS ::=
```

```
BEGIN
```

```
IMPORTS
```

```
    HandoverToUTRANCommand,  
    MeasurementReport,  
    PhysicalChannelReconfiguration,  
    RadioBearerReconfiguration,  
    RadioBearerRelease,  
    RadioBearerSetup,  
    RRC-FailureInfo-r3-IEs,  
    TransportChannelReconfiguration  
FROM PDU-definitions
```

```
-- Core Network IEs :  
    CN-DomainIdentity,  
    CN-DomainInformationList,  
    CN-DRX-CycleLengthCoefficient,  
    NAS-SystemInformationGSM-MAP,  
-- UTRAN Mobility IEs :  
    CellIdentity,  
    URA-Identity,  
-- User Equipment IEs :  
    C-RNTI,  
    DL-PhysChCapabilityFDD-v380ext,  
    FailureCauseWithProtErr,  
    RRC-MessageSequenceNumber,  
    STARTList,  
    STARTSingle,  
    START-Value,  
    U-RNTI,  
    UE-RadioAccessCapability,  
    UE-RadioAccessCapability-v370ext,  
    UE-RadioAccessCapability-v380ext,  
    UE-RadioAccessCapability-v3a0ext,  
    UE-RadioAccessCapability-v4xyext,  
-- Radio Bearer IEs :  
    PredefinedConfigStatusList,  
    PredefinedConfigValueTag,  
    RAB-InformationSetupList,  
    RAB-Identity,  
    SRB-InformationSetupList,  
-- Transport Channel IEs :  
    CPCH-SetID,  
    DL-CommonTransChInfo,  
    DL-AddReconfTransChInfoList,  
    DRAC-StaticInformationList,  
    UL-CommonTransChInfo,  
    UL-AddReconfTransChInfoList,  
-- Measurement IEs :  
    MeasurementIdentity,  
    MeasurementReportingMode,  
    MeasurementType,  
    MeasurementType-r4,  
    AdditionalMeasurementID-List,  
    PositionEstimate,  
    UE-Positioning-IPDL-Parameters-TDD-r4-ext,  
-- Other IEs :  
InterRAT-UE-RadioAccessCapabilityList  
FROM InformationElements  
  
    maxCNdomains,  
    maxNoOfMeas,  
  
    maxRB,  
    maxSRBsetup  
FROM Constant-definitions  
;
```

```
-- Part 1: Class definitions similar to what has been defined in 11.1 for RRC messages
```

```

-- Information that is transferred in the same direction and across the same path is
grouped

-- *****
--
-- RRC information, to target RNC
--
-- *****
-- RRC Information to target RNC sent either from source RNC or from another RAT

ToTargetRNC-Container ::= CHOICE {
    interRATHandoverInfo          InterRATHandoverInfoWithInterRATCapabilities-
r3,
    srcnRelocation                SRNC-RelocationInfo-r3,
    extension                      NULL
}

-- *****
--
-- RRC information, target RNC to source RNC
--
-- *****

Target-RNC-ToSourceRNC-Container ::= CHOICE {
    radioBearerSetup              RadioBearerSetup,
    radioBearerReconfiguration    RadioBearerReconfiguration,
    radioBearerRelease            RadioBearerRelease,
    transportChannelReconfiguration TransportChannelReconfiguration,
    physicalChannelReconfiguration PhysicalChannelReconfiguration,
    rrc-FailureInfo              RRC-FailureInfo-r3-IEs,
    dL-DCCHmessage                OCTET STRINGextension NULL
}

-- Part 2: Container definitions, similar to the PDU definitions in 11.2 for RRC
messages
-- In alphabetical order

-- *****
--
-- Handover to UTRAN information
--
-- *****

InterRATHandoverInfoWithInterRATCapabilities-r3 ::= CHOICE {
    r3          SEQUENCE {
        -- IE InterRATHandoverInfoWithInterRATCapabilities-r3-IEs also
        -- includes non critical extensions
        interRATHandoverInfo-r3          InterRATHandoverInfoWithInterRATCapabilities-
r3-IEs,
        v390NonCriticalExtensions        SEQUENCE {
            interRATHandoverInfoWithInterRATCapabilities-v390ext
        }
        InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs,
        -- Reserved for future non critical extension
        nonCriticalExtensions            SEQUENCE {} OPTIONAL
    }
    OPTIONAL
},
    criticalExtensions                  SEQUENCE {}
}

InterRATHandoverInfoWithInterRATCapabilities-r3-IEs ::= SEQUENCE {
    -- The order of the IEs may not reflect the tabular format
    -- but has been chosen to simplify the handling of the information in the BSC
    -- Other IEs
    ue-RATSpecificCapability            InterRAT-UE-RadioAccessCapabilityList
    OPTIONAL,
    -- interRATHandoverInfo, Octet string is used to obtain 8 bit length field
prior to
    -- actual information. This makes it possible for BSS to transparently handle
information
    -- received via GSM air interface even when it includes non critical
extensions.
    -- The octet string shall include the InterRATHandoverInfo information
    -- The BSS can re-use the 04.18 length field received from the MS
    interRATHandoverInfo                OCTET STRING (SIZE (0..255))
}

```

```

InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs ::= SEQUENCE {
  -- User equipment IES
  failureCauseWithProtErr          FailureCauseWithProtErr
  OPTIONAL
}

-- *****
--
-- SRNC Relocation information
--
-- *****

SRNC-RelocationInfo-r3 ::= CHOICE {
  r3
    SRNC-RelocationInfo-r3 SEQUENCE {
      SRNC-RelocationInfo-r3-IEs,
      v380NonCriticalExtensions SEQUENCE {
        SRNC-RelocationInfo-v380ext SRNC-RelocationInfo-v380ext-IEs,
        -- Reserved for future non critical extension
        v390NonCriticalExtensions SEQUENCE {
          SRNC-RelocationInfo-v390ext SRNC-RelocationInfo-v390ext-
          IEs,
          v3a0NonCriticalExtensions SEQUENCE {
            SRNC-RelocationInfo-v3a0ext SRNC-RelocationInfo-
            v3a0ext-IEs,
            v3b0NonCriticalExtensions SEQUENCE {
              SRNC-RelocationInfo-
              v3b0ext-IEs,
              v3c0NonCriticalExtensions SEQUENCE {
                SRNC-
                RelocationInfo-v3c0ext-IEs,
                v4xyNonCriticalExtensions SEQUENCE {
                  SRNC-
                  RelocationInfo-v4xyext-IEs,
                  -- Reserved for future non critical extension
                  nonCriticalExtensions SEQUENCE {}
                }
              }
            }
          }
        }
      }
    }
  OPTIONAL
}

SRNC-RelocationInfo-r3-IEs ::= SEQUENCE {
  -- Non-RRC IES
  stateOfRRC          StateOfRRC,
  stateOfRRC-Procedure StateOfRRC-Procedure,
  -- Ciphering related information IES
  -- If the extension v380 is included use the extension for the ciphering status
  per CN domain
  cipheringStatus          CipheringStatus,
  calculationTimeForCiphering CalculationTimeForCiphering          OPTIONAL,
  cipheringInfoPerRB-List CipheringInfoPerRB-List          OPTIONAL,
  count-C-List            COUNT-C-List          OPTIONAL,
  integrityProtectionStatus IntegrityProtectionStatus,
  srb-SpecificIntegrityProtInfoList,
  implementationSpecificParams ImplementationSpecificParams          OPTIONAL,
  -- User equipment IES
  u-RNTI          U-RNTI,
  c-RNTI          C-RNTI          OPTIONAL,
  ue-RadioAccessCapability UE-RadioAccessCapability,
  ue-Positioning-LastKnownPos UE-Positioning-LastKnownPos          OPTIONAL,
  -- Other IES
  ue-RATSpecificCapability InterRAT-UE-RadioAccessCapabilityList
  OPTIONAL,
  -- UTRAN mobility IES
  ura-Identity          URA-Identity          OPTIONAL,
  -- Core network IES
  cn-CommonGSM-MAP-NAS-SysInfo NAS-SystemInformationGSM-MAP,
  cn-DomainInformationList CN-DomainInformationList          OPTIONAL,
  -- Measurement IES
  ongoingMeasRepList OngoingMeasRepList          OPTIONAL,
  -- Radio bearer IES

```

```

        predefinedConfigStatusList      PredefinedConfigStatusList,
        srb-InformationList              SRB-InformationSetupList,
        rab-InformationList              RAB-InformationSetupList      OPTIONAL,
-- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo          OPTIONAL,
        ul-TransChInfoList              UL-AddReconfTransChInfoList    OPTIONAL,
        modeSpecificInfo                 CHOICE {
            fdd                           SEQUENCE {
                cpch-SetID                CPCH-SetID                    OPTIONAL,
                transChDRAC-Info          DRAC-StaticInformationList    OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonTransChInfo            DL-CommonTransChInfo          OPTIONAL,
        dl-TransChInfoList              DL-AddReconfTransChInfoList    OPTIONAL,
-- Measurement report
        measurementReport                MeasurementReport              OPTIONAL,
        nonCriticalExtensions            SEQUENCE {
            -- In case of TDD only up-Ipdl-Parameters-TDD is present, otherwise
            -- this IE is absent
            up-Ipdl-Parameters-TDD        UE-Positioning-IPDL-Parameters-TDD-r4-ext  OPTIONAL,
            -- Extension mechanism for non-release4 information
            nonCriticalExtensions          SEQUENCE {}
        }
    }
}

SRNC-RelocationInfo-v380ext-IEs ::= SEQUENCE {
    -- Ciphering related information IEs
    cn-DomainIdentity                    CN-DomainIdentity,
    cipheringStatusList                  CipheringStatusList
}

SRNC-RelocationInfo-v390ext-IEs ::= SEQUENCE {
    cn-DomainInformationList-v390ext     CN-DomainInformationList-v390ext
OPTIONAL,
    ue-RadioAccessCapability-v370ext     UE-RadioAccessCapability-v370ext
OPTIONAL,
    ue-RadioAccessCapability-v380ext     UE-RadioAccessCapability-v380ext
OPTIONAL,
    dl-PhysChCapabilityFDD-v380ext       DL-PhysChCapabilityFDD-v380ext,
    failureCauseWithProtErr              FailureCauseWithProtErr
OPTIONAL
}

SRNC-RelocationInfo-v3a0ext-IEs ::= SEQUENCE {
    -- cn-domain identity for IE startValueForCiphering-v3a0ext is specified
    -- in subsequent extension (SRNC-RelocationInfo-v3b0ext-IEs)
    startValueForCiphering-v3a0ext       START-Value,
    cipheringInfoForSRB1-v3a0ext         CipheringInfoForSRB1-v3a0ext,
    ue-RadioAccessCapability-v3a0ext     UE-RadioAccessCapability-v3a0ext
OPTIONAL
}

SRNC-RelocationInfo-v3b0ext-IEs ::= SEQUENCE {
    -- cn-domain identity for IE startValueForCiphering-v3a0ext included in
previous extension
    cn-DomainIdentity                    CN-DomainIdentity,
    -- the remaining start values are contained in IE startValueForCiphering-
v3b0ext
    startValueForCiphering-v3b0ext       STARTList2
OPTIONAL
}

SRNC-RelocationInfo-v3c0ext-IEs ::= SEQUENCE {
    -- RB Identity on which the source SRNC will send the message contained in the
-- IE "TargetRNC-ToSourceRNC-Container". Only included if type is "UE involved"
    rb-Identity                           RB-Identity      OPTIONAL
}

STARTList2 ::=
    SEQUENCE (SIZE (2..maxCNdomains)) OF
    STARTSingle

SRNC-RelocationInfo-v4xyext-IEs ::= SEQUENCE {
    ue-RadioAccessCapability-v4xyext     UE-RadioAccessCapability-v4xyext
}

```

```

CipheringInfoForSRB1-v3a0ext ::= SEQUENCE {
    dl-UM-SN                               BIT STRING (SIZE (7))
}

CipheringStatusList ::=
    SEQUENCE (SIZE (1..maxCNDomains)) OF
    CipheringStatusCNDomain

CipheringStatusCNDomain ::=
    SEQUENCE {
        cn-DomainIdentity                 CN-DomainIdentity,
        cipheringStatus                   CipheringStatus
    }

SRNC-RelocationInfo-r4 ::=
    SEQUENCE {
        -- Non-RRC IEs
        rb-Identity                        RB-Identity                               OPTIONAL,
        stateOfRRC                         StateOfRRC,
        stateOfRRC-Procedure               StateOfRRC-Procedure,
        cipheringStatus                    CipheringStatus,
        calculationTimeForCiphering        CalculationTimeForCiphering             OPTIONAL,
        cipheringInfoPerRB-List            CipheringInfoPerRB-List                OPTIONAL,
        integrityProtectionStatus           IntegrityProtectionStatus,
        srb-SpecificIntegrityProtInfoList  SRB-SpecificIntegrityProtInfoList,
        implementationSpecificParams        ImplementationSpecificParams          OPTIONAL,
        -- User equipment IEs
        u-RNTI                              U-RNTI,
        c-RNTI                              C-RNTI                               OPTIONAL,
        ue-RadioAccessCapability            UE-RadioAccessCapability,
        ue-Positioning-LastKnownPos         UE-Positioning-LastKnownPos           OPTIONAL,
        -- Other IEs
        ue-RATSpecificCapability            InterRAT-UE-RadioAccessCapabilityList
        OPTIONAL,
        -- UTRAN mobility IEs
        ura-Identity                        URA-Identity                               OPTIONAL,
        -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfoList  NAS-SystemInformationGSM-MAP,
        cn-DomainInformationList            CN-DomainInformationList                OPTIONAL,
        -- Measurement IEs
        ongoingMeasRepList                  OngoingMeasRepList-r4                   OPTIONAL,
        -- Radio bearer IEs
        predefinedConfigStatusList          PredefinedConfigStatusList,
        srb-InformationList                  SRB-InformationSetupList,
        rab-InformationList                  RAB-InformationSetupList                OPTIONAL,
        -- Transport channel IEs
        ul-CommonTransChInfo                UL-CommonTransChInfo                     OPTIONAL,
        ul-TransChInfoList                  UL-AddReconfTransChInfoList             OPTIONAL,
        modeSpecificInfo                    CHOICE {
            fdd                               SEQUENCE {
                cpch-SetID                     CPCH-SetID                               OPTIONAL,
                transChDRAC-Info                DRAC-StaticInformationList              OPTIONAL
            },
            tdd                               NULL
        },
        dl-CommonTransChInfo                DL-CommonTransChInfo                     OPTIONAL,
        dl-TransChInfoList                  DL-AddReconfTransChInfoList             OPTIONAL,
        -- Measurement report
        measurementReport                    MeasurementReport                          OPTIONAL,
        nonCriticalExtensions                SEQUENCE {
            -- In case of TDD only up-IPDL-Parameters-TDD is present, otherwise
            -- this IE is absent
            up-IPDL-Parameters-TDD            UE-Positioning-IPDL-Parameters-TDD-r4-ext  OPTIONAL,
            -- Extension mechanism for non-release4 information
            nonCriticalExtensions              SEQUENCE {}                                OPTIONAL
        }
    }

-- IE definitions

CalculationTimeForCiphering ::=
    SEQUENCE {
        cell-Id                             CellIdentity,
        sfn                                   INTEGER (0..4095)
    }

CipheringInfoPerRB ::=
    SEQUENCE {
        dl-HFN                               BIT STRING (SIZE (20..25)),
        ul-HFN                               BIT STRING (SIZE (20..25))
    }

```



```

-- TABULAR: CipheringInfoPerRB-List, multiplicity value numberOfRadioBearers
-- has been replaced with maxRB.
CipheringInfoPerRB-List ::= SEQUENCE (SIZE (1..maxRB)) OF
                             CipheringInfoPerRB

CipheringStatus ::= ENUMERATED {
                       started, notStarted }

CN-DomainInformation-v390ext ::= SEQUENCE {
    cn-DRX-CycleLengthCoeff CN-DRX-CycleLengthCoefficient
}

CN-DomainInformationList-v390ext ::= SEQUENCE (SIZE (1..maxCNdomains)) OF
    CN-DomainInformation-v390ext

COUNT-C-List ::= SEQUENCE (SIZE (1..maxCNdomains)) OF
    COUNT-CSingle

COUNT-CSingle ::= SEQUENCE {
    cn-DomainIdentity CN-DomainIdentity,
    count-C BIT STRING (SIZE (32))
}

ImplementationSpecificParams ::= BIT STRING (SIZE (1..512))

IntegrityProtectionStatus ::= ENUMERATED {
    started, notStarted }

MeasurementCommandWithType ::= CHOICE {
    setup MeasurementType,
    modify NULL,
    release NULL
}

MeasurementCommandWithType-r4 ::= CHOICE {
    setup MeasurementType-r4,
    modify NULL,
    release NULL
}

OngoingMeasRep ::= SEQUENCE {
    measurementIdentity MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType
    measurementCommandWithType MeasurementCommandWithType,
    measurementReportingMode MeasurementReportingMode OPTIONAL,
    additionalMeasurementID-List AdditionalMeasurementID-List OPTIONAL
}

OngoingMeasRep-r4 ::= SEQUENCE {
    measurementIdentity MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType-r4.
    measurementCommandWithType-r4 MeasurementCommandWithType-r4,
    measurementReportingMode MeasurementReportingMode OPTIONAL,
    additionalMeasurementID-List AdditionalMeasurementID-List OPTIONAL
}

OngoingMeasRepList ::= SEQUENCE (SIZE (1..maxNoOfMeas)) OF
    OngoingMeasRep

OngoingMeasRepList-r4 ::= SEQUENCE (SIZE (1..maxNoOfMeas)) OF
    OngoingMeasRep-r4

SRB-SpecificIntegrityProtInfo ::= SEQUENCE {
    ul-RRC-HFN BIT STRING (SIZE (28)),
    dl-RRC-HFN BIT STRING (SIZE (28)),
    ul-RRC-SequenceNumber RRC-MessageSequenceNumber,
    dl-RRC-SequenceNumber RRC-MessageSequenceNumber
}

SRB-SpecificIntegrityProtInfoList ::= SEQUENCE (SIZE (4..maxSRBsetup)) OF
    SRB-SpecificIntegrityProtInfo

StateOfRRC ::= ENUMERATED {

```

```

cell-DCH, cell-FACH,
cell-PCH, ura-PCH }

StateOfRRC-Procedure ::=          ENUMERATED {
    awaitNoRRC-Message,
    awaitRRC-ConnectionRe-establishmentComplete,
    awaitRB-SetupComplete,
    awaitRB-ReconfigurationComplete,
    awaitTransportCH-ReconfigurationComplete,
    awaitPhysicalCH-ReconfigurationComplete,
    awaitActiveSetUpdateComplete,
    awaitHandoverComplete,
    sendCellUpdateConfirm,
    sendUraUpdateConfirm,
    sendRrcConnectionReestablishment,
    otherStates
}

UE-Positioning-LastKnownPos ::=  SEQUENCE {
    sfn                INTEGER (0..4095),
    cell-id            CellIdentity,
    positionEstimate   PositionEstimate
}

END

```

14.12.2 RRC information, target RNC to source RNC

There are 2 possible cases for RNC relocation:

1. The UE is already under control of target RNC; and
2. The SRNC Relocation with Hard Handover (UE still under control of SRNC), but UE is moving to a location controlled by the target RNC (based on measurement information).

In case 1 the relocation is transparent to the UE and there is no "reverse" direction container. The SRNC just assigns the 'serving' function to the target RNC, which then becomes the Serving RNC.

In case 2 the relocation is initiated by SRNC, which also provides the RRC Initialisation Information to the target RNC. Base on this information, the target RNC prepares the Hard Handover Message ("Physical channel reconfiguration" (subclause 8.2.6), "radio bearer establishment" (subclause 8.2.1), "Radio bearer reconfiguration" (subclause 8.2.2), "Radio bearer release" (subclause 8.2.3) or "Transport channel reconfiguration" (subclause 8.2.4).

In case 2 two possibilities are defined in order to transmit the relocation message from the target RNC to the source RNC which can be chosen by the source RNC by including or not including the IE "RB Id for handover message" in the IE "SRNS Relocation Info".

In case the IE "RB Id for handover message" has been received by the target RNC in the IE "SRNS Relocation Info", the target RNC should choose IE "DL DCCH message" and include the DL DCCH message that should be transmitted transparently to the UE by the source RNC. In that case, the target RNC is integrity protecting the message if applicable.

If the target RNC did not receive the IE "RB Id for handover message" in the IE "SRNS Relocation Info" the target RNC should use another choice. In that case, the source RNC should integrity protect the message before transmitting it to the UE if applicable.

The source RNC then transmits the Handover Message to the UE, which then performs the handover.

In the successful case, the UE transmits an XXX COMPLETE message, using the new configuration, to the target RNC.

In case of failure, the UE transmits an XXX FAILURE, using the old configuration, to the source RNC and the RRC context remains unchanged (has to be confirmed and checked with the SRNS relocation procedure).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE <i>RRC message</i>	MP			At least one spare choice, Criticality: Reject, is needed
>RADIO BEARER SETUP			RADIO BEARER SETUP 10.2.31	
>RADIO BEARER RECONFIGURATION			RADIO BEARER RECONFIGURATION 10.2.25	
>RADIO BEARER RELEASE			RADIO BEARER RELEASE 10.2.28	
>TRANSPORT CHANNEL RECONFIGURATION			TRANSPORT CHANNEL RECONFIGURATION 10.2.51	
>PHYSICAL CHANNEL RECONFIGURATION			PHYSICAL CHANNEL RECONFIGURATION 10.2.20	
>RRC FAILURE INFO			RRC FAILURE INFO 10.2.41 a	
>DL DCCH message			OCTET STRING	

14.12.4.2 SRNS RELOCATION INFO

This RRC message is sent between network nodes when preparing for an SRNS relocation.

With the presence or absence of the IE “RB identity for Hard Handover message” the source RNC indicates to the target SRNC whether the source RNC expects to receive the choice “DL DCCH message” in the IE “RRC information, target RNC to source RNC” in case the SRNS relocation is of type “UE involved”. Furthermore the target RNC uses this information for the calculation of the MAC-I

Direction: source RAT→target RNC

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
Non RRC IEs				
<u>RB identity for Handover message</u>	<u>OP</u>		<u>RB identity 10.3.4.16</u>	Gives the id of the radio bearer on which the source RNC will transmit the RRC message in the case the relocation is of type “UE involved”.
>State of RRC	MP		RRC state indicator, 10.3.3.35a	
>State of RRC procedure	MP		Enumerated (await no RRC message, Complete, await RB Setup Complete,	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			await RB Reconfiguration Complete, await RB Release Complete, await Transport CH Reconfiguration Complete, await Physical CH Reconfiguration Complete, await Active Set Update Complete, await Handover Complete, send Cell Update Confirm, send URA Update Confirm, , others)	
Ciphering related information				
>Ciphering status for each CN domain	MP	<1 to maxCNDo mains>		
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>Ciphering status	MP		Enumerated(Not started, Started)	
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.
>Latest configured CN domain	MP		CN domain identity 10.3.1.1	Value contained in the variable of the same name.
>Calculation time for ciphering related information	CV- <i>Ciphering</i>			Time when the ciphering information of the message were calculated, relative to a cell of the target RNC
>>Cell Identity	MP		Cell Identity 10.3.2.2	Identity of one of the cells under the target RNC and included in the active set of the current call
>>SFN	MP		Integer(0..40 95)	
>COUNT-C list	CV- <i>Ciphering</i>	1 to <maxCNdo mains>		COUNT-C values for radio bearers using transparent mode RLC
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>COUNT-C	MP		Bit string(32)	
>Ciphering info per radio bearer	OP	1 to		For signalling radio bearers

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
		<maxRB>		this IE is mandatory.
>>RB identity	MP		RB identity 10.3.4.16	
>>Downlink HFN	MP		Bit string(20..25)	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
>>Downlink SN	CV-SRB1		Bit String(7)	VT(US) of RLC UM
>>Uplink HFN	MP		Bit string(20..25)	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
Integrity protection related information				
>Integrity protection status	MP		Enumerated(Not started, Started)	
>Signalling radio bearer specific integrity protection information	CV-IP	4 to <maxSRBs etup>		
>>Uplink RRC HFN	MP		Bit string (28)	
>>Downlink RRC HFN	MP		Bit string (28)	
>>Uplink RRC Message sequence number	MP		Integer (0..15)	
>>Downlink RRC Message sequence number	MP		Integer (0..15)	
>Implementation specific parameters	OP		Bit string (1..512)	
RRC IEs				
UE Information elements				
>U-RNTI	MP		U-RNTI 10.3.3.47	
>C-RNTI	OP		C-RNTI 10.3.3.8	
>UE radio access Capability	MP		UE radio access capability 10.3.3.42	
>UE radio access capability extension	OP		UE radio access capability extension 10.3.3.42a	
>Last known UE position	OP			
>>SFN	MP		Integer (0..4095)	Time when position was estimated
>>Cell ID	MP		Cell identity; 10.3.2.2	Indicates the cell, the SFN is valid for.
>>CHOICE <i>Position estimate</i>	MP			
>>>Ellipsoid Point			Ellipsoid Point; 10.3.8.4a	
>>>Ellipsoid point with uncertainty circle			Ellipsoid point with uncertainty circle 10.3.8.4d	
>>>Ellipsoid point with uncertainty ellipse			Ellipsoid point with uncertainty ellipse 10.3.8.4e	
>>>Ellipsoid point with altitude			Ellipsoid point with	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			altitude 10.3.8.4b	
>>>Ellipsoid point with altitude and uncertainty ellipsoid			Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c	
Other Information elements				
>UE system specific capability	OP	1 to <maxSystemCapability>		
>>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	
UTRAN Mobility Information elements				
>URA Identifier	OP		URA identity 10.3.2.6	
CN Information Elements				
>CN common GSM-MAP NAS system information	MP		NAS system information (GSM-MAP) 10.3.1.9	
>CN domain related information	OP	1 to <MaxCNDomains>		CN related information to be provided for each CN domain
>>CN domain identity	MP			
>>CN domain specific GSM-MAP NAS system info	MP		NAS system information (GSM-MAP) 10.3.1.9	
>>CN domain specific DRX cycle length coefficient	MP		CN domain specific DRX cycle length coefficient, 10.3.3.6	
Measurement Related Information elements				
>For each ongoing measurement reporting	OP	1 to <MaxNoOfMeas>		
>>Measurement Identity	MP		Measurement identity 10.3.7.48	
>>Measurement Command	MP		Measurement command 10.3.7.46	
>>Measurement Type	<i>CV-Setup</i>		Measurement type 10.3.7.50	
>>Measurement Reporting Mode	OP		Measurement reporting mode 10.3.7.49	
>>Additional Measurements list	OP		Additional measurements list 10.3.7.1	
>>CHOICE <i>Measurement</i>	OP			
>>>Intra-frequency				

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>>>Intra-frequency cell info	OP		Intra-frequency cell info list 10.3.7.33	
>>>>Intra-frequency measurement quantity	OP		Intra-frequency measurement quantity 10.3.7.38	
>>>>Intra-frequency reporting quantity	OP		Intra-frequency reporting quantity 10.3.7.41	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Intra-frequency measurement reporting criteria			Intra-frequency measurement reporting criteria 10.3.7.39	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Inter-frequency				
>>>>Inter-frequency cell info	OP		Inter-frequency cell info list 10.3.7.13	
>>>>Inter-frequency measurement quantity	OP		Inter-frequency measurement quantity 10.3.7.18	
>>>>Inter-frequency reporting quantity	OP		Inter-frequency reporting quantity 10.3.7.21	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Inter-frequency measurement reporting criteria			Inter-frequency measurement reporting criteria 10.3.7.19	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>>>No reporting			NULL	
>>>Inter-RAT				
>>>>Inter-RAT cell info	OP		Inter-RAT cell info list 10.3.7.23	
>>>>Inter-RAT measurement quantity	OP		Inter-RAT measurement quantity 10.3.7.29	
>>>>Inter-RAT reporting quantity	OP		Inter-RAT reporting quantity 10.3.7.32	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Inter-RAT measurement reporting criteria			Inter-RAT measurement reporting criteria 10.3.7.30	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Traffic Volume				
>>>>Traffic volume measurement Object	OP		Traffic volume measurement object 10.3.7.70	
>>>>Traffic volume measurement quantity	OP		Traffic volume measurement quantity 10.3.7.71	
>>>>Traffic volume reporting quantity	OP		Traffic volume reporting quantity 10.3.7.74	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Traffic volume measurement reporting criteria			Traffic volume measurement reporting criteria 10.3.7.72	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Quality				
>>>>Quality measurement Object	OP		Quality measurement object	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Quality measurement			Quality	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
reporting criteria			measurement reporting criteria 10.3.7.58	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting			NULL	
>>>UE internal				
>>>>UE internal measurement quantity	OP		UE internal measurement quantity 10.3.7.79	
>>>>UE internal reporting quantity	OP		UE internal reporting quantity 10.3.7.82	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>UE internal measurement reporting criteria			UE internal measurement reporting criteria 10.3.7.80	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting			NULL	
>>>UE positioning				
>>>>LCS reporting quantity	OP		LCS reporting quantity 10.3.7.111	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>LCS reporting criteria			LCS reporting criteria 10.3.7.110	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting				
Radio Bearer Information Elements				
>Predefined configuration status information	OP		Predefined configuration status information 10.3.4.5a	
>Signalling RB information list	MP	1 to <maxSRBs etup>		For each signalling radio bearer
>>Signalling RB information	MP		Signalling RB information to setup 10.3.4.24	
>RAB information list	OP	1 to <maxRABs etup>		Information for each RAB
>>RAB information	MP		RAB information	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			to setup 10.3.4.10	
Transport Channel Information Elements				
Uplink transport channels				
>UL Transport channel information common for all transport channels	OP		UL Transport channel information common for all transport channels 10.3.5.24	
>UL transport channel information list	OP	1 to <MaxTrCH >		
>>UL transport channel information	MP		Added or reconfigured UL TrCH information 10.3.5.2	
>CHOICE mode	OP			
>>FDD				
>>>CPCH set ID	OP		CPCH set ID 10.3.5.5	
>>>Transport channel information for DRAC list	OP	1 to <MaxTrCH >		
>>>>DRAC static information	MP		DRAC static information 10.3.5.7	
>>TDD				(no data)
Downlink transport channels				
>DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6	
>DL transport channel information list	OP	1 to <MaxTrCH >		
>>DL transport channel information	MP		Added or reconfigured DL TrCH information 10.3.5.1	
>Measurement report	OP		MEASUREMENT REPORT 10.2.17	
Other Information elements				
Failure cause	OP		Failure cause 10.3.3.13	Diagnostics information related to an earlier SRNC Relocation request (see NOTE 2 in 14.12.0a)
Protocol error information	CV-ProtErr		Protocol error information 10.3.8.12	

Multi Bound	Explanation
MaxNoOfMeas	Maximum number of active measurements, upper limit 16

Condition	Explanation
<i>Setup</i>	The IE is mandatory present when the IE Measurement command has the value "Setup", otherwise the IE is not needed.
<i>Ciphering</i>	The IE is mandatory present when the IE Ciphering Status has the value "started" and the ciphering counters need not be reinitialised, otherwise the IE is not needed.
<i>IP</i>	The IE is mandatory present when the IE Integrity protection status has the value "started" and the integrity protection counters need not be reinitialised, otherwise the IE is not needed.
<i>ProtErr</i>	This IE is mandatory present if the IE "Protocol error indicator" is included and has the value "TRUE". Otherwise it is not needed.
<i>SRB1</i>	The IE is mandatory present for RB1. Otherwise it is not needed.

CHANGE REQUEST

⌘ **25.331 CR 1673** ⌘ rev **1** ⌘ Current version: **5.1.0** ⌘

For HELP on using this form, see bottom of this page or look at the pop-up text over the ⌘ symbols.

Proposed change affects: UICC apps ME Radio Access Network Core Network

Title:	⌘ SRNS relocation with integrity		
Source:	⌘ Alcatel		
Work item code:	⌘ TEI	Date:	⌘ 09/8/2002
Category:	⌘ A	Release:	⌘ Rel-5
	Use <u>one</u> of the following categories:		Use <u>one</u> of the following releases:
	F (correction)	R96	2 (GSM Phase 2)
	A (corresponds to a correction in an earlier release)	R97	(Release 1996)
	B (addition of feature),	R98	(Release 1997)
	C (functional modification of feature)	R99	(Release 1998)
	D (editorial modification)	Rel-4	(Release 1999)
	Detailed explanations of the above categories can be found in 3GPP TR 21.900.	Rel-5	(Release 4)
		Rel-6	(Release 5)
			(Release 6)

Reason for change:	⌘ With the current standard the IE "integrity check info" is supposed to be calculated by the source SRNC in the case of a SRNS relocation "UE involved". However the source SRNC is not always able to calculate this if the target SRNC uses a message format that the source SRNC does not understand (i.e. Rel 4 message, or a non critical extension that is not known by the source SRNC). Also the target SRNC could choose an integrity protection algorithm that is not implemented by the source SRNC.
Summary of change:	⌘ A spare entry in the RRC IE "Target RNC to Source RNC Transparent Container" which includes the entirely compiled downlink message. An additional optional IE giving the RB Id on which the relocation message will be transmitted to the UE is added to the IE "SRNS RELOCATION INFO". Absence of this IE indicates that the source SRNC expects a formerly defined entry and it will calculate the MAC-I itself (if possible). Presence means that the target RNC should use the new defined entry "DL DCCH message" <u>Impact analysis:</u> The problem resolved is the SRNS relocation with integrity active between two RNCs that use different versions of the protocol. There is no backwards incompatibility problems between two RNCs where one implements the change and the other one doesn't.
Consequences if not approved:	⌘ It is not possible to apply integrity protection in the case of SRNS relocation of the type "UE involved" in case the target and the source RNC do not support the same messages, and though the SRNS relocation is not possible in all cases.

Clauses affected:	⌘ 11.5, 14.12.2, 14.12.4.2							
Other specs	⌘	<table border="1" style="display: inline-table; border-collapse: collapse;"> <tr> <td style="text-align: center;">Y</td> <td style="text-align: center;">N</td> </tr> <tr> <td style="text-align: center;"><input type="checkbox"/></td> <td style="text-align: center;"><input checked="" type="checkbox"/></td> </tr> </table>	Y	N	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Other core specifications	⌘
Y	N							
<input type="checkbox"/>	<input checked="" type="checkbox"/>							

affected:

<input checked="" type="checkbox"/>	Test specifications
<input checked="" type="checkbox"/>	O&M Specifications

Other comments: ☹

How to create CRs using this form:

Comprehensive information and tips about how to create CRs can be found at <http://www.3gpp.org/specs/CR.htm>.

Below is a brief summary:

- 1) Fill out the above form. The symbols above marked ☹ contain pop-up help information about the field that they are closest to.
- 2) Obtain the latest version for the release of the specification to which the change is proposed. Use the MS Word "revision marks" feature (also known as "track changes") when making the changes. All 3GPP specifications can be downloaded from the 3GPP server under <ftp://ftp.3gpp.org/specs/> For the latest version, look for the directory name with the latest date e.g. 2001-03 contains the specifications resulting from the March 2001 TSG meetings.
- 3) With "track changes" disabled, paste the entire CR form (use CTRL-A to select it) into the specification just in front of the clause containing the first piece of changed text. Delete those parts of the specification which are not relevant to the change request.

11.5 RRC information between network nodes

```
Internode-definitions DEFINITIONS AUTOMATIC TAGS ::=
```

```
BEGIN
```

```
IMPORTS
```

```
    HandoverToUTRANCommand,  
    MeasurementReport,  
    PhysicalChannelReconfiguration,  
    RadioBearerReconfiguration,  
    RadioBearerRelease,  
    RadioBearerSetup,  
    RRC-FailureInfo-r3-IEs,  
    TransportChannelReconfiguration  
FROM PDU-definitions  
  
-- Core Network IEs :  
    CN-DomainIdentity,  
    CN-DomainInformationList,  
    CN-DRX-CycleLengthCoefficient,  
    NAS-SystemInformationGSM-MAP,  
-- UTRAN Mobility IEs :  
    CellIdentity,  
    URA-Identity,  
-- User Equipment IEs :  
    C-RNTI,  
    DL-PhysChCapabilityFDD-v380ext,  
    FailureCauseWithProtErr,  
    RRC-MessageSequenceNumber,  
    STARTList,  
    STARTSingle,  
    START-Value,  
    U-RNTI,  
    UE-RadioAccessCapability,  
    UE-RadioAccessCapability-v370ext,  
    UE-RadioAccessCapability-v380ext,  
    UE-RadioAccessCapability-v3a0ext,  
    UE-RadioAccessCapability-v4xyext,  
-- Radio Bearer IEs :  
    PredefinedConfigStatusList,  
    PredefinedConfigValueTag,  
    RAB-InformationSetupList,  
    RAB-Identity,  
    RB-Identity,  
    SRB-InformationSetupList,  
-- Transport Channel IEs :  
    CPCH-SetID,  
    DL-CommonTransChInfo,  
    DL-AddReconfTransChInfoList,  
    DRAC-StaticInformationList,  
    UL-CommonTransChInfo,  
    UL-AddReconfTransChInfoList,  
-- Measurement IEs :  
    MeasurementIdentity,  
    MeasurementReportingMode,  
    MeasurementType,  
    MeasurementType-r4,  
    AdditionalMeasurementID-List,  
    PositionEstimate,  
    UE-Positioning-IPDL-Parameters-TDD-r4-ext,  
-- Other IEs :  
InterRAT-UE-RadioAccessCapabilityList  
FROM InformationElements  
  
    maxCNdomains,  
    maxNoOfMeas,  
  
    maxRB,  
    maxRBallRABs,  
    maxRFC3095-CID,  
    maxSRBsetup  
FROM Constant-definitions  
;
```

```

-- Part 1: Class definitions similar to what has been defined in 11.1 for RRC messages
-- Information that is transferred in the same direction and across the same path is
grouped

-- *****
--
-- RRC information, to target RNC
--
-- *****
-- RRC Information to target RNC sent either from source RNC or from another RAT

ToTargetRNC-Container ::= CHOICE {
    interRATHandoverInfo          InterRATHandoverInfoWithInterRATCapabilities-
r3,
    srncRelocation                SRNC-RelocationInfo-r3,
    rfc3095-ContextInfo          RFC3095-ContextInfo-r5,
    extension                     NULL
}

-- *****
--
-- RRC information, target RNC to source RNC
--
-- *****

Target-RNC-ToSourceRNC-Container ::= CHOICE {
    radioBearerSetup              RadioBearerSetup,
    radioBearerReconfiguration    RadioBearerReconfiguration,
    radioBearerRelease            RadioBearerRelease,
    transportChannelReconfiguration TransportChannelReconfiguration,
    physicalChannelReconfiguration PhysicalChannelReconfiguration,
    rrc-FailureInfo              RRC-FailureInfo-r3-IEs,
    dL-DCCHmessage               OCTET STRINGextension-----NULL
}

-- Part 2: Container definitions, similar to the PDU definitions in 11.2 for RRC
messages
-- In alphabetical order

-- *****
--
-- Handover to UTRAN information
--
-- *****

InterRATHandoverInfoWithInterRATCapabilities-r3 ::= CHOICE {
    r3                            SEQUENCE {
        -- IE InterRATHandoverInfoWithInterRATCapabilities-r3-IEs also
        -- includes non critical extensions
        interRATHandoverInfo-r3    InterRATHandoverInfoWithInterRATCapabilities-
r3-IEs,
        v390NonCriticalExtensions SEQUENCE {
            interRATHandoverInfoWithInterRATCapabilities-v390ext
InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs,
            -- Reserved for future non critical extension
            nonCriticalExtensions SEQUENCE {} OPTIONAL
        }
    },
    criticalExtensions            SEQUENCE {}
}

InterRATHandoverInfoWithInterRATCapabilities-r3-IEs ::= SEQUENCE {
    -- The order of the IEs may not reflect the tabular format
    -- but has been chosen to simplify the handling of the information in the BSC
    -- Other IEs
    ue-RATSpecificCapability      InterRAT-UE-RadioAccessCapabilityList
OPTIONAL,
    -- interRATHandoverInfo, Octet string is used to obtain 8 bit length field
prior to
    -- actual information. This makes it possible for BSS to transparently handle
information
    -- received via GSM air interface even when it includes non critical
extensions.
    -- The octet string shall include the InterRATHandoverInfo information

```

```

-- The BSS can re-use the 04.18 length field received from the MS
interRATHandoverInfo          OCTET STRING (SIZE (0..255))
}

InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs ::= SEQUENCE {
-- User equipment IES
failureCauseWithProtErr      FailureCauseWithProtErr
OPTIONAL
}

-- *****
--
-- RFC3095 context, source RNC to target RNC
--
-- *****

RFC3095-ContextInfo-r5 ::= CHOICE {
r5          SEQUENCE {
rfc3095-ContextInfoList-r5    RFC3095-ContextInfoList-r5,
-- Reserved for future non critical extension
nonCriticalExtensions         SEQUENCE {} OPTIONAL
},
criticalExtensions            SEQUENCE {}
}

RFC3095-ContextInfoList-r5 ::= SEQUENCE (SIZE (1..maxRBallRABs)) OF
RFC3095-ContextInfo

-- *****
--
-- SRNC Relocation information
--
-- *****

SRNC-RelocationInfo-r3 ::= CHOICE {
r3          SEQUENCE {
srnc-RelocationInfo-r3       SRNC-RelocationInfo-r3-IEs,
v380NonCriticalExtensions    SEQUENCE {
srnc-RelocationInfo-v380ext  SRNC-RelocationInfo-v380ext-IEs,
-- Reserved for future non critical extension
v390NonCriticalExtensions    SEQUENCE {
srnc-RelocationInfo-v390ext  SRNC-RelocationInfo-v390ext-
IEs,
v3a0NonCriticalExtensions    SEQUENCE {
srnc-RelocationInfo-v3a0ext  SRNC-RelocationInfo-
v3a0ext-IEs,
v3b0NonCriticalExtensions    SEQUENCE {
srnc-RelocationInfo-v3b0ext  SRNC-RelocationInfo-
v3b0ext-IEs,
v3c0NonCriticalExtensions    SEQUENCE {
srnc-RelocationInfo-v3c0ext  SRNC-
RelocationInfo-v3c0ext-IEs,
v4xyNonCriticalExtensions    SEQUENCE {
srnc-RelocationInfo-v4xyext  SRNC-
RelocationInfo-v4xyext-IEs,
-- Reserved for future non critical extension
nonCriticalExtensions        SEQUENCE {}
OPTIONAL
}
OPTIONAL
}
OPTIONAL
}
OPTIONAL
},
criticalExtensions            SEQUENCE {}
}

SRNC-RelocationInfo-r3-IEs ::= SEQUENCE {
-- Non-RRC IES
stateOfRRC                    StateOfRRC,
stateOfRRC-Procedure          StateOfRRC-Procedure,
-- Ciphering related information IES
-- If the extension v380 is included use the extension for the ciphering status
per CN domain
cipheringStatus                CipheringStatus,

```



```

        calculationTimeForCiphering      CalculationTimeForCiphering      OPTIONAL,
        cipheringInfoPerRB-List          CipheringInfoPerRB-List          OPTIONAL,
        count-C-List                      COUNT-C-List                      OPTIONAL,
        integrityProtectionStatus         IntegrityProtectionStatus,
        srb-SpecificIntegrityProtInfoList SRB-SpecificIntegrityProtInfoList,
        implementationSpecificParams      ImplementationSpecificParams      OPTIONAL,
-- User equipment IEs
    u-RNTI                                U-RNTI,
    c-RNTI                                C-RNTI                              OPTIONAL,
    ue-RadioAccessCapability             UE-RadioAccessCapability,
    ue-Positioning-LastKnownPos         UE-Positioning-LastKnownPos        OPTIONAL,
-- Other IEs
    ue-RATSpecificCapability             InterRAT-UE-RadioAccessCapabilityList
OPTIONAL,
-- UTRAN mobility IEs
    ura-Identity                         URA-Identity                        OPTIONAL,
-- Core network IEs
    cn-CommonGSM-MAP-NAS-SysInfoList    NAS-SystemInformationGSM-MAP,
    cn-DomainInformationList            CN-DomainInformationList            OPTIONAL,
-- Measurement IEs
    ongoingMeasRepList                  OngoingMeasRepList                  OPTIONAL,
-- Radio bearer IEs
    predefinedConfigStatusList          PredefinedConfigStatusList,
    srb-InformationList                  SRB-InformationSetupList,
    rab-InformationList                  RAB-InformationSetupList            OPTIONAL,
-- Transport channel IEs
    ul-CommonTransChInfo                UL-CommonTransChInfo                OPTIONAL,
    ul-TransChInfoList                  UL-AddReconfTransChInfoList        OPTIONAL,
    modeSpecificInfo                     CHOICE {
        fdd                               SEQUENCE {
                cpch-SetID                CPCH-SetID                          OPTIONAL,
                transChDRAC-Info          DRAC-StaticInformationList          OPTIONAL
            },
        tdd                               NULL
    },
    dl-CommonTransChInfo                DL-CommonTransChInfo                OPTIONAL,
    dl-TransChInfoList                  DL-AddReconfTransChInfoList        OPTIONAL,
-- Measurement report
    measurementReport                   MeasurementReport                    OPTIONAL,
    nonCriticalExtensions                SEQUENCE {
        -- In case of TDD only up-IPDL-Parameters-TDD is present, otherwise
        -- this IE is absent
        up-IPDL-Parameters-TDD           UE-Positioning-IPDL-Parameters-TDD-r4-ext OPTIONAL,
        -- Extension mechanism for non-release4 information
        nonCriticalExtensions             SEQUENCE {}                          OPTIONAL
    }
}
}

SRNC-RelocationInfo-v380ext-IEs ::= SEQUENCE {
-- Ciphering related information IEs
    cn-DomainIdentity                    CN-DomainIdentity,
    cipheringStatusList                  CipheringStatusList
}

SRNC-RelocationInfo-v390ext-IEs ::= SEQUENCE {
    cn-DomainInformationList-v390ext     CN-DomainInformationList-v390ext
OPTIONAL,
    ue-RadioAccessCapability-v370ext     UE-RadioAccessCapability-v370ext
OPTIONAL,
    ue-RadioAccessCapability-v380ext     UE-RadioAccessCapability-v380ext
OPTIONAL,
    dl-PhysChCapabilityFDD-v380ext       DL-PhysChCapabilityFDD-v380ext,
    failureCauseWithProtErr              FailureCauseWithProtErr
OPTIONAL
}

SRNC-RelocationInfo-v3a0ext-IEs ::= SEQUENCE {
-- cn-domain identity for IE startValueForCiphering-v3a0ext is specified
-- in subsequent extension (SRNC-RelocationInfo-v3b0ext-IEs)
    startValueForCiphering-v3a0ext       START-Value,
    cipheringInfoForSRB1-v3a0ext         CipheringInfoForSRB1-v3a0ext,
    ue-RadioAccessCapability-v3a0ext     UE-RadioAccessCapability-v3a0ext
OPTIONAL
}

SRNC-RelocationInfo-v3b0ext-IEs ::= SEQUENCE {

```

```

-- cn-domain identity for IE startValueForCipherng-v3a0ext included in
previous extension
cn-DomainIdentity          CN-DomainIdentity,
-- the remaining start values are contained in IE startValueForCipherng-
v3b0ext
startValueForCipherng-v3b0ext  STARTList2
OPTIONAL
}
SRNC-RelocationInfo-v3c0ext-IEs ::= SEQUENCE {
-- RB Identity on which the source SRNC will send the message contained in the
-- IE "TargetRNC-ToSourceRNC-Container". Only included if type is "UE involved"
rb-Identity          RB-Identity          OPTIONAL
}
STARTList2 ::=
SEQUENCE (SIZE (2..maxCNdomains)) OF
STARTSingle

SRNC-RelocationInfo-v4xyext-IEs ::= SEQUENCE {
ue-RadioAccessCapability-v4xyext  UE-RadioAccessCapability-v4xyext
}

CipherngInfoForSRB1-v3a0ext ::= SEQUENCE {
dl-UM-SN          BIT STRING (SIZE (7))
}

CipherngStatusList ::=
SEQUENCE (SIZE (1..maxCNdomains)) OF
CipherngStatusCNdomain

CipherngStatusCNdomain ::=
SEQUENCE {
cn-DomainIdentity  CN-DomainIdentity,
cipherngStatus    CipherngStatus
}

SRNC-RelocationInfo-r4 ::=
SEQUENCE {
-- Non-RRC IEs
-- RB Identity on which the source SRNC will send the message contained in the
-- IE "TargetRNC-ToSourceRNC-Container". Only included if type is "UE involved"
rb-Identity          RB-Identity          OPTIONAL,
stateOfRRC          StateOfRRC,
stateOfRRC-Procedure  StateOfRRC-Procedure,
cipherngStatus      CipherngStatus,
calculationTimeForCipherng  CalculationTimeForCipherng  OPTIONAL,
cipherngInfoPerRB-List  CipherngInfoPerRB-List  OPTIONAL,
integrityProtectionStatus  IntegrityProtectionStatus,
srb-SpecificIntegrityProtInfoList  SRB-SpecificIntegrityProtInfoList,
implementationSpecificParams  ImplementationSpecificParams  OPTIONAL,
-- User equipment IEs
u-RNTI          U-RNTI,
c-RNTI          C-RNTI          OPTIONAL,
ue-RadioAccessCapability  UE-RadioAccessCapability,
ue-Positioning-LastKnownPos  UE-Positioning-LastKnownPos  OPTIONAL,
-- Other IEs
ue-RATSpecificCapability  InterRAT-UE-RadioAccessCapabilityList
OPTIONAL,
-- UTRAN mobility IEs
ura-Identity          URA-Identity          OPTIONAL,
-- Core network IEs
cn-CommonGSM-MAP-NAS-SysInfo  NAS-SystemInformationGSM-MAP,
cn-DomainInformationList  CN-DomainInformationList  OPTIONAL,
-- Measurement IEs
ongoingMeasRepList  OngoingMeasRepList-r4  OPTIONAL,
-- Radio bearer IEs
predefinedConfigStatusList  PredefinedConfigStatusList,
srb-InformationList  SRB-InformationSetupList,
rab-InformationList  RAB-InformationSetupList  OPTIONAL,
-- Transport channel IEs
ul-CommonTransChInfo  UL-CommonTransChInfo  OPTIONAL,
ul-TransChInfoList  UL-AddReconfTransChInfoList  OPTIONAL,
modeSpecificInfo  CHOICE {
fdd          SEQUENCE {
cpch-SetID  CPCH-SetID  OPTIONAL,
transChDRAC-Info  DRAC-StaticInformationList  OPTIONAL
},
tdd          NULL
},
dl-CommonTransChInfo  DL-CommonTransChInfo  OPTIONAL,

```



```

    measurementReportingMode      MeasurementReportingMode      OPTIONAL,
    additionalMeasurementID-List   AdditionalMeasurementID-List   OPTIONAL
}

OngoingMeasRep-r4 ::=          SEQUENCE {
    measurementIdentity           MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType-r4.
    measurementCommandWithType   MeasurementCommandWithType-r4,
    measurementReportingMode      MeasurementReportingMode      OPTIONAL,
    additionalMeasurementID-List   AdditionalMeasurementID-List   OPTIONAL
}

OngoingMeasRepList ::=          SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                OngoingMeasRep

OngoingMeasRepList-r4 ::=       SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                OngoingMeasRep-r4

RFC3095-ContextInfo ::=        SEQUENCE {
    rb-Identity                   RB-Identity,
    rfc3095-Context-List          RFC3095-Context-List
}

RFC3095-Context-List ::=       SEQUENCE (SIZE (1..maxRFC3095-CID)) OF SEQUENCE {
    dl-RFC3095-Context            DL-RFC3095-Context            OPTIONAL,
    ul-RFC3095-Context            UL-RFC3095-Context            OPTIONAL
}

SRB-SpecificIntegrityProtInfo ::= SEQUENCE {
    ul-RRC-HFN                    BIT STRING (SIZE (28)),
    dl-RRC-HFN                    BIT STRING (SIZE (28)),
    ul-RRC-SequenceNumber         RRC-MessageSequenceNumber,
    dl-RRC-SequenceNumber         RRC-MessageSequenceNumber
}

SRB-SpecificIntegrityProtInfoList ::= SEQUENCE (SIZE (4..maxSRBsetup)) OF
                                        SRB-SpecificIntegrityProtInfo

StateOfRRC ::=                  ENUMERATED {
                                cell-DCH, cell-FACH,
                                cell-PCH, ura-PCH }

StateOfRRC-Procedure ::=        ENUMERATED {
                                awaitNoRRC-Message,
                                awaitRRC-ConnectionRe-establishmentComplete,
                                awaitRB-SetupComplete,
                                awaitRB-ReconfigurationComplete,
                                awaitTransportCH-ReconfigurationComplete,
                                awaitPhysicalCH-ReconfigurationComplete,
                                awaitActiveSetUpdateComplete,
                                awaitHandoverComplete,
                                sendCellUpdateConfirm,
                                sendUraUpdateConfirm,
                                sendRrcConnectionReestablishment,
                                otherStates
}

UE-Positioning-LastKnownPos ::= SEQUENCE {
    sfn                            INTEGER (0..4095),
    cell-id                        CellIdentity,
    positionEstimate               PositionEstimate
}

-- The structure of UL-RFC3095-Context is FFS
UL-RFC3095-Context ::=          SEQUENCE {
    rfc3095-Context-Identity       INTEGER (0..16383),
    ul-mode                        ENUMERATED {u, o, r}
}

END

```

14.12.2 RRC information, target RNC to source RNC

There are 2 possible cases for RNC relocation:

1. The UE is already under control of target RNC; and
2. The SRNC Relocation with Hard Handover (UE still under control of SRNC), but UE is moving to a location controlled by the target RNC (based on measurement information).

In case 1 the relocation is transparent to the UE and there is no "reverse" direction container. The SRNC just assigns the 'serving' function to the target RNC, which then becomes the Serving RNC.

In case 2 the relocation is initiated by SRNC, which also provides the RRC Initialisation Information to the target RNC. Based on this information, the target RNC prepares the Hard Handover Message ("Physical channel reconfiguration" (subclause 8.2.6), "radio bearer establishment" (subclause 8.2.1), "Radio bearer reconfiguration" (subclause 8.2.2), "Radio bearer release" (subclause 8.2.3) or "Transport channel reconfiguration" (subclause 8.2.4).

In case 2 two possibilities are defined in order to transmit the relocation message from the target RNC to the source RNC which can be chosen by the source RNC by including or not including the IE "RB Id for handover message" in the IE "SRNS Relocation Info".

In case the IE "RB Id for handover message" has been received by the target RNC in the IE "SRNS Relocation Info", the target RNC should choose IE "DL DCCH message" and include the DL DCCH message that should be transmitted transparently to the UE by the source RNC. In that case, the target RNC is integrity protecting the message if applicable.

If the target RNC did not receive the IE "RB Id for handover message" in the IE "SRNS Relocation Info" the target RNC should use another choice. In that case, the source RNC should integrity protect the message before transmitting it to the UE if applicable.

The source RNC then transmits the Handover Message to the UE, which then performs the handover.

In the successful case, the UE transmits an XXX COMPLETE message, using the new configuration, to the target RNC.

In case of failure, the UE transmits an XXX FAILURE, using the old configuration, to the source RNC and the RRC context remains unchanged (has to be confirmed and checked with the SRNS relocation procedure).

Information Element/Group name	Need	Multi	Type and reference	Semantics description
CHOICE <i>RRC message</i>	MP			At least one spare choice, Criticality: Reject, is needed
>RADIO BEARER SETUP			RADIO BEARER SETUP 10.2.31	
>RADIO BEARER RECONFIGURATION			RADIO BEARER RECONFIGURATION 10.2.25	
>RADIO BEARER RELEASE			RADIO BEARER RELEASE 10.2.28	
>TRANSPORT CHANNEL RECONFIGURATION			TRANSPORT CHANNEL RECONFIGURATION 10.2.51	
>PHYSICAL CHANNEL RECONFIGURATION			PHYSICAL CHANNEL RECONFIGURATION	

Information Element/Group name	Need	Multi	Type and reference	Semantics description
			URATION 10.2.20	
>RRC FAILURE INFO			RRC FAILURE INFO 10.2.41 a	
>DL DCCH message			OCTET STRING	

14.12.4.2 SRNS RELOCATION INFO

This RRC message is sent between network nodes when preparing for an SRNS relocation.

With the presence or absence of the IE “RB identity for Hard Handover message” the source RNC indicates to the target SRNC whether the source RNC expects to receive the choice “DL DCCH message” in the IE “RRC information, target RNC to source RNC” in case the SRNS relocation is of type “UE involved”. Furthermore the target RNC uses this information for the calculation of the MAC-I

Direction: source RAT→target RNC

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
Non RRC IEs				
<u>RB identity for Hard Handover message</u>	<u>OP</u>		<u>RB identity 10.3.4.16</u>	<u>Gives the id of the radio bearer on which the source RNC will transmit the RRC message in the case the relocation is of type “UE involved”.</u>
>State of RRC	MP		RRC state indicator, 10.3.3.35a	
>State of RRC procedure	MP		Enumerated (await no RRC message, Complete, await RB Setup Complete, await RB Reconfiguration Complete, await RB Release Complete, await Transport CH Reconfiguration Complete, await Physical CH Reconfiguration Complete, await Active Set Update Complete,	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			await Handover Complete, send Cell Update Confirm, send URA Update Confirm, , others)	
Ciphering related information				
>Ciphering status for each CN domain	MP	<1 to maxCNDo mains>		
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>Ciphering status	MP		Enumerated(Not started, Started)	
>>START	MP		START 10.3.3.38	START value to be used in this CN domain.
>Latest configured CN domain	MP		CN domain identity 10.3.1.1	Value contained in the variable of the same name.
>Calculation time for ciphering related information	CV- <i>Ciphering</i>			Time when the ciphering information of the message were calculated, relative to a cell of the target RNC
>>Cell Identity	MP		Cell Identity 10.3.2.2	Identity of one of the cells under the target RNC and included in the active set of the current call
>>SFN	MP		Integer(0..40 95)	
>COUNT-C list	CV- <i>Ciphering</i>	1 to <maxCNdo mains>		COUNT-C values for radio bearers using transparent mode RLC
>>CN domain identity	MP		CN domain identity 10.3.1.1	
>>COUNT-C	MP		Bit string(32)	
>Ciphering info per radio bearer	OP	1 to <maxRB>		For signalling radio bearers this IE is mandatory.
>>RB identity	MP		RB identity 10.3.4.16	
>>Downlink HFN	MP		Bit string(20..25)	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
>>Downlink SN	CV- <i>SRB1</i>		Bit String(7)	VT(US) of RLC UM
>>Uplink HFN	MP		Bit string(20..25)	This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits)
Integrity protection related information				
>Integrity protection status	MP		Enumerated(Not started, Started)	
>Signalling radio bearer specific integrity protection information	CV- <i>IP</i>	4 to <maxSRBs etup>		
>>Uplink RRC HFN	MP		Bit string (28)	
>>Downlink RRC HFN	MP		Bit string	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			(28)	
>>Uplink RRC Message sequence number	MP		Integer (0..15)	
>>Downlink RRC Message sequence number	MP		Integer (0..15)	
>Implementation specific parameters	OP		Bit string (1..512)	
RRC IEs				
UE Information elements				
>U-RNTI	MP		U-RNTI 10.3.3.47	
>C-RNTI	OP		C-RNTI 10.3.3.8	
>UE radio access Capability	MP		UE radio access capability 10.3.3.42	
>UE radio access capability extension	OP		UE radio access capability extension 10.3.3.42a	
>Last known UE position	OP			
>>SFN	MP		Integer (0..4095)	Time when position was estimated
>>Cell ID	MP		Cell identity; 10.3.2.2	Indicates the cell, the SFN is valid for.
>>CHOICE <i>Position estimate</i>	MP			
>>>Ellipsoid Point			Ellipsoid Point; 10.3.8.4a	
>>>Ellipsoid point with uncertainty circle			Ellipsoid point with uncertainty circle 10.3.8.4d	
>>>Ellipsoid point with uncertainty ellipse			Ellipsoid point with uncertainty ellipse 10.3.8.4e	
>>>Ellipsoid point with altitude			Ellipsoid point with altitude 10.3.8.4b	
>>>Ellipsoid point with altitude and uncertainty ellipsoid			Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c	
Other Information elements				
>UE system specific capability	OP	1 to <maxSystemCapability>		
>>Inter-RAT UE radio access capability	MP		Inter-RAT UE radio access capability 10.3.8.7	
UTRAN Mobility Information elements				
>URA Identifier	OP		URA identity	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			10.3.2.6	
CN Information Elements				
>CN common GSM-MAP NAS system information	MP		NAS system information (GSM-MAP) 10.3.1.9	
>CN domain related information	OP	1 to <MaxCNdomains>		CN related information to be provided for each CN domain
>>CN domain identity	MP			
>>CN domain specific GSM-MAP NAS system info	MP		NAS system information (GSM-MAP) 10.3.1.9	
>>CN domain specific DRX cycle length coefficient	MP		CN domain specific DRX cycle length coefficient, 10.3.3.6	
Measurement Related Information elements				
>For each ongoing measurement reporting	OP	1 to <MaxNoOf Meas>		
>>Measurement Identity	MP		Measurement identity 10.3.7.48	
>>Measurement Command	MP		Measurement command 10.3.7.46	
>>Measurement Type	CV-Setup		Measurement type 10.3.7.50	
>>Measurement Reporting Mode	OP		Measurement reporting mode 10.3.7.49	
>>Additional Measurements list	OP		Additional measurements list 10.3.7.1	
>>CHOICE <i>Measurement</i>	OP			
>>>Intra-frequency				
>>>>Intra-frequency cell info	OP		Intra-frequency cell info list 10.3.7.33	
>>>>Intra-frequency measurement quantity	OP		Intra-frequency measurement quantity 10.3.7.38	
>>>>Intra-frequency reporting quantity	OP		Intra-frequency reporting quantity 10.3.7.41	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>>>Intra-frequency measurement reporting criteria			Intra-frequency measurement reporting criteria 10.3.7.39	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting			NULL	
>>>Inter-frequency				
>>>>Inter-frequency cell info	OP		Inter-frequency cell info list 10.3.7.13	
>>>>Inter-frequency measurement quantity	OP		Inter-frequency measurement quantity 10.3.7.18	
>>>>Inter-frequency reporting quantity	OP		Inter-frequency reporting quantity 10.3.7.21	
>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Inter-frequency measurement reporting criteria			Inter-frequency measurement reporting criteria 10.3.7.19	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>Inter-RAT				
>>>>>Inter-RAT cell info	OP		Inter-RAT cell info list 10.3.7.23	
>>>>>Inter-RAT measurement quantity	OP		Inter-RAT measurement quantity 10.3.7.29	
>>>>>Inter-RAT reporting quantity	OP		Inter-RAT reporting quantity 10.3.7.32	
>>>>>Reporting cell status	OP		Reporting cell status 10.3.7.61	
>>>>>Measurement validity	OP		Measurement validity 10.3.7.51	
>>>>>CHOICE <i>report criteria</i>	OP			
>>>>>>Inter-RAT measurement			Inter-RAT	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
reporting criteria			measurement reporting criteria 10.3.7.30	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting			NULL	
>>>Traffic Volume				
>>>>Traffic volume measurement Object	OP		Traffic volume measurement object 10.3.7.70	
>>>>Traffic volume measurement quantity	OP		Traffic volume measurement quantity 10.3.7.71	
>>>>Traffic volume reporting quantity	OP		Traffic volume reporting quantity 10.3.7.74	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>>Traffic volume measurement reporting criteria			Traffic volume measurement reporting criteria 10.3.7.72	
>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>No reporting			NULL	
>>>>Quality				
>>>>>Quality measurement Object	OP		Quality measurement object	
>>>>>CHOICE <i>report criteria</i>	OP			
>>>>>>Quality measurement reporting criteria			Quality measurement reporting criteria 10.3.7.58	
>>>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>>>No reporting			NULL	
>>>>>UE internal				
>>>>>>UE internal measurement quantity	OP		UE internal measurement quantity 10.3.7.79	
>>>>>>UE internal reporting quantity	OP		UE internal reporting quantity 10.3.7.82	
>>>>>>CHOICE <i>report criteria</i>	OP			
>>>>>>>UE internal measurement reporting criteria			UE internal measurement	

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
			t reporting criteria 10.3.7.80	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting			NULL	
>>>UE positioning				
>>>LCS reporting quantity	OP		LCS reporting quantity 10.3.7.111	
>>>>CHOICE <i>report criteria</i>	OP			
>>>>LCS reporting criteria			LCS reporting criteria 10.3.7.110	
>>>>Periodical reporting			Periodical reporting criteria 10.3.7.53	
>>>>No reporting				
Radio Bearer Information Elements				
>Predefined configuration status information	OP		Predefined configuration status information 10.3.4.5a	
>Signalling RB information list	MP	1 to <maxSRBs etup>		For each signalling radio bearer
>>Signalling RB information	MP		Signalling RB information to setup 10.3.4.24	
>RAB information list	OP	1 to <maxRABs etup>		Information for each RAB
>>RAB information	MP		RAB information to setup 10.3.4.10	
Transport Channel Information Elements				
Uplink transport channels				
>UL Transport channel information common for all transport channels	OP		UL Transport channel information common for all transport channels 10.3.5.24	
>UL transport channel information list	OP	1 to <MaxTrCH >		
>>UL transport channel information	MP		Added or reconfigured UL TrCH information 10.3.5.2	
>CHOICE <i>mode</i>	OP			

Information Element/Group Name	Need	Multi	Type and reference	Semantics description
>>FDD				
>>>CPCH set ID	OP		CPCH set ID 10.3.5.5	
>>>>Transport channel information for DRAC list	OP	1 to <MaxTrCH >		
>>>>>DRAC static information	MP		DRAC static information 10.3.5.7	
>>TDD				(no data)
Downlink transport channels				
>DL Transport channel information common for all transport channels	OP		DL Transport channel information common for all transport channels 10.3.5.6	
>DL transport channel information list	OP	1 to <MaxTrCH >		
>>DL transport channel information	MP		Added or reconfigured DL TrCH information 10.3.5.1	
>Measurement report	OP		MEASUREMENT REPORT 10.2.17	
Other Information elements				
Failure cause	OP		Failure cause 10.3.3.13	Diagnostics information related to an earlier SRNC Relocation request (see NOTE 2 in 14.12.0a)
Protocol error information	CV-ProtErr		Protocol error information 10.3.8.12	

Multi Bound	Explanation
MaxNoOfMeas	Maximum number of active measurements, upper limit 16

Condition	Explanation
<i>Setup</i>	The IE is mandatory present when the IE Measurement command has the value "Setup", otherwise the IE is not needed.
<i>Ciphering</i>	The IE is mandatory present when the IE Ciphering Status has the value "started" and the ciphering counters need not be reinitialised, otherwise the IE is not needed.
<i>IP</i>	The IE is mandatory present when the IE Integrity protection status has the value "started" and the integrity protection counters need not be reinitialised, otherwise the IE is not needed.
<i>ProtErr</i>	This IE is mandatory present if the IE "Protocol error indicator" is included and has the value "TRUE". Otherwise it is not needed.
<i>SRB1</i>	The IE is mandatory present for RB1. Otherwise it is not needed.