

Source: TSG SA WG2
Title: CRs on 23.127 v.3.0.0 (VHE/OSA stage 2)
Agenda Item: 6.2.3

The following Change Requests (CRs) have been approved by TSG SA WG2 and are requested to be approved by TSG SA plenary #8.

Note: the source of all these CRs is now S2, even if the name of the originating company(ies) is still reflected on the cover page of all the attached CRs.

CRs on 23.127 v.3.0.0

spec	release	CR #	cat	Title	S2 TDoc #
23.127	R99	001r1	C	OSA Internal API	S2-000965
23.127	R99	002r1	F	Editorial changes and improvements	S2-000966
23.127	R99	003r1	F	Alignment with stage 3 (TS 29.198)	S2-000963
23.127	R99	004	C	Removal of data-related parameters in call control SCF	S2-000833
23.127	R99	005	F	Replacement of "Camel" by "Network" in Network User	S2-000834
23.127	R99	006r1	C	Introduction of improved notification mechanism	S2-000964
23.127	R99	008r1	C	Modification of call control	S2-000967
23.127	R99	009	C	Data Session Control	S2-001204
23.127	R99	010	C	Modification of call control SCF	S2-001205

CHANGE REQUEST		Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.	
23.127 CR 001R1		Current Version: 3.0.0	
GSM (AA.BB) or 3G (AA.BBB) specification number ↑		↑ CR number as allocated by MCC support team	
For submission to: SA#8 <small>list expected approval meeting # here ↑</small>	for approval <input checked="" type="checkbox"/> for information <input type="checkbox"/>	strategic <input type="checkbox"/> non-strategic <input type="checkbox"/>	(for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
(at least one should be marked with an X)

Source: Alcatel, Ericsson, Siemens **Date:** 22.5.2000

Subject: OSA Internal API

Work item: VHE/OSA

Category:	F Correction <input type="checkbox"/> A Corresponds to a correction in an earlier release <input type="checkbox"/> B Addition of feature <input type="checkbox"/> C Functional modification of feature <input checked="" type="checkbox"/> D Editorial modification <input type="checkbox"/>	Release:	Phase 2 <input type="checkbox"/> Release 96 <input type="checkbox"/> Release 97 <input type="checkbox"/> Release 98 <input type="checkbox"/> Release 99 <input checked="" type="checkbox"/> Release 00 <input type="checkbox"/>
------------------	--	-----------------	--

(only one category shall be marked with an X)

Reason for change: Introduction of an open API between framework and SCSs in the OSA architecture allows for multi-vendor solutions, where framework servers and SCSc are provided by different manufacturers.

Clauses affected: 3.1, 5, 6.1.3, 6.2, 8 (new)

Other specs affected:

Other 3G core specifications	"> <input type="checkbox"/>	→ List of CRs:
Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:
MS test specifications	<input type="checkbox"/>	→ List of CRs:
BSS test specifications	<input type="checkbox"/>	→ List of CRs:
O&M specifications	<input type="checkbox"/>	→ List of CRs:

Other comments:



help.doc

<----- double-click here for help and instructions on how to create a CR.

3 Definitions and abbreviations

3.1 Definitions

For the purposes of this TS, the following definitions apply:

Applications: software components providing services to end-users by utilising service capability features.

HE-VASP: see [9]

Home Environment: responsible for overall provision of services to users.

Local Service: see[9]

OSA Interface: Standardised Interface used by applications to access service capability features.

OSA Internal API: Standardised API between framework and service capability servers.

Personal Service Environment: contains personalised information defining how subscribed services are provided and presented towards the user. The Personal Service Environment is defined in terms of one or more User Profiles.

Service Capabilities: see [9]

Service Capability Feature: see [9]

Service Capability Server: Functional Entity providing OSA interfaces towards an application.

Services: see [9]

User Interface Profile: see [9]

User Profile: see [9]

User Services Profile: see [9].

Value Added Service Provider see [9]

Virtual Home Environment: see [9].

Further UMTS related definitions are given in 3G TS 22.101 and 3G TR 22.905.

5.1 Overview of the Open Service Architecture

The Open Service Architecture consists of three parts:


- **Applications**, e.g. VPN, conferencing, location based applications. These applications are implemented in one or more Application Servers;
- **Framework**, providing applications with basic mechanisms that enable them to make use of the service capabilities in the network. Examples of framework service capability features are Authentication and Discovery. Before an application can use the network functionality made available through the Service Capability Servers, authentication between the application and framework is needed. After authentication, the discovery service capability feature enables the application to find out which network service capability features are provided by the Service Capability Servers. The network service capability features are accessed by the methods defined in the OSA interface classes.
- **Service Capability Servers**, providing the applications with service capability features, which are abstractions from underlying network functionality. Examples of service capability features offered by the Service Capability Servers are Call Control and User Location. Similar service capability features may possibly be provided by more than one Service Capability Server. For example, Call Control functionality might be provided by SCSs on top of CAMEL and MExE.

The OSA service capability features are specified in terms of a number of interface classes and their methods. The interface classes are divided into two groups:

- **framework interface classes**, describing the methods on the framework
- **network interface classes**, describing the methods on the service capability servers.

The interface classes are further divided into methods. For example, the Call Manager interface class might contain a method to create a call (which realises one of the Service capability features 'Initiate and create session' as specified in [9]).

Note that the CAMEL Service Environment does not provide the service logic execution environment for applications using the OSA interface, since these applications are executed in Application Servers.






Figure 1 Overview of Open Service Architecture

This specification, together with the associated stage 3 specification, defines the OSA interface and the OSA internal API between the framework and the service capability servers. OSA does not mandate any specific platform or programming language.

The Service Capability Servers that implement the OSA interface classes are functional entities that can be distributed across one or more physical nodes. For example, the User Location interface classes and Call Control interface classes might be implemented on a single physical entity or distributed across different physical entities. Furthermore, a service capability server can be implemented on the same physical node as a network functional entity or in a separate physical node. For example, Call Control interface classes might be implemented on the same physical entity as the CAMEL protocol stack (i.e. in the SCP) or on a different physical entity.

Several options exist:

Option 1

The OSA interface classes are implemented in one or more physical entity, but separate from the physical network entities. Figure 2 shows the case where the OSA interface classes are implemented in one physical entity, called “gateway” in the figure. Figure 3 shows the case where the SCSs are distributed across several ‘gateways’.




Figure 2 SCSs and network functional entities implemented in separate physical entities




Figure 3 SCSs and network functional entities implemented in separate physical entities, SCSs distributed across several 'gateways'.

Option 2

The OSA interface classes are implemented in the same physical entities as the traditional network entities (e.g. HLR, CSE), see figure 4.




Figure 4 SCSs and network functional entities implemented in same physical entities

Option 3

Option 3 is the combination of option 1 and option 2, i.e. a hybrid solution.




Figure 5 Hybrid implementation (combination of option 1 and 2)

It shall be noted that in all cases there is only one framework. This framework may reside within one of the physical entities containing an SCS or in a separate physical entity.

From the application point of view, it shall make no difference which implementation option is chosen, i.e. in all cases the same network functionality is perceived by the application. The applications shall always be provided with the same set of interface classes and a common access to framework and service capability feature interfaces. It is the framework that will provide the applications with an overview of available service capability features and how to make use of them.

5.2 Basic mechanisms in the Open Service Architecture

This section explains which basic mechanisms are executed in OSA prior to offering and activating applications.

Some of the mechanisms are applied only once (e.g. establishment of service agreement), others are applied each time a user subscription is made to an application (e.g. enabling the call attempt event for a new user).

Basic mechanisms between Application and Framework:

- **Authentication:** Once an off-line service agreement exists, the application can access the authentication interface. The authentication model of OSA is a peer-to-peer model. The application must authenticate the framework and vice versa. The application must be authenticated before it is allowed to use any other OSA interface.
- **Authorisation:** Authorisation is distinguished from authentication in that authorisation is the action of determining what a previously authenticated application is allowed to do. Authentication must precede authorisation. Once authenticated, an application is authorised to access certain service capability features.
- **Discovery of framework and network service capability features.** After successful authentication, applications can obtain available framework interface classes and use the discovery interface to obtain information on authorised network service capability features. The Discovery interface can be used at any time after successful authentication.
- **Establishment of service agreement.** Before any application can interact with a network service capability feature, a service agreement must be established. A service agreement may consist of an off-line (e.g. by physically passing messages) and an on-line part. The application has to sign the on-line part of the service agreement before it is allowed to access any network service capability feature.
- **Access to network service capability features:** The framework must provide access control functions to authorise the access to service capability features or service data for any API operation from a client, with the specified security level, context, domain, etc.

Basic mechanism between Framework and Service Capability Server:

- **Registering of network service capability features.** SCFs offered by a Service Capability Server can be registered at the Framework. In this way the Framework can inform the Applications upon request about available service capability features (Discovery). For example, this mechanism is applied when installing or upgrading a Service Capability Server. See clause 8 for details. ~~This mechanism is in general applied when installing or upgrading a Service Capability Server.~~

~~<editor's note: this mechanism is considered as of lower priority than other parts of OSA for R'99>~~

Basic mechanisms between Application Server and Service Capability Server:

- **Request of event notifications.** This mechanism is applied when a user has subscribed to an application and that application needs to be invoked upon receipt of events from the network related to the user. For example, when a user subscribes to a screening application, the application needs to be invoked when the user makes a call. It will therefore request to be notified when a call setup is performed, with the user number as Called Party Number.

6.1.3 OSA Access

During an authenticated session accessing the Framework, the client application will be able to select and access an instance of a framework or network service capability feature.

Access to framework SCFs is gained by invoking the `obtainInterface`, or `obtainInterfaceWithCallback` operations. The latter is used when a callback reference is supplied to the framework. For example, a network SCF discovery interface class reference is returned when invoking `obtainInterface` with “discovery” as the SCF name.

In order to use network SCFs, the client must first be authorised to do so by establishing a service agreement with the Home Environment. The client application uses the discovery SCF to retrieve the ID of the network SCF they wish to use. They may then use the `accessCheck` operation to check that they are authorised to use the network SCF. The `selectService` operation is used to tell the Home Environment that the client application wishes to use the network SCF. The `signServiceAgreement` operation is used to digitally sign the agreement, and provide non-repudiation for both parties in agreeing that the SCF would be available for use.

Establishing a service agreement is a business level transaction, which requires the HE-VASP that owns the client application to agree terms for the use of an SCF with the Home Environment. Service agreements can be reached using either off-line or on-line mechanisms. Off-line agreements will be reached outside of the scope of OSA interactions, and so are not described here. However, client applications can make use of service agreements that are made off-line. Some Home Environments may only offer off-line mechanisms to reach service agreements.

After a service agreement has been established between the client and the Home Environment domains, the client application will be able to make use of this agreement to access the network SCF.

The `accessCheck` operation allows the client application to check whether it has permission to access (read, write, etc) to a specified SCF, and specific SCF features. The client application defines the security domain and context of access to the SCF. The access control policy is based on a number of conditions, events and permissions that determine whether the client application is authorised to access the SCF/feature.

The `accessCheck` operation is optional, in that can be called by the client application to check that it has permission to use specific SCF features, before starting an SCF instance. It is not compulsory for the client application to make this check before selecting a network SCF and signing a service agreement to use an instance of the SCF. If the `accessCheck` operation confirms that the client application has permission to use a specific SCF feature, then this feature should be available to the client application when using the SCF instance. The Home Environment may include the results of the `accessCheck` as part of the service agreement, that is signed before using an SCF instance, thereby assuring the client application that the SCF features will be available.

The `selectService` operation is used to identify the SCF that the client application wishes to use. A list of service properties initialises the SCF, and an SCF token is returned. The client application and Home Environment must sign a copy of the service agreement to confirm the use of the SCF. The framework invokes `signServiceAgreement` operation on the client applications’ Access callback interface with the service agreement text to be signed. The client application uses its digital signature key to sign the agreement text, and return the signed text to the framework. The client application then calls the `signServiceAgreement` operation on the OSA Access SCF. The framework signs the agreement text, retrieves a reference to a network manager interface for the selected SCF (using the `getServiceManager` method defined in clause 8), and returns this reference to the client application. ~~The framework signs the agreement text, retrieves a reference to a network manager interface for the selected SCF (using a mechanism not specified in release 99), and returns this reference to the client application.~~

In addition, the OSA Access interface may be invoked by SCSs in the context of SCF registration, see subclause 8.1.

The OSA Access framework SCF is defined by a single interface class, which consists of the following methods.

Method `obtainInterface ()`

This method is used to obtain other framework SCFs. The client application uses this method to obtain interface references to other framework SCFs. (The `obtainInterfacesWithCallback` method should be used if the client application is required to supply a callback interface to the framework.)

Direction Application to network

Parameters **interfaceName**
The name of the framework SCF to which a reference to the interface is requested.

Returns **fwInterface**
This is the reference to the SCF interface requested.

Errors **INVALID_INTERFACE_NAME**
Returned if the interfaceName is invalid.

Method **obtainInterfaceWithCallback ()**

This method is used to obtain other framework SCFs. The client application uses this method to obtain interface references to other framework SCFs, when they are required to supply a callback interface to the framework. (The obtainInterface method should be used when no callback interface needs to be supplied.)

Direction Application to network

Parameters **interfaceName**
The name of the framework SCF to which a reference to the interface is requested.

appInterface
This is the reference to the client application interface, which is used for callbacks. If an application interface is not needed, then this method should not be used. (The obtainInterface method should be used when no callback interface needs to be supplied.)

Returns **fwInterface**
This is the reference to the SCF requested.

Errors **INVALID_INTERFACE_NAME**
Returned if the interfaceName is invalid.

Method **accessCheck ()**

This method may be used by the client application to check whether it has been granted permission to access the specified SCF. The response is used to indicate whether the request for access has been granted or denied and if granted the level of trust that will be applied. The securityModelID and the relevant securityLevel are available as part of the registration data for the SCF.

securityModelID:

The identity of the specific Security Model that is to be used to define a set of appropriate policies for the SCF that can be used by the framework to determine access rights. The model may include: blanket permission; session permission or one shot permission. A number of security models will be stored by the framework, and referenced by the access control module, according to the security model identifier of the SCF.

securityLevel:

The trust level required by the SCF for granting access. The Security Level is used by the

framework's access control module when it checks for access rights.

Direction Application to network

Parameters **securityContext**

A context is a group of security relevant attributes that may have an influence on the result of the accessCheck request.

securityDomain

The security domain in which the client application is operating may influence the access control decisions and the specific set of features that the requestor is entitled to use.

group

A group can be used to define the access rights associated with all clients that belong to that group. This simplifies the administration of access rights.

serviceAccessTypes

These are defined by the specific Security Model in use but are expected to include: Create, Read, Update, Delete as well as those specific to SCFs.

Returns **serviceAccessControl**

This is a structure containing the access control policy information controlling access to the SCF, and the trustLevel that the Home Environment has assigned to the client application. It consists of

- policy: indicates whether access has been granted or denied. If granted then the parameter trustLevel must also have a value.
- trustLevel: The trustLevel parameter indicates the trust level that the Home Environment has assigned to the client application.

Errors

Method **selectService ()**

This method is used by the client application to identify the network SCF that the client application wishes to use.

Direction Application to network

Parameters **serviceID**

This identifies the SCF required.

serviceProperties

This is a list of the properties that the SCF should support. These properties (names and values) are used to initialise the SCF instance for use by the client application.

Returns **serviceToken**

This is a free format text token returned by the framework, which can be signed as part of a service agreement. This will contain operator specific information relating to the service level agreement. The serviceToken has a limited lifetime. If the lifetime of the serviceToken expires, a method accepting the serviceToken will return an error code (INVALID_Service_TOKEN). Service Tokens will automatically expire if the client or framework invokes the endAccess method on the other's corresponding access interface.

Errors	<p>INVALID_SERVICE_ID Returned if the serviceID is not recognised by the framework</p> <p>INVALID_SERVICE_PROPERTY Returned if a property is not recognised by the framework</p>
Method	<p>signServiceAgreement () (<i>application to network</i>)</p> <p>This method is used by the client application to request that the framework sign an agreement on the SCF, which allows the client application to use the SCF. If the framework agrees, both parties sign the service agreement, and a reference to the manager interface of the SCF is returned to the client application.</p>
Direction	Application to network
Parameters	<p>serviceToken This is the token returned by the framework in a call to the <code>selectService()</code> method. This token is used to identify the SCF instance requested by the client application.</p> <p>agreementText This is the agreement text that is to be signed by the framework using the private key of the framework.</p> <p>signingAlgorithm This is the algorithm used to compute the digital signature.</p>
Returns	<p>signatureAndServiceMgr This is a reference to a structure containing the digital signature of the framework for the service agreement, and a reference to the manager interface of the SCF:</p> <ul style="list-style-type: none"> • The <code>digitalSignature</code> is the signed version of a hash of the service token and agreement text given by the client application. • The <code>serviceMgrInterface</code> is a reference to the manager interface for the selected SCF.
Errors	<p>INVALID_SERVICE_TOKEN Returned if the serviceToken is not recognised by the framework</p>
Method	<p>signServiceAgreement () (<i>network to application</i>)</p> <p>This method is used by the framework to request that the client application sign an agreement on the SCF. It is called in response to the client application calling the <code>selectService()</code> method on the Access SCF of the framework. The framework provides the service agreement text for the client application to sign. If the client application agrees, it signs the service agreement, returning its digital signature to the framework.</p>
Direction	Network to application
Parameters	<p>serviceToken This is the token returned by the framework in a call to the <code>selectService()</code> method. This token is used to identify the SCF instance to which this service agreement corresponds. (If the client application selects many SCFs, it can determine which selected SCF corresponds to the service agreement by matching the service token.)</p>

agreementText

This is the agreement text that is to be signed by the client application using the private key of the client application.

signingAlgorithm

This is the algorithm used to compute the digital signature.

Returns**digitalSignature**

The digitalSignature is the signed version of a hash of the service token and agreement text given by the framework.

Errors**Method****terminateServiceAgreement ()** (*application to network*)

This method is used by the client application to terminate a service agreement for the SCF.

Direction

Application To Network

Parameters**serviceToken**

This is the token passed back from the framework in a previous `selectService ()` method call. This token is used to identify the service agreement to be terminated.

terminationText

This is the termination text describes the reason for the termination of the service agreement.

digitalSignature

This is a signed version of a hash of the service token and the termination text. The signing algorithm used is the same as the signing algorithm given when the service agreement was signed using `signServiceAgreement ()`. The framework uses this to check that the `terminationText` has been signed by the client. If a match is made, the service agreement is terminated, otherwise an error is returned.

Returns**Errors****Method****terminateServiceAgreement ()** (*network to application*)

This method is used by the framework to terminate a service agreement for the SCF.

Direction

Network to application

Parameters**serviceToken**

This is the token passed back from the framework in a previous `selectService ()` method call. This token is used to identify the service agreement to be terminated.

terminationText

This is the termination text describes the reason for the termination of the service agreement.

digitalSignature

This is a signed version of a hash of the service token and the termination text. The signing algorithm used is the same as the signing algorithm given when the service agreement was signed using `signServiceAgreement ()`. The framework uses this to confirm its identity to the client.

The client can check that the `terminationText` has been signed by the framework.

Returns

Errors

Method **endAccess ()**

The `endAccess` operation is used to end the client application's access session with the framework. The client requests that its access session be ended. After it is invoked, the client application will no longer be authenticated with the framework. The client application will not be able to use the references to any of the framework SCFs gained during the access session. Any calls to these SCF interfaces will fail.

Direction Application To Network

Parameters

Returns

Errors

Method **terminateAccess ()**

The `terminateAccess` operation is used to end the client application's access session with the framework (e.g. this may be done if the framework believes the client application is masquerading as someone else. Using this operation will force the client application to re-authenticate if it wishes to continue using the framework SCFs.)

After `terminateAccess()` is invoked, the client application will no longer be authenticated with the framework. The client application will not be able to use the references to any of the framework SCFs gained during the access session. Any calls to these interfaces will fail.

Direction Network to application

Parameter **terminationText**

This is the termination text describes the reason for the termination of the access session.

signingAlgorithm

This is the algorithm used to compute the digital signature.

digitalSignature

This is a signed version of a hash of the termination text. The framework uses this to confirm its identity to the client. The client can check that the `terminationText` has been signed by the framework.

Returns

Errors

6.2 Discovery

The discovery SCF consists of a single interface class. Before a network SCF can be discovered, the client application

must know what “types” of SCFs are supported by the Framework and what “properties” are applicable to each SCF type. The `listServiceType()` method returns a list of all “SCF types” that are currently supported by the framework and the “describeServiceType()” returns a description of each SCF type. The description of SCF type includes the “SCF-specific properties” that are applicable to each SCF type. Then the client application can discover a specific set of registered SCFs that belong to a given type and possess the desired “property values”, using the “discoverService()” method.

Once the HE-VASP finds out the desired set of SCFs supported by the network, it subscribes (a sub-set of) these SCFs using the Subscription framework SCF. The HE-VASP (or the client applications in its domain) can find out the set of SCFs available to it (i.e., the SCFs that it can use) by invoking “listSubscriberServices()”.

The discovery SCF is invoked by the HE-VASP or client applications. In addition, the discovery interface may be invoked by SCSs in the context of SCF registration, see subclause 8.1. Its methods are described below.

Method **discoverService ()**

The `discoverService` operation is the means by which a client application is able to obtain the IDs of the SCFs that meet its requirements. The client application passes in a list of desired properties to describe the SCF it is looking for, in the form attribute/value pairs for the properties. The client application also specifies the maximum number of matched responses it is willing to accept. The framework must not return more matches than the specified maximum, but it is up to the discretion of the Framework implementation to choose to return less than the specified maximum. The `discoverService()` operation returns a serviceID/Property pair list for those SCFs that match the desired property list that the client application provided.

Direction Application to network

Parameters **serviceName**

The “serviceName” parameter conveys the required SCF type. It is key to the central purpose of “SCF trading”. By stating an SCF type, the importer implies the SCF type and a domain of discourse for talking about properties of SCF.

The framework may return an SCF of a subtype of the “type” requested. An SCF sub-type can be described by the properties of its supertypes.

desiredPropertyList

The “desiredPropertyList” parameter is a list of property name and property value pairs of properties that the discovered set of SCFs should satisfy. These properties deal with the non-functional and non-computational aspects of the desired SCF. The property values in the desired property list must be logically interpreted as “minimum”, “maximum”, etc. by the framework.

max

The “max” parameter states the maximum number of SCFs that are to be returned in the “ServiceList” result.

Returns **serviceList :**

This parameter gives a list of matching SCFs. Each SCF is characterised by an SCF ID and a list of property name and property value pairs associated with the SCF.

Errors **ILLEGAL_SERVICE_TYPE**

Returned if the string representation of the “type” does not obey the rules for SCF type identifiers

UNKNOWN_SERVICE_TYPE

Returned if the “type” is correct syntactically but is not recognised as an SCF type within the Framework

Method **listServiceTypes ()**

This operation returns the names of all SCF types which are in the repository. The details of the SCF types can then be obtained using the describeServiceType() method.

Direction Application to network

Parameters

Returns **listTypes**

The names of the requested SCF types.

Errors**Method** **describeServiceType ()**

This operation lets the caller to obtain the details for a particular SCF type.

Direction Application to network

Parameters **name**

The name of the SCF type to be described

Returns **serviceTypeDescription**

The description of the specified SCF type. The description provides information about:

- the property names associated with the SCF,
- the corresponding property value types,
- the corresponding property mode (mandatory or read only) associated with each SCF property,
- the names of the super types of this type, and
- whether the type is currently enabled or disabled.

Errors **ILLEGAL_SERVICE_TYPE**

Returned if the string representation of the “type” does not obey the rules for SCF type identifiers

UNKNOWN_SERVICE_TYPE

Returned if the “type” is correct syntactically but is not recognised as an SCF type within the Framework

Method **listSubscribedServices ()**

Returns a list of SCFs so far subscribed by the HE-VASP. The HE-VASP (or the client applications in the HE-VASP domain) can obtain a list of subscribed SCFs that they are allowed to access.

Direction Application to network

Parameters

Returns **serviceIDList**

Returns a list of IDs of the SCFs subscribed by the HE-VASP.

Errors

8 OSA Internal API

The OSA internal API between framework and service capability servers supports registering of network service capability features, and permits the framework to retrieve a network SCF manager interface when an application is granted access to a network SCF.

8.1 OSA Access and Discovery

To support registration, the OSA Access and Discovery interfaces, as defined in [clause 6](#), shall be supported at the OSA internal API.

8.2 Registration of network service capability features at the framework

The Framework needs to know the Service Capability Features provided by the SCSs, in order to make them available to applications. For this purpose network service capability features have to be registered with the Framework, and they need to be registered in such a way that applications can discover them as specified in [clause 6](#).

Note: Framework and Service Capability Servers are located within the same trusted domain. Therefore no authentication mechanisms are required between them.

The following table gives an overview of the methods defined in this [subclause](#) and to which interfaces these methods belong.

<u>Service Registration</u>	<u>Service Factory</u>
<u>registerService</u>	<u>getServiceManager</u>
<u>announceServiceAvailability</u>	
<u>unregisterService</u>	
<u>describeService</u>	

Table 1 Overview of Registration interfaces and their methods

8.2.1 Service Registration

The Service Registration interface provides the methods used for the registration of network SCFs at the framework.

Method **registerService()**

The registerService() operation is the means by which a service capability feature is registered in the framework, for subsequent discovery by the applications. A serviceID is returned to the service capability server when a service capability feature is registered in the framework. The serviceID is the handle with which the service capability server can identify the registered service capability feature when needed (e.g. for withdrawing it). The serviceID is only meaningful in the context of the framework that generated it.

Direction Network to network (service capability server to framework)

Parameters **serviceTypeName**

This parameter identifies the SCF type and a set of named property types that may be used in further

describing this service capability feature , i.e. it restricts what is acceptable in the servicePropertyList parameter.

servicePropertyList

This parameter is a list of property name and property value pairs. They describe the SCF being registered. This description typically covers behavioural, non-functional and non-computational aspects of the SCF. It allows for several versions with different descriptions of the same SCF, so that different applications may be allowed different levels of use of the same SCF.

SCF properties may be marked as “mandatory” or “readonly”. These property mode attributes have the following semantics:

mandatory – an SCF associated with this SCF type must provide an appropriate value for this property when registering.

readonly – this modifier indicates that the property is optional, but that once given a value, it may not be subsequently modified.

Some properties may be marked both “mandatory” and “readonly”. Specifying both modifiers indicates that a value must be provided and that it may not be subsequently modified. Examples of such properties are those which form part of a service agreement and hence cannot be modified by the SCS during the life time of the SCF.

Returns

serviceID

This is the unique handle that is returned as a result of the successful completion of this operation. It identifies the SCF as described in terms of properties, that is, as will be allowed to be used by a certain application. The SCS can identify the registered SCF when attempting to access it via other operations such as announceServiceAvailability(), etc. Applications are also returned this serviceID when attempting to discover an SCF of this type.

Errors

If the string representation of the serviceTypeName does not obey the rules for identifiers, then an ILLEGAL_SERVICE_TYPE exception is raised.

If the serviceTypeName is correct syntactically but the framework is able to unambiguously determine that it is not a recognized SCF type, then an UNKNOWN_SERVICE_TYPE exception is raised.

If the type of any of the property values is not the same as the declared type (declared in the SCF type), then a PROPERTY_TYPE_MISMATCH exception is raised.

If an attempt is made to assign a dynamic property value to a readonly property, then the READONLY_DYNAMIC_PROPERTY exception is raised.

If the servicePropertyList parameter omits any property declared in the SCF type with a mode of mandatory, then a MISSING_MANDATORY_PROPERTY exception is raised.

If two or more properties with the same property name are included in this parameter, the DUPLICATE_PROPERTY_NAME exception is raised.

Method

announceServiceAvailability()

The registerService() method described previously does not make an SCF discoverable. The announceServiceAvailability() method is invoked after the SCF's "service factory" is instantiated at a particular interface. This method informs the framework of the availability of a "service factory" for the previously registered SCF, identified by its serviceID, at a specific interface. This "service factory" is the entry point for subsequent use of the corresponding SCF, as previously described in terms of properties. After the receipt of this information, the framework makes the corresponding SCF (identified by the pair [serviceID, serviceFactoryRef]) discoverable.

Direction

Network to network (service capability server to framework)

Parameters**serviceID**

The serviceID of the SCF that is being announced.

serviceFactoryRef

The interface reference at which the "service factory" of the previously registered SCF is available.

Returns**Errors**

If the string representation of the serviceID does not obey the rules for SCF identifiers, then an ILLEGAL_SERVICE_ID exception is raised.

If the serviceID is legal but there is no SCF offer within the Framework with that ID, then an UNKNOWN_SERVICE_ID exception is raised.

Method**unregisterService()**

The unregisterService() operation is used by the SCSs to remove a registered SCF from the framework. The SCF is identified by the serviceID, which was originally returned by the framework in response to the registerService() operation. After the unregisterService(), the SCF can no longer be discovered by applications.

Direction

Network to network (service capability server to framework)

Parameters**serviceID**

The SCF to be withdrawn is identified by the serviceID parameter, which was originally returned by the registerService() operation.

Returns**Errors**

If the string representation of the serviceID does not obey the rules for SCF identifiers, then an ILLEGAL_SERVICE_ID exception is raised.

If the serviceID is legal but there is no SCF offer within the Framework with that ID, then an UNKNOWN_SERVICE_ID exception is raised.

Method**describeService()**

The describeService() operation returns the information about an SCF that is registered in the framework. It comprises the type of the SCF and the properties that describe this SCF. The SCF is identified by the serviceID parameter which was originally returned by the registerService() operation.

This operation is intended to be used between a certain framework and the SCS that registered the SCF, since it is only between them that the serviceID is valid. The SCS may register various versions of the same SCF, each with a different description (more or less restrictive, for example), and each getting a different serviceID assigned. Getting the description of these SCFs from the framework where they have been registered helps the SCS internal maintenance.

Direction

Network to network (service capability server to framework)

Parameters**serviceID**

The SCF to be described is identified by the serviceID parameter, which was originally returned by the registerService() operation.

Returns**serviceDescription**

This consists of the information about an offered SCF that is held by the Framework. It comprises the "type" of the SCF, and the properties that describe this SCF.

Errors

If the string representation of the serviceID does not obey the rules for SCF identifiers, then an ILLEGAL_SERVICE_ID exception is raised.

If the serviceID is legal but there is no SCF offer within the Framework with that ID, then an UNKNOWN_SERVICE_ID exception is raised.

Sequence Diagram

The sequence diagram in figure 11 demonstrates the registration of a new service capability feature, announcing the availability of a registered SCF to the framework, or deletion of an existing registered SCF from the framework, by the SCS.

The SCSs can register only those SCFs, which are supported by the framework (i.e., the corresponding SCF types are supported in the framework). The SCF registration function is supported by the Service Registration interface of the framework. The SCS obtains the reference to the Service Registration interface of the framework by invoking obtainInterface() on the OSA Access interface of the framework. The SCS may first obtain a list of SCF types supported by the framework by invoking listServiceTypes() on the discovery SCF and then obtain a description of a given SCF type by invoking describeServiceType(). Once the supported SCF types and their description (i.e., the SCF properties applicable to each type) are obtained, the SCS can perform SCF registration.

SCF registration is a two-step process, after which a certain version of an SCF, characterised by a serviceDescription, is assigned a serviceID for identification purposes, and a reference to a service factory interface as a first entry point for applications.

- As a first step the SCSs invokes registerService() method on the Service Registration interface by giving the SCF type name and the values of the SCF properties. The framework returns a serviceID, which uniquely identifies the registered SCF within the framework.
- The second step is the instantiation of the SCF at an interface that will be registered in the framework together with its corresponding serviceID. This implies that the SCF is now available for use. The SCSs or the SCF itself invokes announceServiceAvailability() on the framework to announce the availability of the SCF identified by its serviceID at a particular interface. The announceServiceAvailability() method may associate the serviceID either with the actual SCF interface or with the interface of the SCF manager (to achieve location transparency).

An SCF may be withdrawn from the domain by an SCS by invoking unregisterService() on the Service Registration interface. The SCF is identified by the serviceID, which was originally returned by the framework after registration. At any time an SCS can obtain a description of the SCFs registered by it through the describeService() method.



Figure 11 SCF Registration

8.2.2 Service Factory

The Service Factory interface allows the framework to get access to a manager interface of a network SCF. It is used during the signServiceAgreement, in order to return an SCF manager interface reference to the application. Each SCF has a manager interface that is the initial point of contact for the network SCF. E.g., the call control SCF uses the Call Manager interface.

Method **getServiceManager()**

This method returns an SCF manager interface reference for the specified application. Usually, but not necessarily, this involves the instantiation of a new SCF manager interface.

Direction Network to network (framework to service capability server)

Parameters **application**
Specifies the application for which the SCF manager interface is requested.

Returns**serviceManager**Specifies the SCF manager interface reference for the specified application.**Errors**

-

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 002R1

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
 list expected approval meeting # here ↑

for approval
 for information

strategic
 non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
 (at least one should be marked with an X)

Source: Ericsson, Nokia, Siemens **Date:** 22.5.2000

Subject: Editorial changes and improvements

Work item: VHE/OSA

Category: <small>(only one category shall be marked with an X)</small>	F Correction	<input checked="" type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input type="checkbox"/>		Release 98	<input type="checkbox"/>
D Editorial modification	<input type="checkbox"/>	Release 99	<input checked="" type="checkbox"/>		
			Release 00	<input type="checkbox"/>	

Reason for change: Besides editorial changes, which help the readability of the specification, this CR proposes a set of improvements, which can be divided in two categories:

- Terminology improvements: the UML and CORBA –compliant term *interface* is used instead of *interface class*; the term *API* is now used to qualify OSA; the terms *client* and *client application*, which were sometimes used in a wrong context, have been removed and replaced by the term *application*; the term *operation* was replaced by *method* where appropriate.
- SCF, methods and parameters description improvements: more accurate descriptions are provided when needed.

Clauses affected: Modifications are spread over the whole specification

Other specs affected:	Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
	Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
	MS test specifications	<input type="checkbox"/>	→ List of CRs:	
	BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
	O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



1 Scope

This document specifies the stage 2 of the Virtual Home Environment and Open Service Architecture.

Virtual Home Environment (VHE) is defined as a concept for personal service environment (PSE) portability across network boundaries and between terminals. The concept of the VHE is such that users are consistently presented with the same personalised features, User Interface customisation and services in whatever network and whatever terminal (within the capabilities of the terminal and the network), wherever the user may be located. For Release 99, e.g. CAMEL, MExE and SAT are considered the mechanisms supporting the VHE concept.

The Open Service Architecture (OSA) defines an architecture that enables operator and third party applications to make use of network functionality through an open standardised [interfaceAPI](#) (the OSA [InterfaceAPI](#)). OSA provides the glue between applications and service capabilities provided by the network. In this way applications become independent from the underlying network technology. The applications constitute the top level of the Open Service Architecture (OSA). This level is connected to the Service Capability Servers (SCSs) via the OSA [interfaceAPI](#). The SCSs map the OSA [interfaceAPI](#) onto the underlying telecom specific protocols (e.g. MAP, CAP etc.) and are therefore hiding the network complexity from the applications.

Applications can be network/server centric applications or terminal centric applications. Terminal centric applications reside in the Mobile Station (MS). Examples are MExE and SAT applications. Network/server centric applications are outside the core network and make use of service capability features offered through the OSA [interfaceAPI](#). (Note that applications may belong to the network operator domain although running outside the core network. Outside the core network means that the applications are executed in Application Servers that are physically separated from the core network entities).

2 References

References may be made to:

- a) Specific versions of publications (identified by date of publication, edition number, version number, etc.), in which case, subsequent revisions to the referenced document do not apply; or
- b) All versions up to and including the identified version (identified by "up to and including" before the version identity); or
- c) All versions subsequent to and including the identified version (identified by "onwards" following the version identity); or
- d) Publications without mention of a specific version, in which case the latest version applies.

A non-specific reference to an ETS shall also be taken to refer to later versions published as an EN with the same number.

2.1 Normative references

- [1] GSM 01.04 (ETR 350): "Digital cellular telecommunication system (Phase 2+); Abbreviations and acronyms"
- [2] GSM 02.57: "Digital cellular telecommunication system (Phase 2+); Mobile Station Application Execution Environment (MExE); Service description"
- [3] [UMTS3G](#) TS 23.057: "Mobile Station Application Execution Environment (MExE); Functional description - Stage2"
- [4] [UMTS3G](#) TS 22.078: "Customised Applications for Mobile network Enhanced Logic (CAMEL) (Phase3); Service description - Stage 1"

- [5] [UMTS3G](#) TS 23.078: "Customised Applications for Mobile network Enhanced Logic (CAMEL) (Phase3); Functional description - Stage 2"
- [6] GSM 11.14: "Digital cellular telecommunication system (Phase 2+); Specification of the SIM Application Toolkit for the Subscriber Identity Module - Mobile Equipment; (SIM - ME) interface"
- [7] [UMTS3G](#) TS 22.101: "Universal Mobile Telecommunications System (UMTS); Service Aspects; Service Principles"
- [8] [UMTS3G](#) TS 22.105: "Universal Mobile Telecommunications System (UMTS); Services and Service Capabilities"
- [9] [UMTS3G](#) TS 22.121: "Universal Mobile Telecommunications System (UMTS); Virtual Home Environment"
- [10] 3GPP TR 22.905: "3rd Generation Partnership Project; Technical Specification Group Services and System Aspects; Vocabulary for 3GPP Specifications"
- [11] IETF PPP Authentication Protocols - Challenge Handshake Authentication Protocol [RFC 1994, August 1996]
- [12] World Wide Web Consortium Composite Capability/Preference Profiles (CC/PP): A user side framework for content negotiation (<http://www.w3.org>)
- [13] Wireless Application Protocol, User Agent Profile Specification (<http://www.wapforum.org/>)
- [14] [The Object Management Group, The Complete CORBA/IIOP 2.3.1 Specification, OMG document formal/99-10-07 \(<http://www.omg.org/corba/corbaiiop.html>\)](#)

2.2 Informative references

- [1] [UMTS3GPP](#) TR 22.970: "Universal Mobile Telecommunications System (UMTS); Virtual Home Environment"

~~<Editor's note: some references may have to be aligned with their official title, e.g. 'UMTS' documents>~~

3 Definitions and abbreviations

3.1 Definitions

For the purposes of this TS, the following definitions apply:

Applications: software components providing services to end-users by utilising service capability features.

HE-VASP: see [9]

Home Environment: responsible for overall provision of services to users.

Interface: listing and semantics of the methods and attributes provided by an object that belongs to a Service Capability Feature.

Local Service: see [9]

OSA [InterfaceAPI](#): Standardised [InterfaceAPI](#) used by applications to access service capability features.

Personal Service Environment: contains personalised information defining how subscribed services are provided and presented towards the user. The Personal Service Environment is defined in terms of one or more User Profiles.

Service Capabilities: see [9]

Service Capability Feature: see [9]

Service Capability Server: Functional Entity providing OSA interfaces towards an application.

Services: see [9]

User Interface Profile: see [9]

User Profile: see [9]

User Services Profile: see [9].

Value Added Service Provider see [9]

Virtual Home Environment: see [9].

Further UMTS related definitions are given in 3G TS 22.101 and 3G TR 22.905.

3.2 Abbreviations

For the purposes of this TS the following abbreviations apply:

<u>API</u>	<u>Application Programming Interface</u>
CAMEL	Customised Application For Mobile Network Enhanced Logic
CSE	Camel Service Environment
HE	Home Environment
HE-VASP	Home Environment Value Added Service Provider
HLR	Home Location Register
IDL	Interface Description Language
MAP	Mobile Application Part
ME	Mobile Equipment
MExE	Mobile Station (Application) Execution Environment
MS	Mobile Station
MSC	Mobile Switching Centre
OSA	Open Service Architecture
PLMN	Public Land Mobile Network
PSE	Personal Service Environment
SAT	SIM Application Tool-Kit
SCF	Service Capability Feature
<u>SCP</u>	<u>Service Control Point</u>
SCS	Service Capability Server
SIM	Subscriber Identity Module USIM User Service Identity Module
VASP	Value Added Service Provider
VHE	Virtual Home Environment
WGW	WAP Gateway
WPP	WAP Push Proxy

Further GSM related abbreviations are given in GSM 01.04. Further UMTS related abbreviations are given in 3G TR 22.905.

4 Virtual Home Environment

The Virtual Home Environment (VHE) is an important portability concept of the 3G mobile systems. It enables end users to bring with them their personal service environment whilst roaming between networks, and also being independent of terminal used.

The Personal Service Environment (PSE) describes how the user wishes to manage and interact with her communication services. It is a combination of a list of subscribed to services, service preferences and terminal interface preferences. PSE also encompasses the user management of multiple subscriptions, e.g. business and private, multiple terminal types and location preferences. The PSE is defined in terms of one or more User Profiles.

The user profiles consist of two kinds of information:

- Interface related information (User Interface Profile) and,
- Service related information (User Services profile).

Please see TS22.121 [9] for more details.

5 Open Service Architecture

In order to implement not known end user services/applications today, a highly flexible Open Service Architecture (OSA) is required. The Open Service Architecture (OSA) is the architecture enabling applications to make use of network capabilities. The applications will access the network through the OSA [interfaceAPI](#) that is specified in this Technical Specification.

Network functionality offered to applications is defined as a set of Service Capability Features (SCFs) in the OSA [interfaceAPI](#), which are supported by different Service Capability Servers (SCS). These SCFs provide access to the network capabilities on which the application developers can rely when designing new applications (or enhancements/variants of already existing ones). The different features of the different SCSs can be combined as appropriate. The exact addressing (parameters, type and error values) of these features is described in stage 3 descriptions. These [interface](#)-descriptions (defined using [OMG CORBA Interface Description Language™](#)) are open and accessible to application developers, who can design services in any programming language. ~~The service logic is executed towards the OSA interfaces,~~ while the underlying core network functions use their specific protocols.

The aim of OSA is to provide an extendible and scalable architecture that allows for inclusion of new service capability features and SCSs in future releases of UMTS with a minimum impact on the applications using the OSA [interfaceAPI](#).

The standardised OSA [interfaceAPI](#) shall be secure, it is independent of vendor specific solutions and independent of programming languages, operating systems etc used in the service capabilities. Furthermore, the OSA [interfaceAPI](#) is independent of the location within the home environment where service capabilities are implemented and independent of supported server capabilities in the network.

To make it possible for application developers to rapidly design new and innovative applications, an architecture with open interfaces is imperative. By using object-oriented techniques, like CORBA, it is possible to use different operating systems and programming languages in application servers and service capability servers. ~~The different servers inter-work via the OSA interfaces.~~ The service capability servers serve as gateways between the network entities and the applications.

The OSA API is ~~an application layer interface, which is~~ based on lower layers using main stream information technology and protocols. The middleware (e.g. CORBA) and lower layer protocols (e.g. IP) should provide security mechanisms to encrypt data (e.g. IP sec).

5.1 Overview of the Open Service Architecture

The Open Service Architecture consists of three parts:

- **Applications**, e.g. VPN, conferencing, location based applications. These applications are implemented in one or more Application Servers;
- **Framework**, providing applications with basic mechanisms that enable them to make use of the service capabilities in the network. Examples of framework service capability features are Authentication and Discovery. Before an application can use the network functionality made available through ~~the~~ [Service Capability Features Servers](#), authentication between the application and framework is needed. After authentication, the discovery service capability feature enables the application to find out which network service capability features are provided by the Service Capability Servers. The network service capability features are accessed by the

methods defined in the OSA [interface classes/interfaces](#).

- **Service Capability Servers**, providing the applications with service capability features, which are abstractions from underlying network functionality. Examples of service capability features offered by the Service Capability Servers are Call Control and User Location. Similar service capability features may possibly be provided by more than one Service Capability Server. For example, Call Control functionality might be provided by SCSs on top of CAMEL and MExE.

The OSA service capability features are specified in terms of a number of [interface classes/interfaces](#) and their methods. The [interface classes/interfaces](#) are divided into two groups:

- framework [interface classes/interfaces](#), describing the methods on the framework
- network [interface classes/interfaces](#), describing the methods on the service capability servers.

The [interface classes/interfaces](#) are further divided into methods. For example, the Call Manager [interface class/interface](#) might contain a method to create a call (which realises one of the Service capability features ‘Initiate and create session’ as specified in [9]).

Note that the CAMEL Service Environment does not provide the service logic execution environment for applications using the OSA [interface API](#), since these applications are executed in Application Servers.




Figure 1 Overview of Open Service Architecture

This specification, together with the associated stage 3 specification, defines the OSA [interface API](#). OSA does not mandate any specific platform or programming language.

The Service Capability Servers that **provide/implement** the OSA [interface classes/interfaces](#) are functional entities that can be distributed across one or more physical nodes. For example, the User Location [interface classes/interfaces](#) and Call Control [interface classes/interfaces](#) might be implemented on a single physical entity or distributed across different physical entities. Furthermore, a service capability server can be implemented on the same physical node as a network functional entity or in a separate physical node. For example, Call Control [interface classes/interfaces](#) might be implemented on the same physical entity as the CAMEL protocol stack (i.e. in the [CSE/SCP](#)) or on a different physical entity.

Several options exist:

Option 1

The OSA ~~interface classes~~ interfaces are implemented in one or more physical entity, but separate from the physical network entities. Figure 2 shows the case where the OSA ~~interface classes~~ interfaces are implemented in one physical entity, called “gateway” in the figure. Figure 3 shows the case where the SCSs are distributed across several ‘gateways’.




Figure 2 SCSs and network functional entities implemented in separate physical entities




Figure 3 SCSs and network functional entities implemented in separate physical entities, SCSs distributed across several ‘gateways’.

Option 2

The OSA ~~interface classes~~ interfaces are implemented in the same physical entities as the traditional network entities (e.g. HLR, CSE), see figure 4.




Figure 4 SCSs and network functional entities implemented in same physical entities

Option 3

Option 3 is the combination of option 1 and option 2, i.e. a hybrid solution.




Figure 5 Hybrid implementation (combination of option 1 and 2)

It shall be noted that in all cases there is only one framework. This framework may reside within one of the physical entities containing an SCS or in a separate physical entity.

From the application point of view, it shall make no difference which implementation option is chosen, i.e. in all cases the same network functionality is perceived by the application. The applications shall always be provided with the same set of interface classes interfaces and a common access to framework and service capability feature interfaces. It is the

framework that will provide the applications with an overview of available service capability features and how to make use of them.

5.2 Basic mechanisms in the Open Service Architecture

This [section subclause](#) explains which basic mechanisms are executed in OSA prior to offering and activating applications.

Some of the mechanisms are applied only once (e.g. establishment of service agreement), others are applied each time a user subscription is made to an application (e.g. enabling the call attempt event for a new user).

Basic mechanisms between Application and Framework:

- **Authentication:** Once an off-line service agreement exists, the application can access the authentication interface. The authentication model of OSA is a peer-to-peer model. The application must authenticate the framework and vice versa. The application must be authenticated before it is allowed to use any other OSA interface.
- **Authorisation:** Authorisation is distinguished from authentication in that authorisation is the action of determining what a previously authenticated application is allowed to do. Authentication must precede authorisation. Once authenticated, an application is authorised to access certain service capability features.
- **Discovery of framework and network service capability features.** After successful authentication, applications can obtain available framework [interface classes/interfaces](#) and use the discovery interface to obtain information on authorised network service capability features. The Discovery interface can be used at any time after successful authentication.
- **Establishment of service agreement.** Before any application can interact with a network service capability feature, a service agreement must be established. A service agreement may consist of an off-line (e.g. by physically [exchanging documents/passing messages](#)) and an on-line part. The application has to sign the on-line part of the service agreement before it is allowed to access any network service capability feature.
- **Access to network service capability features:** The framework must provide access control functions to authorise the access to service capability features or service data for any API method from an [application-client](#), with the specified security level, context, domain, etc.

Basic mechanism between Framework and Service Capability Server:

- **Registering of network service capability features.** SCFs offered by a Service Capability Server can be registered at the Framework. In this way the Framework can inform the Applications upon request about available service capability features (Discovery). This mechanism is in general applied when installing or upgrading a Service Capability Server.

~~<editor's note: this mechanism is considered as of lower priority than other parts of OSA for R'99>~~

Basic mechanisms between Application Server and Service Capability Server:

- **Request of event notifications.** This mechanism is applied when a user has subscribed to an application and that application needs to be invoked upon receipt of events from the network related to the user. For example, when a user subscribes to an [incoming call](#) screening application, the application needs to be invoked when the user [receives/makes](#) a call. It will therefore request to be notified when a call setup is performed, with the user number as Called Party Number.

5.3 Handling of end-user related security

Once OSA basic mechanisms have ensured that an application has been authenticated and authorised to use network service capability features, it is important to also handle end-user related security aspects. These aspects consist of the following.

- **End-user authorisation to applications**, limiting the access of end-users to the applications they are subscribed to.
- **Application authorisation to end-users**, limiting the usage by applications of network capabilities to authorised (i.e. subscribed) end-users.
- **End-user's privacy**, allowing the user to set privacy options.

These aspects are addressed in the following [subsections](#).

5.3.1 End-user authorisation to applications

An end-user is authorised to use an application only when he or she is subscribed to it.

In the case where the end-user has subscribed to the application before the application accesses the network SCFs, then the subscription is part of the Service Level Agreement signed between the HE and the HE-VASP.

After the application has been granted access to network SCFs, subscriptions are controlled by the Home Environment. Depending on the identity of an authenticated and authorised end-user, the Home Environment may use any relevant policy to define and possibly restrict the list of services to which a particular end-user can subscribe. At any time, the Home Environment may decide, unilaterally or after agreement with the HE-VASP, to cancel a particular subscription.

Service subscription and activation information need to be shared between the Home Environment and the HE-VASP, so that the HE-VASP knows which end-users are entitled to use its services. Appropriate online and/or offline synchronisation mechanisms (e.g. SLA re-negotiation) can be used between the HE and the HE-VASP, which are not specified in OSA release 99.

End-to-end interaction between a subscribed end-user and an application may require the usage of appropriate authentication and authorisation mechanisms between the two, which are independent from the OSA API, and therefore not in the scope of OSA standardisation.

5.3.2 Application authorisation to end-users

The Home Environment is entitled to provide service capabilities to an application with regard to a specific end-user if the following conditions are met:

- 1) The end-user is subscribed to the application
- 2) The end-user has activated the application
- 3) The usage of this network service capability does not violate the end-users privacy settings (see next [section](#)).

The service capability server ensures that the above conditions are met whenever an application attempts to use a service capability feature for a given end-user, and to respond to the application accordingly, possibly using relevant error parameters (USER_NOT_SUBSCRIBED, APPLICATION_NOT_ACTIVATED, USER_PRIVACY_VIOLATION). The mechanism used by the SCS to ensure this is internal to the HE (e.g. access to user profile) and is not standardised in OSA release 99.

5.3.3 End-user's privacy

The Home Environment may permit an end-user to set privacy options. For instance, it may permit the end-user to decide whether his or her location may be provided to 3rd parties, or whether he or she accepts information to be pushed to his or her terminal. Such privacy settings may have an impact on the ability of the network to provide service capability features to applications (e.g. user location, user interaction). Thus, even if an application is authorised to use an SCF and the end-user is subscribed to this application and this application is activated, privacy settings may still prevent the HE from fulfilling an application request.

The service capability server ensures that a given application request does not violate an end-users privacy settings or that the application has relevant privileges to override them (e.g. for emergency reasons). The mechanism used by the SCS to ensure this is internal to the HE and is not standardised in OSA release 99.

5.4 Base ~~interface classes~~interfaces

The base ~~interface classes~~interfaces described in this sub-clause are provided for completeness of the documentation.
~~With object oriented design all classes are based on a base class.~~

5.4.1 Base ~~Interface Class~~Interface

This ~~interface class~~ is the foundation of ~~the~~-all the other interfaces and shall be inherited by all of the~~other interface classes~~. It does not contain any method.

Name Base_Interface

Method

Parameters

Returns

Errors

5.4.2 Base Service ~~Interface class~~Interface

This ~~interface class~~ provides the base for all ~~service interface classes~~interfaces described in the following ~~chapter clauses~~. It allows an application to set an interface reference to be used by the OSA interfaces for requests and asynchronous responses to the application. For example, when an application wants to be notified upon the receipt of the "called party busy" event, the Service Capability Server must know where to send the notification. This reference can be provided by the application with the setCallback method across the OSA ~~interface API~~.

Name Base_Service_Interface

Method **setCallback()**

This method specifies the reference address of the callback interface that an SCF uses to invoke methods on the application.

Direction Application to Framework

Parameters **appInterface**

Specifies a reference to the application interface, which is used for callbacks.

Returns

Errors

6 Framework service capability features

Note: when the direction of a method in an interface is "application to network", this means that the method is invoked from the application to an SCS residing on the network side of the OSA API.

6.1 Trust and Security Management SCFs

The Trust and Security Management service capability features provide:

- The first point of contact for an ~~an~~-client application to access a Home Environment;

- The authentication operationmethods for the client-application and Home Environment to perform an authentication protocol;
- The client-application with the ability to select a network service capability feature to make use of;
- The client-application with a portal to access other framework service capability features.

The process by which the client-application accesses the Home Environment has been separated into 3 stages, each supported by a different framework service capability feature:

1. Initial Contact with the framework
2. Authentication to the framework
3. Access to framework and network service capability features

6.1.1 Initial Contact

The client-application gains a reference to the Initial Contact SCF for the Home Environment that they wish to access. This may be gained through a URL, a Naming or Trading Service or an equivalent servicen-Application Support Broker, a *stringified* object reference, etc. At this stage, the applicationclient has no guarantee that this is a reference to the Home Environment.

The client-application uses this referenceSCF to initiate the authentication process with the Home Environment.

Initial ContactThe Initial SCF supports the initiateAuthentication operationmethod to allow the authentication process to take place (using the Authentication SCF defined in sectionsclause 6.1.2). This operationmethod must be the first invoked by the client-application. Invocations of other operationmethods will fail until authentication has been successfully completed.

Once the clientapplication -has authenticated with the provider, itthe-client can gain access to other framework and network service capability features. This is done by invoking the requestAccess method, by which the client-application requests a certain type of access service capability feature. The OSA Access service capability feature is defined in sectionsclause 6.1.3.

The Initial Contact framework SCF is defined by a unique interface-classinterface, consisting of the following methods.

Method **initiateAuthentication()**

The client-application uses this method to initiate the authentication process.

Direction Application to Framework

Parameters **clientAppID**

This is an identifier for the client-application. It is used to identify the applicationclient to the framework, (see authenticate() on Authentication). If the clientAppID cannot be found by the framework, an error code is returned by the framework. The value of the parameter fwAuthInterface is NULL in this case.

authType

This identifies the type of authentication mechanism requested by the clientapplication. It provides operators and HE-VASPsclients with the opportunity to use an alternative to the OSA Authentication interface, e.g. CORBA Security.

appAuthInterface

This provides the reference for the framework to call the authentication interface of the **client** application.

Returns**fwAuthInterface**

This provides the reference for the **client**-application to call the authentication SCF of the framework.

Errors**Method****requestAccess ()**

Once **clientapplication** -and framework are authenticated, the **formerclientapplication** invokes the requestAccess **operationmethod** on the Initial **Contact** SCF. This allows the **client**-application to request the type of access **itthey** requires. If **itthey** requests **OSA_ACCESS**, then a reference to the OSA Access interface is returned. (Home Environments can define their own access interfaces to satisfy **clientapplication** -requirements for different types of access.)

Direction

Application to network

Parameters**accessType**

This identifies the type of access SCF requested by the **client**-application.

appAccessInterface

This provides the reference for the framework to call the access interface of the **client**-application.

Returns**fwAccessInterface**

This provides the reference for the **applicationclient** to call the access SCF of the framework.

Errors**INVALID_AUTHENTICATION**

The application is not authenticated.

6.1.2 Authentication

Once the **client**-application has made initial contact with the Home Environment, authentication of the **client**-application and Home Environment may be required.

The API supports multiple authentication techniques. The procedure used to select an appropriate technique for a given situation is described below. The authentication mechanisms may be supported by cryptographic processes to provide confidentiality, and by digital signatures to ensure integrity. The inclusion of cryptographic processes and digital signatures in the authentication procedure depends on the type of authentication technique selected. In some cases strong authentication may need to be enforced by the Home Environment to prevent misuse of resources. In addition it may be necessary to define the minimum encryption key length that can be used to ensure a high degree of confidentiality.

The **client**-application must authenticate with the framework before it is able to use any of the other interfaces supported by the framework. Invocations on other interfaces will fail until authentication has been successfully completed.

1. The **client**-application calls initiateAuthentication on the Home Environment's framework Initial interface. This allows the **applicationclient** to specify the type of authentication process. This authentication process may be specific to the Home Environment, or the implementation technology used. The initiateAuthentication **operationmethod** can be used to specify the specific process, (e.g. CORBA security). OSA defines a generic authentication service capability feature (Authentication), which can be used to perform the authentication process.

The initiateAuthentication [operationmethod](#) allows the [client](#)-application to pass a reference to its own authentication interface to the Framework, and receive a reference to the Authentication interface supported by the framework, in return.

2. The [client](#)-application invokes the selectAuthMethod on the framework's Authentication SCF. This includes the authentication capabilities of the [client](#)-application. The framework then chooses an authentication method based on the authentication capabilities of the [client](#)-application and the framework. If the [applicationclient](#) is capable of handling more than one authentication method, then the framework chooses one option, defined in the prescribedMethod parameter. In some instances, the authentication capability of the [client](#)-application may not fulfil the demands of the framework, in which case, the authentication will fail.
3. The [client](#)-application and framework interact to authenticate each other. Depending on the method prescribed, this procedure may consist of a number of messages e.g. a challenge/ response protocol. This authentication protocol is performed using the authenticate [operationmethod](#) on the Authentication interface. Depending on the authentication method selected, the protocol may require invocations on the Authentication SCF supported by the framework; or on the [client](#)-application counterpart; or on both.

The Authentication framework SCF is defined by a single [interface classinterface](#), consisting of the following methods.

Method **selectAuthMethod ()**

The [client](#)-application uses this method to initiate the authentication process. The mechanism returned by the framework is the mechanism it prefers. This should be within capability of the [client](#) application. If a mechanism that is acceptable to the framework within the capability of the [client](#) application cannot be found, the framework returns an error code (INVALID_AUTH_CAPABILITY).

Direction Application to network

Parameters **authCapability**

This is the means by which the authentication mechanisms supported by the [applicationclient](#) are conveyed to the framework.

Returns **prescribedMethod**

This is returned by the framework to indicate the mechanism it prefers for the authentication process. If the value of the prescribedMethod returned by the framework is not understood by the [client](#) application, it is considered a [fatalcatastrophic](#) error and the [client](#)-application must abort.

Errors **INVALID AUTH CAPABILITY**

No acceptable authentication mechanism could be found by the framework.

Method **authenticate ()** (*application to network*)

This method is used by the [applicationclient](#) to authenticate the framework using the mechanism indicated in prescribed Method. The framework must respond with the correct responses to the challenges presented by the [client application](#). The clientAppID received in the initiateAuthentication() can be used by the framework to reference the correct public key for the [client](#)-application (the key management system is currently outside of the scope of the OSA specification). The number of [interactionsexchanges](#) and the order of the [interactionsexchanges](#) is dependent on the prescribedMethod.

Direction Application to network

Parameters **prescribedMethod**

This parameter contains the method that the framework has specified as acceptable for

authentication (see `selectAuthMethod`).

challenge

The challenge presented by the `client`-application to be responded to by the framework. The challenge mechanism used will be in accordance with the IETF *PPP Authentication Protocols - Challenge Handshake Authentication Protocol* [RFC 1994, August1996]. The challenge will be encrypted with the mechanism prescribed by `selectAuthMethod()`.

Returns

response

This is the response of the framework to the challenge of the `client`-application in the current sequence. The response will be based on the challenge data, decrypted with the mechanism prescribed by `selectAuthMethod()`.

Errors

Method

authenticate() (*network to application*)

This method is used by the framework to authenticate the `client`-application using the mechanism indicated in `prescribedMethod`. The `client`-application must respond with the correct responses to the challenges presented by the framework. The number of `interactionsexchanges` and the order of the `interactionsexchanges` is dependant on the `prescribedMethod`. (These may be interleaved with `authenticate()` calls by the `client`-application on the Authentication interface. This is defined by the `prescribedMethod`.)

Direction

Network to application

Parameters

prescribedMethod

This parameter contains the agreed method for authentication (see `selectAuthMethod` on the Authentication interface.)

challenge

The challenge presented by the framework to be responded to by the `client`-application. The challenge mechanism used will be in accordance with the IETF *PPP Authentication Protocols - Challenge Handshake Authentication Protocol* [RFC 1994, August1996]. The challenge will be encrypted with the mechanism prescribed by `selectAuthMethod()`.

Returns

response

This is the response of the `client`-application to the challenge of the framework in the current sequence. The response will be based on the challenge data, decrypted with the mechanism prescribed by `selectAuthMethod()`.

Errors

INVALID_AUTHENTICATION

The application could not be authenticated.

Method

abortAuthentication() (*application to network*)

The `client`-application uses this method to abort the authentication process. This method is invoked if the `applicationclient` no longer wishes to continue the authentication process, (e.g. if the framework responds incorrectly to a challenge.) If this method has been invoked, calls to the `requestAccessoperationmethod` on Initial `Contact` will return an error code (INVALID_AUTHENTICATION) until the `applicationclient` has been properly authenticated.

Direction

Application to network

Parameters

Returns**Errors****Method** `abortAuthentication()` (*network to application*)

The framework uses this method to abort the authentication process. This method is invoked if the framework wishes to abort the authentication process, (e.g. if the `client` application responds incorrectly to a challenge.) If this method has been invoked, calls to the `requestAccess` `operationmethod` on Initial will return an error code (INVALID_AUTHENTICATION), until the `applicationclient` has been properly authenticated.

Direction Network to application

Parameters**Returns****Errors**

6.1.3 OSA Access

During an authenticated session accessing the Framework, the `client` application will be able to select and access an instance of a framework or network service capability feature.

Access to framework SCFs is gained by invoking the `obtainInterface`, or `obtainInterfaceWithCallback` `operationmethods`. The latter is used when a callback reference is supplied to the framework. For example, a network SCF discovery `interface-classinterface` reference is returned when invoking `obtainInterface` with “discovery” as the SCF name.

In order to use network SCFs, the `applicationclient` must first be authorised to do so by establishing a service agreement with the Home Environment. The `client` application uses the discovery SCF to retrieve the ID of the network SCF they wish to use. They may then use the `accessCheck` `operationmethod` to check that they are authorised to use the network SCF. The `selectService` `operationmethod` is used to tell the Home Environment that the `client` application wishes to use the network SCF. The `signServiceAgreement` `operationmethod` is used to digitally sign the agreement, and provide non-repudiation for both parties in agreeing that the SCF would be available for use.

Establishing a service agreement is a business level transaction, which requires the HE-VASP that owns the `client` application to agree terms for the use of an SCF with the Home Environment. Service agreements can be reached using either off-line or on-line mechanisms. Off-line agreements will be reached outside of the scope of OSA interactions, and so are not described here. However, `client` applications can make use of service agreements that are made off-line. Some Home Environments may only offer off-line mechanisms to reach service agreements.

After a service agreement has been established between the `applicationclient` and the Home Environment domains, the `client` application will be able to make use of this agreement to access the network SCF.

The `accessCheck` `operationmethod` allows the `client` application to check whether it has permission to access (read, write, etc) to a specified SCF, and specific SCF features. The `client` application defines the security domain and context of access to the SCF. The access control policy is based on a number of conditions, events and permissions that determine whether the `client` application is authorised to access the SCF/feature.

The `accessCheck` `operationmethod` is optional, in that can be called by the `client` application to check that it has permission to use specific SCF features, before starting an SCF instance. It is not compulsory for the `client` application to make this check before selecting a network SCF and signing a service agreement to use an instance of the SCF. If the `accessCheck` `operationmethod` confirms that the `client` application has permission to use a specific SCF feature, then this feature should be available to the `client` application when using the SCF instance. The Home Environment may include the results of the `accessCheck` as part of the service agreement, that is signed before using an SCF instance, thereby assuring the `client` application that the SCF features will be available.

The selectService [operationmethod](#) is used to identify the SCF that the [client](#)-application wishes to use. A list of service properties initialises the SCF, and an SCF token is returned. The [client](#)-application and Home Environment must sign a copy of the service agreement to confirm the use of the SCF. The framework invokes signServiceAgreement [operationmethod](#) on the [client](#)-applications's Access callback interface with the service agreement text to be signed. The [client](#)-application uses its digital signature key to sign the agreement text, and return the signed text to the framework. The [client](#)-application then calls the signServiceAgreement [operationmethod](#) on the OSA Access SCF. The framework signs the agreement text, retrieves a reference to a network manager interface for the selected SCF (using a mechanism not specified in release 99), and returns this reference to the [client](#)-application.

The OSA Access framework SCF is defined by a single [interface-classinterface](#), which consists of the following methods.

Method **obtainInterface ()**

~~This method is used to obtain other framework SCFs.~~ The [client](#)-application uses this method to obtain interface references to other framework SCFs ([e.g. discovery, load manager](#)). (The obtainInterfacesWithCallback method should be used if the [client](#)-application is required to supply a callback interface to the framework.)

Direction Application to network

Parameters **interfaceName**

The name of the framework SCF to which a reference to the interface is requested.

Returns **fwInterface**

This is the reference to the SCF interface requested.

Errors **INVALID_INTERFACE_NAME**

Returned if the interfaceName is invalid.

Method **obtainInterfaceWithCallback ()**

~~This method is used to obtain other framework SCFs.~~ The [client](#)-application uses this method to obtain interface references to other framework SCFs ([e.g. discovery, load manager](#)), when they are required to supply a callback interface to the framework. (The obtainInterface method should be used when no callback interface needs to be supplied.)

Direction Application to network

Parameters **interfaceName**

The name of the framework SCF to which a reference to the interface is requested.

appInterface

This is the reference to the [client](#)-application interface, which is used for callbacks. If an application interface is not needed, then this method should not be used. (The obtainInterface method should be used when no callback interface needs to be supplied.)

Returns **fwInterface**

This is the reference to the SCF requested.

Errors **INVALID_INTERFACE_NAME**

Returned if the interfaceName is invalid.

Method **accessCheck ()**

This method may be used by the **client** application to check whether it has been granted permission to access the specified SCF. The response is used to indicate whether the request for access has been granted or denied and if granted the level of trust that will be applied. ~~The securityModelID and the relevant securityLevel are available as part of the registration data for the SCF.~~

~~securityModelID:~~

~~The identity of the specific Security Model that is to be used to define a set of appropriate policies for the SCF that can be used by the framework to determine access rights. The model may include: blanket permission; session permission or one shot permission. A number of security models will be stored by the framework, and referenced by the access control module, according to the security model identifier of the SCF.~~

~~securityLevel:~~

~~The trust level required by the SCF for granting access. The Security Level is used by the framework's access control module when it checks for access rights.~~

Direction Application to network

Parameters **securityContext**

A context is a group of security relevant attributes that may have an influence on the result of the accessCheck request.

securityDomain

The security domain in which the **client** application is operating may influence the access control decisions and the specific set of features that the requestor is entitled to use.

group

A group can be used to define the access rights associated with all **applicationselements** that belong to that group. This simplifies the administration of access rights.

serviceAccessTypes

These are defined by the specific Security Model in use but are expected to include: Create, Read, Update, Delete as well as those specific to SCFs.

Returns **serviceAccessControl**

This is a structure containing: ~~the access control policy information controlling access to the SCF, and the trustLevel that the Home Environment has assigned to the client application. It consists of~~

- policy: indicates whether access has been granted or denied. If granted then the parameter trustLevel must also have a value.
- trustLevel: The trustLevel parameter indicates the trust level that the Home Environment has assigned to the **client** application.

Errors**Method** **selectService ()**

This method is used by the **client** application to identify the network SCF that the **client** application

wishes to use.

Direction Application to network

Parameters **serviceID**
This identifies the SCF required.

serviceProperties

This is a list of the properties that the SCF should support. These properties (names and values) are used to initialise the SCF instance for use by the *client* application.

Returns **serviceToken**
This is a free format text token returned by the framework, which can be signed as part of a service agreement. This will contain operator specific information relating to the service level agreement. The serviceToken has a limited lifetime. If the lifetime of the serviceToken expires, a method accepting the serviceToken will return an error code (INVALID_Service_TOKEN). Service Tokens will automatically expire if the *application* or framework invokes the endAccess method on the other's corresponding access interface.

Errors **INVALID_SERVICE_ID**
Returned if the serviceID is not recognised by the framework

INVALID_SERVICE_PROPERTY
Returned if a property is not recognised by the framework

Method **signServiceAgreement ()** (*application to network*)

This method is used by the *client* application to request that the framework sign an agreement on the SCF, which allows the *client* application to use the SCF. If the framework agrees, both parties sign the service agreement, and a reference to the manager interface of the SCF is returned to the *client* application.

Direction Application to network

Parameters **serviceToken**
This is the token returned by the framework in a call to the selectService() method. This token is used to identify the SCF instance requested by the *client* application.

agreementText
This is the agreement text that is to be signed by the framework using the private key of the framework.

signingAlgorithm
This is the algorithm used to compute the digital signature.

Returns **signatureAndServiceMgr**
This is a reference to a structure containing the digital signature of the framework for the service agreement, and a reference to the manager interface of the SCF:

- The digitalSignature is the signed version of a hash of the service token and agreement text given by the *client* application.
- The serviceMgrInterface is a reference to the manager interface for the selected SCF.

Errors **INVALID_SERVICE_TOKEN**

Returned if the serviceToken is not recognised by the framework

Method **signServiceAgreement ()** (*network to application*)

This method is used by the framework to request that the **client**-application sign an agreement on the SCF. It is called in response to the **client**-application calling the selectService() method on the Access SCF of the framework. The framework provides the service agreement text for the **client** application to sign. If the **client**-application agrees, it signs the service agreement, returning its digital signature to the framework.

Direction Network to application

Parameters **serviceToken**

This is the token returned by the framework in a call to the selectService() method. This token is used to identify the SCF instance to which this service agreement corresponds. (If the **client** application selects many SCFs, it can determine which selected SCF corresponds to the service agreement by matching the service token.)

agreementText

This is the agreement text that is to be signed by the **client**-application using the private key of the **client**-application.

signingAlgorithm

This is the algorithm used to compute the digital signature.

Returns **digitalSignature**

The digitalSignature is the signed version of a hash of the service token and agreement text given by the framework.

Errors

Method **terminateServiceAgreement ()** (*application to network*)

This method is used by the **client**-application to terminate a service agreement for the SCF.

Direction Application To Network

Parameters **serviceToken**

This is the token passed back from the framework in a previous selectService() method call. This token is used to identify the service agreement to be terminated.

terminationText

This is the termination text describes the reason for the termination of the service agreement.

digitalSignature

This is a signed version of a hash of the service token and the termination text. The signing algorithm used is the same as the signing algorithm given when the service agreement was signed using signServiceAgreement(). The framework uses this to check that the terminationText has been signed by the **applicationclient**. If a match is made, the service agreement is terminated, otherwise an error is returned.

Returns

Errors

Method `terminateServiceAgreement()` (network to application)

This method is used by the framework to terminate a service agreement for the SCF.

Direction Network to application

Parameters `serviceToken`

This is the token passed back from the framework in a previous `selectService()` method call. This token is used to identify the service agreement to be terminated.

`terminationText`

This is the termination text describes the reason for the termination of the service agreement.

`digitalSignature`

This is a signed version of a hash of the service token and the termination text. The signing algorithm used is the same as the signing algorithm given when the service agreement was signed using `signServiceAgreement()`. The framework uses this to confirm its identity to the `applicationClient`. The `applicationClient` can check that the `terminationText` has been signed by the framework.

Returns

Errors

Method `endAccess()`

The `endAccess` `operationmethod` is used to end the `client`-application's access session with the framework. The `applicationClient` requests that its access session be ended. After it is invoked, the `client`-application will no longer be authenticated with the framework. The `client`-application will not be able to use the references to any of the framework SCFs gained during the access session. Any calls to these SCF interfaces will fail.

Direction Application To Network

Parameters

Returns

Errors

Method `terminateAccess()`

The `terminateAccess` `operationmethod` is used to end the `client`-application's access session with the framework (e.g. this may be done if the framework believes the `client` application is masquerading as someone else. Using this `operationmethod` will force the `client` application to re-authenticate if it wishes to continue using the framework SCFs.)

After `terminateAccess()` is invoked, the `client`-application will no longer be authenticated with the framework. The `client`-application will not be able to use the references to any of the framework SCFs gained during the access session. Any calls to these interfaces will fail.

Direction Network to application

Parameter `terminationText`

s

This is the termination text describes the reason for the termination of the access session.

signingAlgorithm

This is the algorithm used to compute the digital signature.

digitalSignature

This is a signed version of a hash of the termination text. The framework uses this to confirm its identity to the [applicationClient](#). The [applicationClient](#) can check that the `terminationText` has been signed by the framework.

Returns

Errors

6.2 Discovery

The discovery SCF -consists of a single [interface-classinterface](#). Before a network SCF can be discovered, the [client](#) application must know what “types” of SCFs are supported by the Framework and what “properties” are applicable to each SCF type. The `listServiceType()` method returns a list of all “SCF types” that are currently supported by the framework and the “describeServiceType()” returns a description of each SCF type. The description of SCF type includes the “SCF-specific properties” that are applicable to each SCF type. Then the [client](#)-application can discover a specific set of registered SCFs that belong to a given type and possess the desired “property values”, using the “discoverService() method.

Once the HE-VASP finds out the desired set of SCFs supported by the network, it subscribes (a sub-set of) these SCFs using the Subscription framework SCF. The HE-VASP (or the [client](#)-applications in its domain) can find out the set of SCFs available to it (i.e., the SCFs that it can use) by invoking “listSubscriberServices()”.

The discovery SCF is invoked by the HE-VASP or [client](#)-applications. Its methods are described below.

Method **discoverService ()**

The `discoverService` [methodeperation](#) is the means by which an [client](#)-application is able to obtain the IDs of the SCFs that meet its requirements. The [client](#)-application passes in a list of desired properties to describe the SCF it is looking for, in the form attribute/value pairs for the properties. The [client](#)-application also specifies the maximum number of matched responses it is willing to accept. The framework must not return more matches than the specified maximum, but it is up to the discretion of the Framework implementation to choose to return less than the specified maximum. The `discoverService()` [operationmethod](#) returns a serviceID/Property pair list for those SCFs that match the desired property list that the [client](#)-application provided.

Direction Application to network

Parameters **serviceTypeName**

The “ServiceTypeName” parameter conveys the required SCF type. It is key to the central purpose of “SCF trading”. By stating an SCF type, the importer implies the SCF type and a domain of discourse for talking about properties of SCF.

The framework may return an SCF of a subtype of the “type” requested. An SCF sub-type can be described by the properties of its supertypes.

desiredPropertyList

The “desiredPropertyList” parameter is a list of property name and property value pairs of properties that the discovered set of SCFs should satisfy. These properties deal with the non-functional and non-computational aspects of the desired SCF. The property values in the desired property list must

be logically interpreted as “minimum”, “maximum”, etc. by the framework.

max

The “max” parameter states the maximum number of SCFs that are to be returned in the “ServiceList” result.

Returns

serviceList :

This parameter gives a list of matching SCFs. Each SCF is characterised by an SCF ID and a list of property name and property value pairs associated with the SCF.

Errors

ILLEGAL_SERVICE_TYPE

Returned if the string representation of the “type” does not obey the rules for SCF type identifiers

UNKNOWN_SERVICE_TYPE

Returned if the “type” is correct syntactically but is not recognised as an SCF type within the Framework

Method

listServiceTypes ()

This [operationmethod](#) returns the names of all SCF types which are in the repository. The details of the SCF types can then be obtained using the describeServiceType() method.

Direction

Application to network

Parameters

Returns

listTypes

The names of the requested SCF types.

Errors

Method

describeServiceType ()

This [operationmethod](#) lets the caller to obtain the details for a particular SCF type.

Direction

Application to network

Parameters

name

The name of the SCF type to be described

Returns

serviceTypeDescription

The description of the specified SCF type. The description provides information about:

- the property names associated with the SCF,
- the corresponding property value types,
- the corresponding property mode (mandatory or read only) associated with each SCF property,
- the names of the super types of this type, and
- whether the type is currently enabled or disabled.

Errors

ILLEGAL_SERVICE_TYPE

Returned of the string representation of the “type” does not obey the rules for SCF type identifiers

UNKNOWN_SERVICE_TYPE

Returned if the “type” is correct syntactically but is not recognised as an SCF type within the Framework

Method **listSubscribedServices ()**

Returns a list of SCFs so far subscribed by the HE-VASP. The HE-VASP (or the [client](#) applications in the HE-VASP domain) can obtain a list of subscribed SCFs that they are allowed to access.

Direction Application to network

Parameters

Returns **serviceIDList**

Returns a list of IDs of the SCFs subscribed by the HE-VASP.

Errors

6.3 Integrity Management SCFs

6.3.1 Load Manager

The Load Manager SCF permits to manage the load on both the application and network sides.

The framework API should allow the load to be distributed across multiple machines and across multiple component processes, according to a load balancing policy. The separation of the load balancing mechanism and load balancing policy ensures the flexibility of the load balancing functionality. The load balancing policy identifies what load balancing rules the framework should follow for the specific [client](#)-application. It might specify what action the framework should take as the congestion level changes. For example, some real-time critical applications will want to make sure continuous service is maintained, below a given congestion level, at all costs, whereas other applications will be satisfied with disconnecting and trying again later if the congestion level rises. Clearly, the load balancing policy is related to the QoS level to which the application is subscribed.

The Load Manager SCF consists of a single [interface-classinterface](#). Most methods are asynchronous, in that they [are one-way invocations](#). Consequently, they do not lock a thread into waiting whilst a transaction performs. In this way, the [application serverclient-machine](#) can handle many more calls, than one that uses synchronous message calls.

The load management [operationmethods](#) do not exchange callback interfaces as it is assumed that the [client](#)-application has supplied its Load Management callback interface at the time it obtains the Framework’s Load Manager SCF, by use of the `obtainInterfaceWithCallback` [operationmethod](#) on the OSA Access SCF.

Method **reportLoad()**

The [client](#)-application notifies the framework about its current load level (0,1, or 2) when the load level on the application has changed.

At **level 0** load, the application is performing within its load specifications (i.e. it is not congested or overloaded). At **level 1** load, the application is overloaded. At **level 2** load, the application is severely overloaded.

Direction Application to network

Parameters **requester**
Specifies the application interface for callbacks.

loadLevel
Specifies the load level for which the application reported.

Returns

Errors

Method **enableLoadControl()**

Upon detecting load condition change, (i.e. load level changing from 0 to 1, 0 to 2, 1 to 2 or 2 to 1, for the SCFs or framework which has been registered for load control), the framework enables load management activity at the ~~client~~ application based on the policy.

Direction Network to application

Parameter **loadStatistics**
s Specifies the new load statistics

Returns

Errors

Method **disableLoadControl()**

After load level of the framework or SCF which has been registered for load control moves back to normal, framework disables load control activity at the ~~client~~ application based on policy.

Direction Network to application

Parameters **ServiceIDs**
Specifies the framework and SCFs for which the load has changed to normal. The serviceIDs is null to specify the framework only.

Returns

Errors

Method **resumeNotification()**

Resume the notification from an application for its load status after the detection of load level change at the framework and the evaluation of the load balancing policy.

Direction Network to application

Parameters

Returns

Errors

Method **suspendNotification()**

Suspend the notification from an application for its load status after the detection of load level

change at the framework and the evaluation of the load balancing policy.

Direction Network to application

Parameters

Returns

Errors

Method **queryLoadReq ()**

The ~~client~~ application requests load statistic records for the framework and specified SCFs.

Direction Application to Network

Parameters **requester**

Specifies the application interface for callbacks.

serviceIDs

Specifies the framework, SCFs or applications for which the load statistics shall be reported. The serviceIDs is null for framework load statistics only.

timeInterval

Specifies the time interval within which the load statistics are generated.

Returns

Errors

Method **queryLoadRes ()**

Returns load statistics to the application which requested the information.

Direction Network to application

Parameters **loadStatistics**

Specifies the framework-supplied load statistics.

Returns

Errors

Method **queryLoadErr ()**

Returns an error code to the application that requested load statistics.

Direction Network to application

Parameters **loadStatisticsError**

Specifies the framework-supplied error code.

Returns

Errors

Method **queryAppLoadReq ()**

The framework requests for load statistic records produced by a specified application.

Direction Network to application

Parameters **serviceIDs**
Specifies the SCFs or applications for which the load statistics shall be reported.

timeInterval
Specifies the time interval within which the load statistics are generated.

Returns

Errors

Method **queryAppLoadRes ()**

Report load statistics back to the framework that requested the information.

Direction Application to network

Parameters **loadStatistics**
Specifies the load statistics in the application.

Returns

Errors

Method **queryAppLoadErr ()**

Return an error response to the framework that requested the application's load statistics information.

Direction Application to network

Parameters **loadStatisticsError**
Specifies the error code associated with the failed attempt to retrieve the application's load statistics.

Returns

Errors

Method **registerLoadController ()**

Register the ~~client~~-application for load management under various load conditions.

Direction Application to network

Parameters **requester**
Specifies the application interface for callbacks.

serviceIDs
Specifies the framework and SCFs to be registered for load control. To register for framework load control only, the `serviceIDs` is null.

Returns**Errors****Method** **unregisterLoadController ()**

Unregister the **client**-application for load management.

Direction Application to network

Parameters **requester**
Specifies the application interface for callbacks.

serviceIDs
Specifies the framework or SCFs to be unregistered for load control.

Returns**Errors****Method** **resumeNotification ()**

Resume load management notifications to the application for the framework and specified SCFs after their load condition changes.

Direction Application to network

Parameters **serviceIDs**
Specifies the framework and SCFs for which notifications are to be resumed. The **serviceIDs** is null to resume notifications for the framework only.

Returns**Errors****Method** **suspendNotification()**

Suspend load management notifications to the application for the framework and specified SCFs, while the application handles a temporary load condition.

Direction Application to network

Parameters **serviceIDs**
Specifies the framework and SCFs for which notifications are to be suspended. The **serviceIDs** is null to suspend notifications for the framework only.

Returns**Errors**

6.3.2 Fault Manager

This SCF is used by the application to inform the framework of events which affect the integrity of the framework and

SCFs, and to request information about the integrity of the system.

It consists of a single ~~interface class~~interface, with the following methods.

Method **activityTestReq ()**

This method may be used by the application to test that the framework or an SCF is ~~operation method~~al. On receipt of this request, the framework must carry out a test on the specified SCF or the framework itself to check that it is operating correctly and report the test result.

Direction Application to network

Parameters **activityTestID**

The identifier provided by the ~~client~~application to correlate the response (when it arrives) with this request.

svcID

This parameter identifies which SCF the ~~client~~application is requesting the activity test to be done for. A null value denotes that the activity test is being requested for the framework.

appID

This parameter identifies which ~~client~~application is requesting the activity test, and therefore which application to send the result to.

Returns

Errors

Method **activityTestRes ()**

The framework returns the result of the activity test in this method, along with a test identifier to allow correlation of result to request within the ~~client~~application.

Direction Network to application

Parameters **activityTestID**

The identifier provided by the ~~application client~~ (in the request), to correlate this response with the original request.

activityTestResult

The result of the activity test.

Returns

Errors

Method **appActivityTestReq ()**

This method is invoked by the framework to request that the ~~client~~application carries out an activity test to check that it is operating correctly.

Direction Network to application

Parameters **activityTestID**

The identifier provided by the ~~application client~~ (in the request), to correlate this response with the

original request.

Returns

Errors

Method **appActivityTestRes ()**

This method is used by the **client**-application to return the result of a previously requested activity test.

Direction Application to network

Parameters **activityTestID**

The identifier is used by the framework to correlate this response (when it arrives) with the original request.

activityTestResult

The result of the activity test.

Returns

Errors

Method **fwFaultReportInd ()**

This method is invoked by the framework to notify the **client**-application of a failure within the framework. The **client**-application must not continue to use the framework until it has recovered (as indicated by a **fwFaultRecoveryInd**).

Direction Network to application

Parameters **fault**

Specifies the fault that has been detected.

Returns

Errors

Method **fwFaultRecoveryInd ()**

This method is invoked by the framework to notify the **client**-application that a previously reported fault has been rectified.

Direction Network to application

Parameters **fault**

Specifies the fault from which the framework has recovered.

Returns

Errors

Method **svcUnavailableInd ()**

This method is used by the **client**-application to inform the framework that it can no longer use the indicated SCF (either due to a failure in the **client**-application or in the SCF). On receipt of this request, the framework should take the appropriate corrective action. The framework assumes that the session between this **client**-application and instance SCF is to be closed and updates its own records appropriately as well as attempting to inform the SCF instance and/or its administrator. If the **client**-application then tries to continue the use of this session it should be returned an error.

Direction Application to network

Parameters **serviceID**

The identity of the SCF which can no longer be used.

appID

The identity of the application sending the indication.

Returns

Errors

Method **svcUnavailableInd ()**

This method is used by the framework to inform the **client**-application that it can no longer use the indicated SCF due to a failure in the SCF. On receipt of this request, the **client**-application must act to reset its use of the specified SCF (using the normal mechanisms such as the discovery and authentication interfaces to stop use of this SCF instance and begin use of a different SCF instance).

Direction Network to application

Parameters **serviceID**

The identity of the SCF which can no longer be used.

reason

The reason why the SCF is no longer available.

Returns

Errors

Method **genFaultStatsRecordReq ()**

This method is used by the application to solicit fault statistics from the framework. On receipt of this request, the framework must produce a fault statistics record, which is returned to the **client** application. The fault statistics record must contain information about faults relating to the SCFs specified in the **serviceIDList** parameter, during the specified period.

Direction Application to Network

Parameters **timePeriod**

The period over which the fault statistics are to be generated. A null value leaves this to the discretion of the framework.

serviceIDList

This parameter lists the SCFs that the application would like to have included in the general fault statistics record. If the application would like the framework fault statistics to be included it should include the NULL **serviceID**.

appID

This parameter identifies which client application is requesting the statistics record, and therefore which application to send the record to.

Returns**Errors****Method** `genFaultStatsRecordRes ()`

This method is used by the framework to provide fault statistics to an client application in response to a `genFaultStatsRecordReq`.

Direction Network to application

Parameters **faultStatistics**
The fault statistics record.

serviceIDList

This parameter lists the SCFs that have been included in the general fault statistics record. The framework is denoted by the NULL serviceID.

7 Network service capability features

The Network service capability features are provided to the applications by service capability ies servers to enable access to network resources.

Note: when the direction of a method in an interface class interface is “application to network”, this means that the method is invoked from the application to an SCS residing on the network side of the OSA API interface.

7.1 Call Control

The Call control network service capability feature consists of two interface classes interfaces:

1. Call manager, containing management function for call related issues
2. Call, containing methods to control a call

A call can be controlled by one Call Manager only. A Call Manager can control several calls..




Figure 6 Call control interfaces classes usage relationship

The Call Control service capability features are described in terms of the methods in the Call Control interface classes interfaces. Table 1 Table 1 Table 1 gives an overview of the Call Control methods and to which interface classes interfaces these methods belong.

CallManager	Call
enableCallNotification	routeCallToDestination_Req
disableCallNotification	routeCallToDestination_Res
callNotificationTerminated	routeCallToDestination_Err
callEventNotify	release
callAborted	deassignCall
callNotificationTerminated	getCallInfo_Req
	getCallInfo_Res
	getCallInfo_Err
	superviseCall_Req
	sSuperviseCall_Res
	superviseCall_Err
	callFaultDetected
	setAdviceOfCharge
	setCallChargePlan

Table 1 Overview of Call Control ~~interface-classes~~interfaces and their methods

7.1.1 Call Manager

The generic call manager ~~interface-class~~interface provides the management functions to the generic call Service Capability Features. The application programmer can use this ~~interface-class~~interface ~~to create call objects and~~ to enable or disable call-related event notifications.

Method **enableCallNotification()**

This method is used to enable call notifications to be sent to the application.

Direction Application to network

Parameters **appInterface**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `setCallback()` method.

eventCriteria

Specifies the event specific criteria used by the application to define the event required. Individual addresses or address ranges may be specified for destination and/or origination. Examples of events are “incoming call attempt reported by network”, “answer”, “no answer”, “busy”.

Returns **assignmentID**

Specifies the ID assigned by the generic call control manager object for this newly-enabled event notification.

Errors **USER_NOT_SUBSCRIBED**

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **disableCallNotification()**

This method is used by the application to disable call notifications.

Direction Application to network

Parameters **eventCriteria**

Specifies the event specific criteria used by the application to define the event to be disabled. Examples of events are "incoming call attempt reported by network", "answer", "no answer", "busy".

assignmentID

Specifies the assignment ID given by the generic call control manager object when the previous enableNotification() was called.

Returns -

Errors INVALID_ASSIGNMENTID

Returned if the assignment ID does not correspond to one of the valid assignment IDs.

Method **callEventNotify()**

This method notifies the application of the arrival of a call-related event.

Direction Network to application

Parameters **callReference**

Specifies the call session ID and the reference to the call object to which the notification relates.

eventInfo

Specifies data associated with this event. These data include originating aAddress, original dDestination aAddress, redirecting aAddress and aApplication information, which consists of teleservice information, bearer service information, calling party's category, presentation address, additional calling party address, alerting mechanism, network access type, interworking indicators and generic info for operator specific information. (see for more explanation on these data the routeCallToDestination() method).

assignmentID

Specifies the assignment IDid which was returned by the enableNotification() method. The application can use assignment ID to associate events with event-specific criteria and to act accordingly.

appInterface

Specifies a reference to the application object which implements the callback interface for the new call.

Returns -

Errors -

Method **callAborted()**

This method indicates to the application that the call object has aborted or terminated abnormally. No further communication will be possible between the call object and the application.

Direction Network to application

Parameters **call**

Specifies the call object that has aborted or terminated abnormally.

callSessionID

Specifies the call session ID of the call that has aborted or terminated abnormally.

Returns -

Errors -

Method **callNotificationTerminated()**

This method indicates to the application that all event notifications have been terminated (for example, due to faults detected).

Direction Network to application

Parameters -

Returns -

Errors -

7.1.2 Call

The generic call ~~interface class~~ interface provides basic call control methods for applications, a structure to allow simple and complex call behaviour to be used.

Method **routeCallToDestination_Req()**

This asynchronous method requests routing of the call ~~(and inherently attached parties)~~ to the destination party (specified in the parameter `TargetAddress`). The destination party is attached to the call via a passive leg. This means that the call is not automatically released if the destination party disconnects from the call; only the leg with which the destination party was attached to the call is released in that case. .

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

responseRequested

Specifies the set of observed call events that will result in a `routeCallToDestination_Res()` being generated.

targetAddress

Specifies the destination party to which the call should be routed.

originatingAddress

Specifies the address of the originating (calling) party.

originalDestinationAddress

Specifies the original destination address of the call, ~~i.e. the address as specified by the originating party.~~ This parameter ~~may~~should be equal to the originalDestinationAddress or Destination Address as received by the application in the eventInfo parameter of the callEventNotify method. The latter alternative is conventional when a new targetAddress is supplied by the application.

redirectingAddress

Specifies the last address from which the call was redirected.

appInfo

Specifies application-related information pertinent to the call: ~~(such as alerting method, tele service type, service identities and interaction indicators).~~ teleservice information, bearer service information, calling party's category, presentation address, additional calling party address, alerting mechanism, network access type, interworking indicators and generic info for operator specific information.

assignmentID

Specifies the ID assigned ~~to the request by the network SCS.~~ The same ID will be returned in the routeCallToDestinationRes or Err. This allows the application to correlate the request and the result.

Returns

-

Errors**USER_NOT_SUBSCRIBED**

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method**routeCallToDestination_Res()**

This asynchronous method indicates that the request to route the call to the destination was successful, and indicates the response of the destination party (for example, the call was answered, not answered, refused due to busy, etc.).

Direction

Network to application

Parameters**callSessionID**

Specifies the call session ID of the call.

eventReport

Specifies the result of the request to route the call to the destination party. It ~~also~~includes the network event, date and time, monitoring mode and event specific information such as release cause. ~~the mode that the call object is in and other related information.~~

Returns -

Errors -

Method **routeCallToDestination_Err()**

This asynchronous method indicates that the request to route the call to the destination party was unsuccessful, e.g. an error detected in the network or the call was abandoned. ~~the call could not be routed to the destination party (for example, the network was unable to route the call, the parameters were incorrect, the request was refused, etc.).~~

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **release()**

This method requests the release of the call and associated objects.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

cause
Specifies the cause of the release.

Returns -

Errors -

Method **deassignCall()**

This method requests that the relationship between the application and the call and associated object be de-assigned. It leaves the call in progress, however, it purges the specified call object so that the application has no further control of call processing. If a call is de-assigned that has event reports or call information reports requested, then these reports will be disabled and any related information discarded.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

Returns -

Errors -

Method **getCallInfo_Req ()**

This asynchronous method requests information associated with the call to be provided at the appropriate time (for example, to calculate charging). This method must be invoked before the call is routed to a target address. ~~The call object will exist after the call is ended if information is required to be sent to the application at the end of the call. The call information will be sent after any call event reports.~~

~~Note: At the end of the call, the call information must be sent before the call is deleted.~~

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

callInfoRequested

Specifies the call information that is requested.

Returns -

Errors -

Method **getCallInfo_Res ()**

This asynchronous method reports time information of the finished call or call attempt as well as release cause depending on which information has been requested by getCallInfoReq, all the necessary information requested by the application, for example to calculate charging. This information may be used e.g. for charging purposes. The call information will possibly be sent after routeCallToDestinationRes in all cases where the call or a leg of the call has been disconnected or a routing failure has been encountered.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

callInfoReport

Specifies the call information requested.

Returns -

Errors -

Method **getCallInfo_Err ()**

This asynchronous method reports that the original request was erroneous, or resulted in an error condition.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

errorIndication

Specifies the error which led to the original request failing.

Returns -

Errors -

Method **superviseCall_Req()**

The application calls this method to supervise a call. The application can set a granted connection time for this call. If an application calls this function before it calls a `routeCallToDestination_Req()` or a user interaction function the time measurement will start as soon as the call is answered by the B-party or the user interaction system.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

time

Specifies the granted time in milliseconds for the connection. When specified as 0, volume based supervision is applied. Either bytes (volume) or time should be specified.

treatment

Specifies how the network should react after the granted connection time expired.

bytes

Specifies the granted number of bytes that can be transmitted for the connection. When the quantity is specified as 0, time based supervision is applied. Either bytes (volume) or time should be specified.

Returns -

Errors -

Method **superviseCall_Res()**

This asynchronous method responds to superviseCallReq and reports a call supervision event to the application. The call information will be sent after possible routeCallToDestinationRes in all cases when the call, user interaction device or a leg of the call has been disconnected or a routing failure encountered. This method is also invoked when a tariff switch happens in the network during an active call.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

report

Specifies the situation, which triggered the sending of the call supervision response.

usedTime

Specifies the used time for the call supervision (in milliseconds).

usedVolume

Specifies the used volume for the call supervision (in the same units as specified in the request).

Returns -

Errors -

Method **superviseCall_Err()**

This asynchronous method reports a call supervision error to the application.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **callFaultDetected()**

This method indicates to the application that a fault in the network has been detected which can't be communicated by a network event, e.g., when the user aborts before any routing method is called by the application.

The system purges the call object. Therefore, the application has no further control of call processing. No report will be forwarded to the application.

~~has been detected in the call.~~

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call object in which the fault has been detected.

fault
Specifies the fault that has been detected.

Returns -

Errors -

Method **setAdviceOfCharge()**

This method allows the application to supply the charging information that will be sent to the end-users handset.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

aOCInfo
Specifies two sets of Advice of Charge parameter according to GSM

tariffSwitch
Specifies the tariff switch interval that signifies when the second set of AoC parameters becomes valid.

Returns -

Errors -

Method **setCallChargePlan()**

Allows an application to include charging information in network generated CDR.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

callDetailRecordInfo

Free Format string containing the application specific charging information

Returns -

Errors -

Sequence Diagrams

The following section will describe some scenarios to illustrate the use of the methods described above.

Enable Call notification

The first task to perform in order to allow applications to provide call control related services to certain users is to enable call-related events for these users to trigger the application. This is done with the method `enableCallNotification()`.




Figure 7 Enable call notification

Number translation

The example in figure 8 shows a simple number translation application.

After the call is triggered (according to the criteria in a previous `enableCallNotification()`), **the SCS notifies the application is notified** with an `eventCallNotify()` message. This allows the application to perform the needed actions and continue the call set-up via a `routeCallToDestination_Req()` message. **The SCS relays the result of the call set-up (both positive and negative) is relayed to the application, which ends after that.**




Figure 8 Simple number translation

Call barring

The next example (Figure 9) shows how a call barring application can be implemented:




Figure 9 Call barring application

Pre-paid with advice of charge

The next example shows how a pre-paid application can be implemented:

With a pre-paid application it is the application that will determine the charging for the call. This means that the application will hold the whole tariffing scheme needed and needs to control the whole call. For the call shown the following conditions apply:

- It is a long call
- Two tariff changes take place during the call.
- The application will inform the user about the applicable charging (UICall interface in figure 8, which belongs to the Call User Interaction SCF the methods needed for this are described in section subclause 7.5.2. Note that the UI Manager interface has been omitted for simplicity).

After the application has been triggered, it sends a `superviseCallReq()` message indicating that the application will be responsible for charging the call. Before the call is routed to the requested destination (5), the application sends the allowed time for the call (4) and informs the user about the charging applicable (using the Advice of Charge functionality in the core network) for this call (3). The sent information consists of two sets of AoC information and a tariff switch. The application will be notified via the `superviseCallRes()` message if the tariff switch expired during the supervised period. This allows the application to send a new set of AoC information and a new tariff switch.

The application is notified of the expiration of the allowed time (7) and determines if the user has enough account left to continue with the call.

- 1 If there is enough account left a new time slot is allowed
- 2 Is there not enough account, the user will be notified and the call terminated after some time in order to allow the user to finish the call graciously.




Figure 10 Pre-paid with AoC

7.2 Network User Location

The Network User Location service capability feature provides terminal location information, based on network-related

information, such as a VLR Number, Location Area Identification, or Cell Global Identification. It may also provide geographical location information, if the network is able to support the corresponding capability. The following information is reported when requested provided that the network is able to support the corresponding capability:

- user whom the report concerns
- geographical position
- VLR number
- Cell Global Identification or Location Area Identification
- location number (network specific, refer to ITU-T Q.763)
- time when the position information was attained

It consists of a single ~~interface class~~ interface, permitting an application to perform the following:

- User location requests.
- Requests for starting (or stopping) the generation by the network of periodic user location reports.
- Requests for starting (or stopping) the generation by the network of user location reports based on location changes.

Method **locationReportReq()**

Request for mobile-related location information on one or several users.

Direction Application to network

Parameters **appLocationCamel**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to Authentication OSA Access SCF interface).

users

Specifies the user(s) for which the location shall be reported.

Returns **assignmentId**

Specifies the assignment ID of the location-report request.

Errors **INVALID_PARAMETER_VALUE**

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **locationReportRes ()**

Delivery of a mobile location report. The report is containing mobile-related location information for one or several users.

Direction Network to application

Parameters **assignmentId**
Specifies the assignment ID of the location-report request.

locations
Specifies the location(s) of one or several users.

Returns -

Errors **INVALID_PARAMETER_VALUE**
A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID
The assignment ID does not correspond to one of a valid assignment.

Method **locationReportErr ()**

This method indicates that the location report request has failed.

Direction Network to application

Parameters **assignmentId**
Specifies the assignment ID of the failed location report request.

cause
Specifies the error that led to the failure.

diagnostic
Specifies additional information about the error that led to the failure

Returns -

Errors -

Method **periodicLocationReportingStartReq ()**

Request for periodic mobile location reports on one or several users.

Direction Application to network

Parameters **appLocation**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to [OSA Access SCF Authentication interface](#)).

users

Specifies the user(s) for which the location shall be reported.

reportingInterval

Specifies the requested interval in seconds between the reports.

Returns

assignmentId

Specifies the assignment ID of the periodic location-reporting request.

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

periodicLocationReportingStop()

This method stops the sending of periodic mobile location reports for one or several users.

Direction

Application to network

Parameters

stopRequest

Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.

Returns

-

Errors

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method **periodicLocationReport ()**

Periodic delivery of mobile location reports. The reports are containing mobile-related location information for one or several users.

Direction Network to application

Parameters **assignmentId**

Specifies the assignment ID of the periodic location-reporting request.

locations

Specifies the location(s) of one or several users.

Returns -

Errors**INVALID_PARAMETER_VALUE**

A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method **periodicLocationReportErr ()**

This method indicates that a requested periodic location report has failed. Note that errors only concerning individual users are reported in the ordinary periodicLocationReport() message.

Direction Network to application

Parameters **assignmentId**

Specifies the assignment ID of the failed periodic location reporting start request.

cause

Specifies the error that led to the failure.

diagnostic

Specifies additional information about the error that led to the failure.

Returns -

Errors -

Method **triggeredLocationReportingStartReq ()**

Request for user location reports, containing mobile related information, when the location is changed (the report is triggered by the location change, e.g. change of VLR number, change of [Cell Global-Cell Identification](#)).

Direction Application to network

Parameters **appLocation**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface ()` method (refer to [OSA Access](#)

[SCFAuthentication interface](#)).

users

Specifies the user(s) for which the location shall be reported.

triggers

Specifies the trigger conditions.

Returns

assignmentId

Specifies the assignment ID of the triggered location-reporting request.

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

triggeredLocationReportingStop()

Request that triggered mobile location reporting should stop.

Direction

Application to network

Parameters

stopRequest

Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.

Returns

-

Errors

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment

Method

triggeredLocationReport()

Delivery of a report that is indicating that one or several user's mobile location has changed.

Direction

Network to application

Parameters

assignmentId
Specifies the assignment ID of the triggered location-reporting request.

location
Specifies the location of the user.

criterion
Specifies the criterion that triggered the report.

Returns -

Errors

INVALID_PARAMETER_VALUE
A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID
The assignment ID does not correspond to one of a valid assignment.

Method **triggeredLocationReportErr()**

This method indicates that a requested triggered location report has failed. Note that errors only concerning individual users are reported in the ordinary triggeredLocationReport() message.

Direction Network to application

Parameters

assignmentId
Specifies the assignment ID of the failed triggered location reporting start request.

cause
Specifies the error that led to the failure.

diagnostic
Specifies additional information about the error that led to the failure.

Returns -

Errors -

7.3 User Status

The User Status service capability feature provides general user status monitoring. It allows applications to obtain the status of the user's terminal. It consists of a single ~~interface-class~~[interface](#).

Method **statusReportReq()**

Request for a report on the status of one or several users.

Direction Application to network

Parameters **appStatus**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to [OSA Access SCF Authentication interface](#)).

users

Specifies the user(s) for which the status shall be reported.

Returns

assignmentId

Specifies the assignment ID of the status-report request.

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

statusReportRes()

Delivery of a report, that is containing one or several user's status.

Direction

Network to application

Parameters

assignmentId

Specifies the assignment ID of the status-report request.

status

Specifies the status of one or several users.

Returns

-

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method

statusReportErr()

This method indicates that the status report request has failed.

Direction Network to application

Parameters **assignmentId**
Specifies the assignment ID of the failed status report request.

cause
Specifies the error that led to the failure.

diagnostic
Specifies additional information about the error that led to the failure.

Returns -

Errors -

Method **triggeredStatusReportingStartReq()**

Request for triggered status reports when one or several user's status is changed. The user status SCF will send a report when the status changes.

Direction Application to network

Parameters **appStatus**
If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to [OSA Access SCF Authentication interface](#)).

users
Specifies the user(s) for which the status changes shall be reported.

Returns **assignmentId**
Specifies the assignment ID of the triggered status-reporting request.

Errors **INVALID_PARAMETER_VALUE**
A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET
The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE
The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED
Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED
Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **triggeredStatusReportingStop()**

This method stops the sending of status reports for one or several users.

Direction Application to network

Parameters **stopRequest**

Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.

Returns -

Errors **INVALID_ASSIGNMENT_ID**

The assignment ID does not correspond to one of a valid assignment.

Method **triggeredStatusReport()**

Delivery of a report that is indicating that a user's status has changed.

Direction Network to application

Parameters **assignmentId**

Specifies the assignment ID of the triggered status-reporting request.

status

Specifies the status of the user.

Returns -

Errors **INVALID_PARAMETER_VALUE**

A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method **triggeredStatusReportErr()**

This method indicates that a requested triggered status reporting has failed. Note that errors only concerning individual users are reported in the ordinary triggeredStatusReport() message.

Direction Network to application

Parameters **assignmentId**

Specifies the assignment ID of the failed triggered status reporting start request.

cause

Specifies the error that led to the failure.

diagnostic

Specifies additional information about the error that led to the failure.

Returns -

Errors -

7.4 Terminal Capabilities

It shall be possible for an application to request Terminal Capabilities as defined by MExE [3]. The terminal capabilities are provided by a MExE compliant terminal to the MExE Service Environment either on request or by the terminal itself.

Terminal Capabilities are available only after a Capability negotiation has previously taken place between the user's MExE terminal and the MExE Service environment as specified in [3].

Note: for Release 99 only WAP MExE devices can supply terminal capabilities.

The Terminal Capabilities service capability feature is supported by a unique [interface-classinterface](#), which consists of the following method.

The Terminal Capabilities service capability feature is supported by a unique [interface-classinterface](#), which consists of the following method.

Method **getTerminalCapabilities()**

This method is used by an application to get the capabilities of a user's terminal.

Direction Application to Network

Parameters **terminalIdentity**

Identifies the terminal. It may be a logical address known by the WAP Gateway/PushProxy.

Returns **statusCode**

Indicates whether or not the terminal capabilities are available.

terminalCapabilities

Specifies the latest available capabilities of the user's terminal.

This information, if available, is returned as CC/PP headers as specified in W3C [12] and adopted in the WAP UAProf specification [13]. It contains URLs; terminal attributes and values, in RDF format; or a combination of both.

Errors -

7.5 Message Transfer

7.5.1 Generic User Interaction

The Generic User Interaction service capability feature is used by applications to interact with end users. It consists of two [interface-classesinterfaces](#):

1. User Interaction Manager, containing management functions for User Interaction related issues
2. Generic User Interaction, containing methods to interact with an end-user

The Generic User Interaction service capability feature is described in terms of the methods in the Generic User Interaction [interface-classes/interfaces](#).

The following table gives an overview of the Generic User Interaction methods and to which [interface-classes/interfaces](#) these methods belong.

User Interaction Manager	Generic User Interaction
createUI	sendInfoReq
createUICall	sendInfoRes
enableUINotification	sendInfoErr
disableUINotification	sendInfoAndCollectReq
userInteractionEventNotify	sendInfoAndCollectRes
userInteractionAborted	sendInfoAndCollectErr
	release
	userInteractionFaultDetected

Table 322 Overview of Generic User Interaction [interface-classes/interfaces](#) and their methods

User Interaction Manager

Inherits from the generic service interface.

The User Interaction Manager [interface-class/interface](#) provides the management functions to the User Interaction [class](#) interface.

Method **createUI ()**

This method is used to create a new (non call related) user interaction object.

Direction Application to network

Parameters **appUI**

Specifies the application interface for callbacks from the user interaction created.

userAddress

Indicates the end-user whom to interact with

Returns **userInteraction**

Specifies the interface and sessionID of the user interaction created.

Errors **USER_NOT_SUBSCRIBED**

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method createUICall()

This method is used to create a new call related user interaction object.

The user interaction can take place to the specified party ([callLegIdentifieruserAdress](#)) or to all parties in a call ([callIdentifier](#)). Only one of [callIdentifier](#) or [callLegIdentifieruserAdress](#) may be defined (the other should be set to NULL).

Note that for certain implementations user interaction can only be performed towards the controlling call party, which shall be the only party in the call.

Direction Application to network

Parameters appUI

Specifies the application interface for callbacks from the user interaction created.

callIdentifier

Specifies the call interface and session ID of the call associated with the send info [operationmethod](#).

callLegIdentifier

Indicates the end-user whom to interact with

Returns userInteraction

Specifies the interface and sessionID of the user interaction created.

Errors

Method enableUINotification()

This method is used to enable the reception of user initiated user interaction.

Direction Application to network

Parameters appInterface

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the [setCallback\(\)](#) method.

eventCriteria

Specifies the event specific criteria used by the application to define the event required, like user address and service code.

Returns assignmentID

Specifies the ID assigned for this newly-enabled event notification.

Errors

Method disableUINotification()

This method allows the application to remove notification for UI related actions previously set.

Direction Application to network

Parameters **assignmentID**
Specifies the assignment ID given by the user interaction manager interface when the previous `enableNotification()` was called. If the assignment ID does not correspond to one of the valid assignment IDs, the framework will return an error code.

Returns

Errors

Method **userInteractionEventNotify()**

This method notifies the application of a user initiated request for user interaction.

Direction Network to Application

Parameters **ui**
Specifies the reference to the interface and the sessionID to which the notification relates.

eventInfo
Specifies data associated with this event.

assignmentID
Specifies the assignment [ID#d](#) which was returned by the `enableNotification()` method. The application can use assignment [ID#d](#) to associate events with event specific criteria and to act accordingly.

Returns **appInterface**
Specifies the application interface for callbacks from the user interaction created.

Errors

Method **userInteractionAborted()**

This method indicates to the application that the User Interaction SCF instance has terminated or closed abnormally. No further communication will be possible between the User Interaction SCF instance and application.

Direction Network to Application

Parameters **userInteraction**
Specifies the interface and sessionID of the user interaction SCF that has terminated.

Returns

Errors

Generic User Interaction

Inherits from the generic service interface. The Generic User Interaction [interface-classinterface](#) provides functions to

send information or data to, or gather information from, the user (or call party). The information to send can be an announcement or a text. The data downloaded in the terminal is specified by a URL.

Method **sendInfoReq ()**

This asynchronous method sends information to the user.

Direction Application to Network

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

info

Specifies the information to send to the user. This information can be:

- an infoID, identifying pre-defined information to be send (announcement and/or text);
- a string, defining the text to be sent;
- a URL , identifying pre-defined information or data to be sent to or downloaded into the terminal

variableInfo

Defines the variable part of the information to send to the user.

repeatIndicator

Defines how many times the information shall be send to the end-user. In the case of a call related user interaction, a value of zero (0) indicates that the announcement shall be repeated until the call or call leg is released or an abortActionReq () is sent.

responseRequested

Specifies if a response is required from the call user interaction SCF, and any action the SCF should take.

Returns **assignmentID**

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

Errors

Method **sendInfoRes ()**

This asynchronous method informs the application about the start or the completion of a sendInfoReq (). This response is called only if the application has required a response.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

response

Specifies the type of response received from the user.

Returns**Errors****Method** **sendInfoErr ()**

This asynchronous method indicates that the request to send information was unsuccessful.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

error

Specifies the error which led to the original request failing.

Returns**Errors****Method** **sendInfoAndCollectReq ()**

This asynchronous method plays an announcement or sends other information to the user and collects some information from the user. The announcement usually prompts for a number of characters (for example, these are digits or text strings such as "YES" if the user's terminal device is a phone).

Direction Application to Network

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

infoID

Specifies the ID of the information to send to the user.

variableInfo

Defines the variable part of the information to send to the user.

criteria

Specifies additional properties for the collection of information, such as the maximum and minimum number of characters, end character, first character timeout and inter-character timeout.

Returns**assignmentID**

Specifies the ID assigned by the generic user interface

Errors**Method** **sendInfoAndCollectRes ()**

This asynchronous method returns the information collected to the application.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

response

Specifies the type of response received from the user.

info

Specifies the information collected from the user.

Returns

Errors

Method **sendInfoAndCollectErr()**

This asynchronous method indicates that the request to send information and collect a response was unsuccessful.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

error

Specifies the error which led to the original request failing.

Returns

Errors

Method **release()**

This method requests that the relationship between the application and the user interaction object be released. It causes the release of the used user interaction resources and interrupts any ongoing user interaction.

Direction Application to Network

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

Returns

Errors

Method **userInteractionFaultDetected()**

This method indicates to the application that a fault has been detected in the user interaction.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the interface and sessionID of the user interaction SCF in which the fault has been detected.

fault

Specifies the fault that has been detected.

Returns .

Errors

7.5.2 Call User Interaction

The Call User Interaction service capability feature is used by applications to interact with end users participating to a call. It consists of two [interface classes/interfaces](#):

1. User Interaction Manager, containing management functions for User Interaction related issues. This [interface class](#) is the same as the one defined in [section/subclause 7.5.1](#).
2. Call User Interaction, extending Generic User Interaction for call-specific user interaction. It provides functions to send information to, or gather information from, a user (or call party) in a call.

The Call User Interaction service capability feature is described in terms of the methods in the Call User Interaction [interface classes/interfaces](#).

The following table gives an overview of the Call User Interaction methods and to which [interface classes/interfaces](#) these methods belong.

User Interaction Manager	Call User Interaction
<i>As defined for the Generic User Interaction SCF</i>	<i>Inherits from Generic User Interaction and adds:</i>
	abortActionReq
	abortActionRes
	abortActionErr

Table 433 Overview of Call User Interaction [interface classes/interfaces](#) and their methods

Method **abortActionReq()**

This asynchronous method aborts a user interaction operation, e.g. a `sendInfoCall_Req()`. The call and call leg are otherwise unaffected. The call user interaction SCF interrupts the indicated action.

Direction Application to Network

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID : **TAssignmentID**

Specifies the user interaction request to be cancelled.

Returns

Errors

Method **abortActionRes ()**

This asynchronous method confirms that the request to abort a user interaction operation on a call leg was successful.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID : **TAssignmentID**

Specifies the user interaction request to be cancelled.

Returns

Errors

Method **abortActionErr ()**

This asynchronous method indicates that the request to abort a user interaction operation on a call leg resulted in an error.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID : **TAssignmentID**

Specifies the user interaction request to be cancelled.

error

Specifies the error which led to the original request failing.

Returns

Errors

7.6 User Profile Management

User Profile information may be distributed between the Home Environment and the Home Environment Value-Added Services Providers. The HE-VASP may manage information specific to the services supported by their OSA applications. For this, they may use models and mechanisms, which are out of the scope of OSA release 99.

Home Environment User Profile information consists of various [user](#) interface and service related information. Of particular interest in the context of release 99 is the following information:

- list of services to which the end-user is subscribed

- service status (active/inactive)
- privacy status with regards to network service capabilities (e.g. user location, user interaction)
- terminal capabilities

Home Environment user profile information may be stored centrally, or the information may be distributed over relevant physical entities.

Terminal capabilities may be accessed by OSA applications through the network Terminal Capabilities SCF.

History

Date	Version	Comment
July 1999	0.1.0	Initial Draft produced in Hazlet, New Jersey, USA
September 1999	0.2.0	Version presented to S2 plenary in Bonn, Germany (not including all agreed changes yet from VHE/OSA adhoc session)
September 1999	0.2.1	Output of Bonn meeting (Presented to SA for information, since V1.0.0 was not available due to 3GPP e-mail exploder problems).
October 1999	0.3.0	Version sent to S2 e-mail list and proposed to send to SA plenary
October 1999	0.3.1	Small editorial updates in Interface section (subclauses 6 and 7)
October 1999	1.0.0	Version 0.3.1 raised to V1.0.0 by S2 e-mail approval and sent to SA e-mail list for information
November 1999	1.1.0	Updated after comments in S2#9 according to S2-99C06 (S2-99B32, S2-99B33 and S2-99B36)
December 1999	1.1.1	Updated after drafting session in Munich, approved in S2#11
February 2000	1.2.0	Updated after S2#11 according to S2-000230 (S2-000081, S2-000146, S2-000148, S2-000172, S2-000187, S2-000188, S2-000189, S2-000202, S2-000203) and with various minor editorial changes
February 2000	1.3.0	Updated during OSA interim session in Stockholm (February 23-24) and consolidated the week after.
March 2000	1.4.0	Updated during OSA drafting session in S2#12 according to S2-000500 and S2-000355.
March 2000	2.0.0	Editorial changes compared to 1.4.0. Presented to SA#7 for approval.
March 2000	3.0.0	Output of SA#7. Minor editorial changes compared to v.2.0.0.
Rapporteur: Christophe Gourraud, Ericsson Email: christophe.gourraud@lmc.ericsson.se Telephone: +1 514 345 7900 (#5795)		

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 003R1

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
 list expected approval meeting # here ↑

for approval
 for information

strategic
 non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
 (at least one should be marked with an X)

Source: Ericsson, Siemens **Date:** 22.5.2000

Subject: Alignment with stage 3 (TS 29.198)

Work item: VHE/OSA

Category: <small>(only one category shall be marked with an X)</small>	F Correction	<input checked="" type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input type="checkbox"/>		Release 98	<input type="checkbox"/>
	D Editorial modification	<input type="checkbox"/>	Release 99	<input checked="" type="checkbox"/>	
			Release 00	<input type="checkbox"/>	

Reason for change: Mis-alignments between stage 2 and stage 3 specifications were identified, some of which requiring corrections in stage 2. These corrections concern methods and parameters in the OSA interfaces.
 A particular case is the re-introduction of OAM and Heartbeat Management framework SCFs, which were part of earlier versions of the specification, but were accidentally removed when it was raised to 3.0.0.

Clauses affected:

Other specs affected:

Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
MS test specifications	<input type="checkbox"/>	→ List of CRs:	
BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



<----- double-click here for help and instructions on how to create a CR.

6.2 Discovery

The discovery SCF consists of a single interface class. Before a network SCF can be discovered, the client application must know what “types” of SCFs are supported by the Framework and what “properties” are applicable to each SCF type. The `listServiceType()` method returns a list of all “SCF types” that are currently supported by the framework and the “describeServiceType()” returns a description of each SCF type. The description of SCF type includes the “SCF-specific properties” that are applicable to each SCF type. Then the client application can discover a specific set of registered SCFs that belong to a given type and possess the desired “property values”, using the “discoverService()” method.

Once the HE-VASP finds out the desired set of SCFs supported by the network, it subscribes (a sub-set of) these SCFs using the Subscription framework SCF. The HE-VASP (or the client applications in its domain) can find out the set of SCFs available to it (i.e., the SCFs that it can use) by invoking “listSubscriberServices()”.

The discovery SCF is invoked by the HE-VASP or client applications. Its methods are described below.

Method **discoverService ()**

The `discoverService` operation is the means by which a client application is able to obtain the IDs of the SCFs that meet its requirements. The client application passes in a list of desired properties to describe the SCF it is looking for, in the form attribute/value pairs for the properties. The client application also specifies the maximum number of matched responses it is willing to accept. The framework must not return more matches than the specified maximum, but it is up to the discretion of the Framework implementation to choose to return less than the specified maximum. The `discoverService()` operation returns a serviceID/Property pair list for those SCFs that match the desired property list that the client application provided.

Direction Application to network

Parameters **serviceTypeName**

The “ServiceTypeName” parameter conveys the required SCF type. It is key to the central purpose of “SCF trading”. By stating an SCF type, the importer implies the SCF type and a domain of discourse for talking about properties of SCF.

The framework may return an SCF of a subtype of the “type” requested. An SCF sub-type can be described by the properties of its supertypes.

desiredPropertyList

The “desiredPropertyList” parameter is a list of property name and property value pairs of properties that the discovered set of SCFs should satisfy. These properties deal with the non-functional and non-computational aspects of the desired SCF. The property values in the desired property list must be logically interpreted as “minimum”, “maximum”, etc. by the framework.

max

The “max” parameter states the maximum number of SCFs that are to be returned in the “ServiceList” result.

Returns **serviceList :**

This parameter gives a list of matching SCFs. Each SCF is characterised by an SCF ID and a list of property name and property value pairs associated with the SCF.

Errors **ILLEGAL_SERVICE_TYPE**

Returned if the string representation of the “type” does not obey the rules for SCF type identifiers

UNKNOWN_SERVICE_TYPE

Returned if the “type” is correct syntactically but is not recognised as an SCF type within the Framework

Method listServiceTypes ()

This operation returns the names of all SCF types which are in the repository. The details of the SCF types can then be obtained using the describeServiceType() method.

Direction Application to network

Parameters

Returns listTypes

The names of the requested SCF types.

Errors**Method describeServiceType()**

This operation lets the caller to obtain the details for a particular SCF type.

Direction Application to network

Parameters name

The name of the SCF type to be described

Returns serviceTypeDescription

The description of the specified SCF type. The description provides information about:

- the property names associated with the SCF,
- the corresponding property value types,
- the corresponding property mode (mandatory or read only) associated with each SCF property,
- the names of the super types of this type, and
- whether the type is currently enabled or disabled.

Errors **ILLEGAL_SERVICE_TYPE**

Returned if the string representation of the “type” does not obey the rules for SCF type identifiers

UNKNOWN_SERVICE_TYPE

Returned if the “type” is correct syntactically but is not recognised as an SCF type within the Framework

Method listSubscribedServices ()

Returns a list of SCFs so far subscribed by the HE-VASP. The HE-VASP (or the client applications in the HE-VASP domain) can obtain a list of subscribed SCFs that they are allowed to access.

Direction Application to network

Parameters**Returns****serviceIDList**

Returns a list of IDs of the SCFs subscribed by the HE-VASP.

Errors

6.3 Integrity Management SCFs

6.3.1 Load Manager

The framework API should allow the load to be distributed across multiple machines and across multiple component processes, according to a load balancing policy. The separation of the load balancing mechanism and load balancing policy ensures the flexibility of the load balancing functionality. The load balancing policy identifies what load balancing rules the framework should follow for the specific client application. It might specify what action the framework should take as the congestion level changes. For example, some real-time critical applications will want to make sure continuous service is maintained, below a given congestion level, at all costs, whereas other applications will be satisfied with disconnecting and trying again later if the congestion level rises. Clearly, the load balancing policy is related to the QoS level to which the application is subscribed.

The Load Manager SCF consists of a single interface class. Most methods are asynchronous, in that they do not lock a thread into waiting whilst a transaction performs. In this way, the client machine can handle many more calls, than one that uses synchronous message calls.

The load management operations do not exchange callback interfaces as it is assumed that the client application has supplied its Load Management callback interface at the time it obtains the Framework's Load Manager SCF, by use of the `obtainInterfaceWithCallback` operation on the OSA Access SCF.

Method **reportLoad()**

The client application notifies the framework about its current load level (0,1, or 2) when the load level on the application has changed.

At *level 0* load, the application is performing within its load specifications (i.e. it is not congested or overloaded). At *level 1* load, the application is overloaded. At *level 2* load, the application is severely overloaded.

Direction Application to network**Parameters** **requester**

Specifies the application interface for callbacks.

loadLevel

Specifies the load level for which the application reported.

Returns**Errors****Method** **enableLoadControl()**

Upon detecting load condition change, (i.e. load level changing from 0 to 1, 0 to 2, 1 to 2 or 2 to 1, for the SCFs or framework which has been registered for load control), the

framework enables load management activity at the client application based on the policy.

Direction Network to application

Parameters **loadStatistics**
Specifies the new load statistics

Returns

Errors

Method **disableLoadControl()**

After load level of the framework or SCF which has been registered for load control moves back to normal, framework disables load control activity at the client application based on policy.

Direction Network to application

Parameters **ServiceIDs**
Specifies the framework and SCFs for which the load has changed to normal. The serviceIDs is null to specify the framework only.

Returns

Errors

Method **resumeNotification()**

Resume the notification from an application for its load status after the detection of load level change at the framework and the evaluation of the load balancing policy.

Direction Network to application

Parameters

Returns

Errors

Method **suspendNotification()**

Suspend the notification from an application for its load status after the detection of load level change at the framework and the evaluation of the load balancing policy.

Direction Network to application

Parameters

Returns

Errors

Method **queryLoadReq()**

The client application requests load statistic records for the framework and specified SCFs.

Direction Application to Network

Parameters **requester**
Specifies the application interface for callbacks.

serviceIDs
Specifies the framework, SCFs or applications for which the load statistics shall be reported. The serviceIDs is null for framework load statistics only.

timeInterval
Specifies the time interval within which the load statistics are generated.

Returns

Errors

Method **queryLoadRes ()**
Returns load statistics to the application which requested the information.

Direction Network to application

Parameters **loadStatistics**
Specifies the framework-supplied load statistics.

Returns

Errors

Method **queryLoadErr ()**
Returns an error code to the application that requested load statistics.

Direction Network to application

Parameters **loadStatisticsError**
Specifies the framework-supplied error code.

Returns

Errors

Method **queryAppLoadReq ()**
The framework requests for load statistic records produced by a specified application.

Direction Network to application

Parameters **serviceIDs**
Specifies the SCFs or applications for which the load statistics shall be reported.

timeInterval
Specifies the time interval within which the load statistics are generated.

Returns

Errors**Method** **queryAppLoadRes ()**

Report load statistics back to the framework that requested the information.

Direction Application to network

Parameters **loadStatistics**
Specifies the load statistics in the application.

Returns

Errors

Method **queryAppLoadErr ()**

Return an error response to the framework that requested the application's load statistics information.

Direction Application to network

Parameters **loadStatisticsError**
Specifies the error code associated with the failed attempt to retrieve the application's load statistics.

Returns

Errors

Method **registerLoadController ()**

Register the client application for load management under various load conditions.

Direction Application to network

Parameters **requester**
Specifies the application interface for callbacks.

serviceIDs

Specifies the framework and SCFs to be registered for load control. To register for framework load control only, the `serviceIDs` is null.

Returns

Errors

Method **unregisterLoadController ()**

Unregister the client application for load management.

Direction Application to network

Parameters **requester**
Specifies the application interface for callbacks.

serviceIDs

Specifies the framework or SCFs to be unregistered for load control.

Returns**Errors****Method** **resumeNotification ()**

Resume load management notifications to the application for the framework and specified SCFs after their load condition changes.

Direction Application to network

Parameters **serviceIDs**

Specifies the framework and SCFs for which notifications are to be resumed. The serviceIDs is null to resume notifications for the framework only.

Returns**Errors****Method** **suspendNotification()**

Suspend load management notifications to the application for the framework and specified SCFs, while the application handles a temporary load condition.

Direction Application to network

Parameters **serviceIDs**

Specifies the framework and SCFs for which notifications are to be suspended. The serviceIDs is null to suspend notifications for the framework only.

Returns**Errors**

6.3.2 Fault Manager

This SCF is used by the application to inform the framework of events which affect the integrity of the framework and SCFs, and to request information about the integrity of the system.

It consists of a single interface class, with the following methods.

Method **activityTestReq()**

This method may be used by the application to test that the framework or an SCF is operational. On receipt of this request, the framework must carry out a test on the specified SCF or the framework itself to check that it is operating correctly and report the test result.

Direction Application to network

Parameters **activityTestID**

The identifier provided by the client application to correlate the response (when it arrives) with this request.

svcID

This parameter identifies which SCF the client application is requesting the activity test to be done for. A null value denotes that the activity test is being requested for the framework.

appID

This parameter identifies which client application is requesting the activity test, and therefore which application to send the result to.

Returns

Errors

Method **activityTestRes ()**

The framework returns the result of the activity test in this method, along with a test identifier to allow correlation of result to request within the client application.

Direction Network to application

Parameters **activityTestID**

The identifier provided by the client (in the request), to correlate this response with the original request.

activityTestResult

The result of the activity test.

Returns

Errors

Method **appActivityTestReq ()**

This method is invoked by the framework to request that the client application carries out an activity test to check that it is operating correctly.

Direction Network to application

Parameters **activityTestID**

The identifier provided by the client (in the request), to correlate this response with the original request.

Returns

Errors

Method **appActivityTestRes ()**

This method is used by the client application to return the result of a previously requested activity test.

Direction Application to network

Parameters **activityTestID**

The identifier is used by the framework to correlate this response (when it arrives) with the original request.

activityTestResult

The result of the activity test.

Returns**Errors****Method** **fwFaultReportInd ()**

This method is invoked by the framework to notify the client application of a failure within the framework. The client application must not continue to use the framework until it has recovered (as indicated by a fwFaultRecoveryInd).

Direction Network to application

Parameters **fault**

Specifies the fault that has been detected.

Returns**Errors****Method** **fwFaultRecoveryInd ()**

This method is invoked by the framework to notify the client application that a previously reported fault has been rectified.

Direction Network to application

Parameters **fault**

Specifies the fault from which the framework has recovered.

Returns**Errors****Method** **svcUnavailableInd ()**

This method is used by the client application to inform the framework that it can no longer use the indicated SCF (either due to a failure in the client application or in the SCF). On receipt of this request, the framework should take the appropriate corrective action. The framework assumes that the session between this client application and instance SCF is to be closed and updates its own records appropriately as well as attempting to inform the SCF instance and/or its administrator. If the client application then tries to continue the use of this session it should be returned an error.

Direction Application to network

Parameters **serviceID**

The identity of the SCF which can no longer be used.

appID

The identity of the application sending the indication.

Returns

Errors

Method **svcUnavailableInd ()**

This method is used by the framework to inform the client application that it can no longer use the indicated SCF due to a failure in the SCF. On receipt of this request, the client application must act to reset its use of the specified SCF (using the normal mechanisms such as the discovery and authentication interfaces to stop use of this SCF instance and begin use of a different SCF instance).

Direction Network to application

Parameters **serviceID**

The identity of the SCF which can no longer be used.

reason

The reason why the SCF is no longer available.

Returns

Errors

Method **genFaultStatsRecordReq ()**

This method is used by the application to solicit fault statistics from the framework. On receipt of this request, the framework must produce a fault statistics record, which is returned to the client application. The fault statistics record must contain information about faults relating to the SCFs specified in the *serviceIDList* parameter, during the specified period.

Direction Application to Network

Parameters **timePeriod**

The period over which the fault statistics are to be generated. A null value leaves this to the discretion of the framework.

serviceIDList

This parameter lists the SCFs that the application would like to have included in the general fault statistics record. If the application would like the framework fault statistics to be included it should include the NULL *serviceID*.

appID

This parameter identifies which client application is requesting the statistics record, and therefore which application to send the record to.

Returns

Errors

Method **genFaultStatsRecordRes ()**

This method is used by the framework to provide fault statistics to a client application in response to

a genFaultStatsRecordReq.

Direction Network to application

Parameters **faultStatistics**
The fault statistics record.

serviceIDsList

This parameter lists the SCFs that have been included in the general fault statistics record. The framework is denoted by the NULL serviceID.

6.3.3 Heartbeat Management

This SCF allows the initialisation of a heartbeat supervision of the client application. In case of SCF supervision, it is the framework's responsibility to check the health status of the respective SCF.

Since the OSA API is inherently synchronous, the heartbeats themselves are synchronous for efficiency reasons.

The Heartbeat Management SCF consists of a two interface classes: Heartbeat Management and Heartbeat.

Heartbeat Management

Method **enableHeartBeat ()**

With this method, the client application registers at the framework for heartbeat supervision of itself.

Direction Application to network

Parameters **duration**
The duration in milliseconds between the heartbeats.

appInterface
This parameter refers to the callback interface.

Returns **session**
Identifies the heartbeat session. In general, the application has only one session. In case of SCF and framework supervision by the client application, the application may maintain more than one session.

Errors

Method **disableHeartBeat ()**

Allows the stop of the heartbeat supervision of the application.

Direction Application to network

Parameters **session**
Identifies the heartbeat session.

Returns

Errors**Method** **changeTimeperiod()**

Allows the administrative change of the heartbeat period.

Direction Application to network

Parameters **session**

Identifies the heartbeat session. In general, the application has only one session.

duration

The time interval in milliseconds between the heartbeats.

Returns**Errors****Method** **enableAppHeartBeat()**

With this method, the framework registers at the client application for heartbeat supervision of itself.

Direction Network to application

Parameters **duration**

The time interval in milliseconds between the heartbeats.

fwInterface

This parameter refers to the callback interface.

session

Identifies the heartbeat session..

Returns**Errors****Method** **disableAppHeartBeat()**

Allows the stop of the heartbeat supervision of the application.

Direction Network to application

Parameters **session**

Identifies the heartbeat session.

Returns**Errors****Method** **changeTimeperiod()**

Allows the administrative change of the heartbeat period.

Direction Network to application

Parameters **session**
Identifies the heartbeat session.

duration
The time interval in milliseconds between the heartbeats.

Returns

Errors

Heartbeat

Method **send ()**
This is the method the client application uses in case it supervises the framework or an SCF. The sender must raise an exception if no result comes back after a certain, user-defined time.

Direction

Parameters **session**
Identifies the heartbeat session. In general, the application has only one session.

Returns

Errors

Method **send ()**
This is the method the framework uses in case it supervises a client application. The sender must raise an exception if no result comes back after a certain, user-defined time.

Direction

Parameters **session**
Identifies the heartbeat session.

Returns

Errors

6.3.4 OAM

The OAM SCF is used to query the system date and time. The application and the framework can synchronise the date and time to a certain extent. Accurate time synchronisation is outside the scope of the OSA API.

The OAM SCF consists of a unique interface class.

Method **systemDateTimeQuery ()**
This method is used to query the system date and time. The client application passes in its own date

and time to the framework. The framework responds with the system date and time.

Direction Application to network

Parameters clientDateAndTime
This is the date and time of the client application.

Returns systemDateAndTime
This is the system date and time returned by the framework.

Errors INVALID DATE TIME FORMAT

Method systemDateTimeQuery()

This method is used to query the system date and time. The framework passes in the system date and time to the client. The client responds with its own date and time.

Direction Network to application

Parameters systemDateAndTime
This is the system date and time of the framework.

Returns clientDateAndTime
This is the date and time returned by the client.

Errors OSA INVALID DATE TIME FORMAT

7 Network service capability features

The service capability features provided to the application by service capabilities servers to enable access to network resources.

Note: when the direction of a method in an interface class is “application to network”, this means that the method is invoked from the application to an SCS residing on the network side of the OSA interface.

7.1 Call Control

The Call control network service capability feature consists of two interface classes:

1. Call manager, containing management function for call related issues
2. Call, containing methods to control a call

A call can be controlled by one Call Manager only. A Call Manager can control several calls..




Figure 6 Call control classes usage relationship

The Call Control service capability features are described in terms of the methods in the Call Control interface classes. [Table 1](#) gives an overview of the Call Control methods and to which interface classes these methods belong.

CallManager	Call
enableCallNotification	routeCallToDestination_Req
disableCallNotification	routeCallToDestination_Res
callNotificationTerminated	routeCallToDestination_Err
callEventNotify	release
callAborted	deassignCall
callNotificationTerminated	getCallInfo_Req
	getCallInfo_Res
	getCallInfo_Err
	superviseCall_Req
	SuperviseCall_Res
	superviseCall_Err
	callFaultDetected
	setAdviceOfCharge
	setCallChargePlan

Table 1 Overview of Call Control interface classes and their methods

7.1.1 Call Manager

The generic call manager interface class provides the management functions to the generic call Service Capability Features. The application programmer can use this interface class to create call objects and to enable or disable call-related event notifications.

Method **enableCallNotification()**

This method is used to enable call notifications to be sent to the application.

Direction Application to network

Parameters **appInterface**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `setCallback()` method.

eventCriteria

Specifies the event specific criteria used by the application to define the event required. Examples of events are “incoming call attempt reported by network”, “answer”, “no answer”, “busy”.

Returns **assignmentID**

Specifies the ID assigned by the generic call control manager object for this newly-enabled event notification.

Errors **USER_NOT_SUBSCRIBED**

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **disableCallNotification()**

This method is used by the application to disable call notifications.

Direction Application to network

Parameters **eventCriteria**
~~Specifies the event specific criteria used by the application to define the event to be disabled. Examples of events are "incoming call attempt reported by network", "answer", "no answer", "busy".~~

assignmentID

Specifies the assignment ID given by the generic call control manager object when the previous enableNotification() was called.

Returns -

Errors INVALID_ASSIGNMENTID

Returned if the assignment ID does not correspond to one of the valid assignment IDs.

Method **callEventNotify()**

This method notifies the application of the arrival of a call-related event.

Direction Network to application

Parameters **callReference**

Specifies the reference to the call object to which the notification relates.

eventInfo

Specifies data associated with this event. These data include originatingAddress, originalDestinationAddress, redirectingAddress and AppInfo (see for more explanation on these data the routeCallToDestination() method).

assignmentID

Specifies the assignment id which was returned by the enableNotification() method. The application can use assignment ID to associate events with event-specific criteria and to act accordingly.

appInterface

Specifies a reference to the application object which implements the callback interface for the new call.

Returns -

Errors -

Method **callAborted()**

This method indicates to the application that the call object has aborted or terminated abnormally. No further communication will be possible between the call object and the application.

Direction Network to application

Parameters **callReference**

Specifies the call object that has aborted or terminated abnormally.

callSessionID

~~Specifies the call session ID of the call that has aborted or terminated abnormally.~~

Returns -

Errors -

Method **callNotificationTerminated()**

This method indicates to the application that all event notifications have been terminated (for example, due to faults detected).

Direction Network to application

Parameters -

Returns -

Errors -

7.1.2 Call

The generic call interface class provides a structure to allow simple and complex call behaviour to be used.

Method **routeCallToDestination_Req()**

This asynchronous method requests routing of the call (and inherently attached parties) to the destination party (specified in the parameter `TargetAddress`). The destination party is attached to the call via a passive leg. This means that the call is not automatically released if the destination party disconnects from the call; only the leg with which the destination party was attached to the call is released in that case. .

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

responseRequested

Specifies the set of observed events that will result in a `routeCallToDestination_Res()` being generated.

targetAddress

Specifies the destination party to which the call should be routed.

originatingAddress

Specifies the address of the originating (calling) party.

originalDestinationAddress

Specifies the original destination address of the call, i.e. the address as specified by the originating party. This parameter should be equal to the `originalDestinationAddress` as received by the application in the `eventInfo` parameter of the `callEventNotify` method.

redirectingAddress

Specifies the last address from which the call was redirected.

appInfo

Specifies application-related information pertinent to the call (such as alerting method, tele-service type, service identities and interaction indicators).

assignmentID

Specifies the ID assigned by the network SCS. The same ID will be returned in the `routeCallToDestinationRes` or `Err`. This allows the application to correlate the request and the result.

Returns

-

Errors

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

`routeCallToDestination_Res()`

This asynchronous method indicates that the request to route the call to the destination was successful, and indicates the response of the destination party (for example, the call was answered, not answered, refused due to busy, etc.).

Direction

Network to application

Parameters

`callSessionID`

Specifies the call session ID of the call.

`eventReport`

Specifies the result of the request to route the call to the destination party. It also includes the mode that the call object is in and other related information.

`assignmentID`

Specifies the assignment ID of the routing request.

Returns

-

Errors

-

Method

`routeCallToDestination_Err()`

This asynchronous method indicates that the request to route the call to the destination party was unsuccessful - the call could not be routed to the destination party (for example, the network was

unable to route the call, the parameters were incorrect, the request was refused, etc.).

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

assignmentID
Specifies the assignment ID of the routing request.

Returns -

Errors -

Method **release()**
This method requests the release of the call and associated objects.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

cause
Specifies the cause of the release.

Returns -

Errors -

Method **deassignCall()**
This method requests that the relationship between the application and the call and associated object be de-assigned. It leaves the call in progress, however, it purges the specified call object so that the application has no further control of call processing. If a call is de-assigned that has event reports or call information reports requested, then these reports will be disabled and any related information discarded.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

Returns -

Errors -

Method **getCallInfoReq()**
This asynchronous method requests information associated with the call to be provided at the appropriate time (for example, to calculate charging). This method must be invoked before the call is routed to a target address. The call object will exist after the call is ended if information is required to be sent to the application at the end of the call. The call information will be sent after any call

event reports.

Note: At the end of the call, the call information must be sent before the call is deleted.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoRequested
Specifies the call information that is requested.

Returns -

Errors -

Method **getCallInfo_Req ()**

This asynchronous method reports all the necessary information requested by the application, for example to calculate charging.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoReport
Specifies the call information requested.

Returns -

Errors -

Method **getCallInfo_Err ()**

This asynchronous method reports that the original request was erroneous, or resulted in an error condition.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **superviseCall_Req ()**

The application calls this method to supervise a call. The application can set a granted connection time for this call. If an application calls this function before it calls a `routeCallToDestination_Req ()` or a user interaction function the time measurement will start as soon as the call is answered by the B-party or the user interaction system.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

time

Specifies the granted time in milliseconds for the connection. When specified as 0, volume based supervision is applied. Either bytes (volume) or time should be specified.
treatment
Specifies how the network should react after the granted connection time expired.

bytes

Specifies the granted number of bytes that can be transmitted for the connection. When the quantity is specified as 0, time based supervision is applied. Either bytes (volume) or time should be specified.

Returns -

Errors -

Method **superviseCall_Res()**

This asynchronous method reports a call supervision event to the application.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

report

Specifies the situation, which triggered the sending of the call supervision response.

usedTime

Specifies the used time for the call supervision (in milliseconds).

usedVolume

Specifies the used volume for the call supervision (in the same units as specified in the request).

Returns -

Errors -

Method **superviseCall_Err()**

This asynchronous method reports a call supervision error to the application.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication

Specifies the error which led to the original request failing.

Returns -

Errors -

Method **callFaultDetected()**

This method indicates to the application that a fault has been detected in the call.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call object in which the fault has been detected.

fault

Specifies the fault that has been detected.

Returns -

Errors -

Method **setAdviceOfCharge()**

This method allows the application to the charging information that will be send to the end-users handset.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

aOCInfo

Specifies two sets of Advice of Charge parameter according to GSM

tariffSwitch

Specifies the tariff switch that signifies when the second set of AoC parameters becomes valid.

Returns -

Errors -

Method **setCallChargePlan()**

Allows an application to include charging information in network generated CDR.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

callChargePlanDetailRecordInfo

Free Format string containing the application specific charging information

Returns -

Errors -

Sequence Diagrams

The following section will describe some scenarios to illustrate the use of the methods described above.

Enable Call notification

The first task to perform in order to allow applications to provide call control related services to certain users is to enable call-related events for these users to trigger the application. This is done with the method `enableCallNotification()`.




Figure 7 Enable call notification

Number translation

The example in figure 8 shows a simple number translation application.

After the call is triggered (according to the criteria in a previous `enableCallNotification()`), the SCS notifies the application with an `eventCallNotify()` message. This allows the application to perform the needed actions and continue the call set-up via a `routeCallToDestination_Req()` message. The SCS relays the result of the call set-up (both positive and negative) to the application, which ends after that.




Figure 8 Simple number translation

Call barring

The next example (Figure 9) shows how a call barring application can be implemented:




Figure 9 Call barring application

Pre-paid with advice of charge

The next example shows how a pre-paid application can be implemented:

With a pre-paid application it is the application that will determine the charging for the call. This means that the application will hold the whole tariffing scheme needed and needs to control the whole call. For the call shown the following conditions apply:

- It is a long call
- Two tariff changes take place during the call.
- The application will inform the user about the applicable charging (the methods needed for this are described in section 7.5.2).

After the application has been triggered, it sends a `superviseCall_Req()` message indicating that the application will be responsible for charging the call. Before the call is be routed to the requested destination(5), the application sends the allowed time for the call (4) and informs the user about the charging applicable (using the Advice of Charge functionality in the core network) for this call (3). The sent information consists of two sets of AoC information and a tariff switch. The application will be notified via the `superviseCall_Res()` message if the tariff switch expired during the supervised period. This allows the application to send a new set of AoC information and a new tariff switch.

The application is notified of the expiration of the allowed time (7) and determines if the user has enough account left to continue with the call.

- 1 If there is enough account left a new time slot is allowed
- 2 Is there not enough account, the user will be notified and the call terminated after some time in order to allow the user to finish the call graciously.




Figure 10 Pre-paid with AoC

7.2 Network User Location

The Network User Location service capability feature provides terminal location information, based on network-related

information, such as a VLR Number, Location Area Identification, or Cell Global Identification. It may also provide geographical location information, if the network is able to support the corresponding capability.

It consists of a single interface class, permitting an application to perform the following:

- User location requests.
- Requests for starting (or stopping) the generation by the network of periodic user location reports.
- Requests for starting (or stopping) the generation by the network of user location reports based on location changes.

Method **locationReportReq()**

Request for mobile-related location information on one or several users.

Direction Application to network

Parameters **appLocationCamel**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to Authentication interface).

users

Specifies the user(s) for which the location shall be reported.

Returns **assignmentID**

Specifies the assignment ID of the location-report request.

Errors **INVALID_PARAMETER_VALUE**

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **locationReportRes()**

Delivery of a mobile location report. The report is containing mobile-related location information for one or several users.

Direction Network to application

Parameters **assignmentID**
Specifies the assignment ID of the location-report request.

locations
Specifies the location(s) of one or several users.

Returns -

Errors **INVALID_PARAMETER_VALUE**
A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID
The assignment ID does not correspond to one of a valid assignment.

Method **locationReportErr()**
This method indicates that the location report request has failed.

Direction Network to application

Parameters **assignmentID**
Specifies the assignment ID of the failed location report request.

cause
Specifies the error that led to the failure.

diagnostic
Specifies additional information about the error that led to the failure

Returns -

Errors -

Method **periodicLocationReportingStartReq()**
Request for periodic mobile location reports on one or several users.

Direction Application to network

Parameters **appLocation**
If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to Authentication interface).

users
Specifies the user(s) for which the location shall be reported.

reportingInterval

Specifies the requested interval in seconds between the reports.

Returns

assignmentID

Specifies the assignment ID of the periodic location-reporting request.

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

periodicLocationReportingStop()

This method stops the sending of periodic mobile location reports for one or several users.

Direction

Application to network

Parameters

stopRequest

Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.

Returns

-

Errors

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method

periodicLocationReport()

Periodic delivery of mobile location reports. The reports are containing mobile-related location information for one or several users.

Direction

Network to application

Parameters

assignmentID

Specifies the assignment ID of the periodic location-reporting request.

locations

Specifies the location(s) of one or several users.

Returns

-

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method

periodicLocationReportErr ()

This method indicates that a requested periodic location report has failed. Note that errors only concerning individual users are reported in the ordinary periodicLocationReport() message.

Direction

Network to application

Parameters

assignmentID

Specifies the assignment ID of the failed periodic location reporting start request.

cause

Specifies the error that led to the failure.

diagnostic

Specifies additional information about the error that led to the failure.

Returns

-

Errors

-

Method

triggeredLocationReportingStartReq ()

Request for user location reports, containing mobile related information, when the location is changed (the report is triggered by the location change, e.g. change of VLR number, change of Global Cell Identification).

Direction

Application to network

Parameters

appLocation

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the obtainInterface () method (refer to Authentication interface).

users

Specifies the user(s) for which the location shall be reported.

triggers

Specifies the trigger conditions.

Returns

assignmentID

Specifies the assignment ID of the triggered location-reporting request.

Errors	<p>INVALID_PARAMETER_VALUE A method parameter has an invalid value.</p> <p>NO_CALLBACK_ADDRESS_SET The requested method has been refused, because no callback address is set.</p> <p>RESOURCES_UNAVAILABLE The required resources in the network are not available. The application may try to invoke the method at a later time.</p> <p>USER_NOT_SUBSCRIBED Returned if the end-user is not subscribed to the application</p> <p>APPLICATION_NOT_ACTIVATED Returned if the end-user has de-activated the application</p> <p>USER_PRIVACY_VIOLATION Returned if the requests violates the end-user's privacy setting</p>
Method	<p>triggeredLocationReportingStop() Request that triggered mobile location reporting should stop.</p>
Direction	Application to network
Parameters	<p>stopRequest Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.</p>
Returns	-
Errors	<p>INVALID_ASSIGNMENT_ID The assignment ID does not correspond to one of a valid assignment</p>
Method	<p>triggeredLocationReport() Delivery of a report that is indicating that one or several user's mobile location has changed.</p>
Direction	Network to application
Parameters	<p>assignmentID Specifies the assignment ID of the triggered location-reporting request.</p> <p>location Specifies the location of the user.</p> <p>criterion Specifies the criterion that triggered the report.</p>
Returns	-

Errors	INVALID_PARAMETER_VALUE A method parameter has an invalid value.
	INVALID_ASSIGNMENT_ID The assignment ID does not correspond to one of a valid assignment.
Method	triggeredLocationReportErr() This method indicates that a requested triggered location report has failed. Note that errors only concerning individual users are reported in the ordinary triggeredLocationReport() message.
Direction	Network to application
Parameters	assignmentID Specifies the assignment ID of the failed triggered location reporting start request. cause Specifies the error that led to the failure. diagnostic Specifies additional information about the error that led to the failure.
Returns	-
Errors	-

7.3 User Status

The User Status service capability feature provides general user status monitoring. It allows applications to obtain the status of the user's terminal. It consists of a single interface class.

Method	statusReportReq() Request for a report on the status of one or several users.
Direction	Application to network
Parameters	appStatus If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the obtainInterface() method (refer to Authentication interface). users Specifies the user(s) for which the status shall be reported.
Returns	assignmentID Specifies the assignment ID of the status-report request.

Errors	INVALID_PARAMETER_VALUE
	A method parameter has an invalid value.
	NO_CALLBACK_ADDRESS_SET
	The requested method has been refused, because no callback address is set.
	RESOURCES_UNAVAILABLE
	The required resources in the network are not available. The application may try to invoke the method at a later time.
USER_NOT_SUBSCRIBED	
Returned if the end-user is not subscribed to the application	
APPLICATION_NOT_ACTIVATED	
Returned if the end-user has de-activated the application	
USER_PRIVACY_VIOLATION	
Returned if the requests violates the end-user's privacy setting	

Method **statusReportRes ()**
 Delivery of a report, that is containing one or several user's status.

Direction Network to application

Parameters **assignmentID**
 Specifies the assignment ID of the status-report request.

status
 Specifies the status of one or several users.

Returns -

Errors

INVALID_PARAMETER_VALUE
A method parameter has an invalid value.
INVALID_ASSIGNMENT_ID
The assignment ID does not correspond to one of a valid assignment.

Method **statusReportErr ()**
 This method indicates that the status report request has failed.

Direction Network to application

Parameters **assignmentID**
Specifies the assignment ID of the failed status report request.

cause
 Specifies the error that led to the failure.

diagnostic

Specifies additional information about the error that led to the failure.

Returns

-

Errors

-

Method**triggeredStatusReportingStartReq()**

Request for triggered status reports when one or several user's status is changed. The user status SCF will send a report when the status changes.

Direction

Application to network

Parameters**appStatus**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to Authentication interface).

users

Specifies the user(s) for which the status changes shall be reported.

Returns**assignmentID**

Specifies the assignment ID of the triggered status-reporting request.

Errors**INVALID_PARAMETER_VALUE**

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method**triggeredStatusReportingStop()**

This method stops the sending of status reports for one or several users.

Direction

Application to network

Parameters **stopRequest**
 Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.

Returns -

Errors **INVALID_ASSIGNMENT_ID**
 The assignment ID does not correspond to one of a valid assignment.

Method **triggeredStatusReport()**
 Delivery of a report that is indicating that a user's status has changed.

Direction Network to application

Parameters **assignmentID**
 Specifies the assignment ID of the triggered status-reporting request.

status
 Specifies the status of the user.

Returns -

Errors **INVALID_PARAMETER_VALUE**
 A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID
 The assignment ID does not correspond to one of a valid assignment.

Method **triggeredStatusReportErr()**
 This method indicates that a requested triggered status reporting has failed. Note that errors only concerning individual users are reported in the ordinary triggeredStatusReport() message.

Direction Network to application

Parameters **assignmentID**
 Specifies the assignment ID of the failed triggered status reporting start request.

cause
 Specifies the error that led to the failure.

diagnostic
 Specifies additional information about the error that led to the failure.

Returns -

Errors -

7.4 Terminal Capabilities

It shall be possible for an application to request Terminal Capabilities as defined by MExE [3]. The terminal capabilities are provided by a MExE compliant terminal to the MExE Service Environment either on request or by the terminal itself.

Terminal Capabilities are available only after a Capability negotiation has previously taken place between the user's MExE terminal and the MExE Service environment as specified in [3].

Note: for Release 99 only WAP MExE devices can supply terminal capabilities.

The Terminal Capabilities service capability feature is supported by a unique interface class, which consists of the following method.

The Terminal Capabilities service capability feature is supported by a unique interface class, which consists of the following method.

Method **getTerminalCapabilities()**

This method is used by an application to get the capabilities of a user's terminal.

Direction Application to Network

Parameters **terminalIdentity**
Identifies the terminal. It may be a logical address known by the WAP Gateway/PushProxy.

Returns **statusCode**
Indicates whether or not the terminal capabilities are available.

terminalCapabilities
Specifies the latest available capabilities of the user's terminal. This information, if available, is returned as CC/PP headers as specified in W3C [12] and adopted in the WAP UAProf specification [13]. It contains URLs; terminal attributes and values, in RDF format; or a combination of both.

Errors -

7.5 Message Transfer

7.5.1 Generic User Interaction

The Generic User Interaction service capability feature is used by applications to interact with end users. It consists of two interface classes:

1. User Interaction Manager, containing management functions for User Interaction related issues
2. Generic User Interaction, containing methods to interact with an end-user

The Generic User Interaction service capability feature is described in terms of the methods in the Generic User Interaction interface classes.

The following table gives an overview of the Generic User Interaction methods and to which interface classes these methods belong.

User Interaction Manager	Generic User Interaction
createUI	sendInfoReq
createUICall	sendInfoRes
enableUINotification	sendInfoErr
disableUINotification	sendInfoAndCollectReq
userInteractionEventNotify	sendInfoAndCollectRes
userInteractionAborted	sendInfoAndCollectErr
	release
	userInteractionFaultDetected

Table 32 Overview of Generic User Interaction interface classes and their methods

User Interaction Manager

Inherits from the generic service interface.

The User Interaction Manager interface class provides the management functions to the User Interaction class interface.

Method **createUI ()**

This method is used to create a new (non call related) user interaction object.

Direction Application to network

Parameters **appUI**

Specifies the application interface for callbacks from the user interaction created.

userAddress

Indicates the end-user whom to interact with

Returns **userInteraction**

Specifies the interface and sessionID of the user interaction created.

Errors **USER_NOT_SUBSCRIBED**

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **createUICall ()**

This method is used to create a new call related user interaction object.

The user interaction can take place to the specified party (`userAddress`) or to all parties in a call (`callIdentifier`). Only one of `callIdentifier` or `userAddress` may be defined (the other should be set to `NULL`).

Note that for certain implementations user interaction can only be performed towards the controlling call party, which shall be the only party in the call.

Direction Application to network

Parameters **appUI**

Specifies the application interface for callbacks from the user interaction created.

callIdentifier

Specifies the call interface and session ID of the call associated with the send info operation.

callLegIdentifier

Indicates the end-user whom to interact with

Returns

userInteraction

Specifies the interface and sessionID of the user interaction created.

Errors

Method **enableUINotification()**

This method is used to enable the reception of user initiated user interaction.

Direction Application to network

Parameters **appInterface**

If this parameter is set (i.e. not `NULL`) it specifies a reference to the application interface, which is used for callbacks. If set to `NULL`, the application interface defaults to the interface specified via the `setCallback()` method.

eventCriteria

Specifies the event specific criteria used by the application to define the event required, like user address and service code.

Returns

assignmentID

Specifies the ID assigned for this newly-enabled event notification.

Errors

Method **disableUINotification()**

This method allows the application to remove notification for UI related actions previously set.

Direction Application to network

Parameters **assignmentID**

Specifies the assignment ID given by the user interaction manager interface when the previous `enableNotification()` was called. If the assignment ID does not correspond to one of the valid assignment IDs, the framework will return an error code.

Returns

Errors**Method** **userInteractionEventNotify()**

This method notifies the application of a user initiated request for user interaction.

Direction Network to Application

Parameters **ui**

Specifies the reference to the interface and the sessionID to which the notification relates.

eventInfo

Specifies data associated with this event.

assignmentID

Specifies the assignment id which was returned by the `enableNotification()` method. The application can use assignment id to associate events with event specific criteria and to act accordingly.

Returns **appInterface**

Specifies the application interface for callbacks from the user interaction created.

Errors**Method** **userInteractionAborted()**

This method indicates to the application that the User Interaction SCF instance has terminated or closed abnormally. No further communication will be possible between the User Interaction SCF instance and application.

Direction Network to Application

Parameters **userInteraction**

Specifies the interface and sessionID of the user interaction SCF that has terminated.

Returns

Errors**Generic User Interaction**

Inherits from the generic service interface. The Generic User Interaction interface class provides functions to send information or data to, or gather information from, the user (or call party). The information to send can be an announcement or a text. The data downloaded in the terminal is specified by a URL.

Method **sendInfoReq()**

This asynchronous method sends information to the user.

Direction Application to Network

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

info

Specifies the information to send to the user. This information can be:

- an infoID, identifying pre-defined information to be send (announcement and/or text);
- a string, defining the text to be sent;
- a URL , identifying pre-defined information or data to be sent to or downloaded into the terminal

variableInfo

Defines the variable part of the information to send to the user.

repeatIndicator

Defines how many times the information shall be send to the end-user. In the case of a call related user interaction, a value of zero (0) indicates that the announcement shall be repeated until the call or call leg is released or an abortActionReq() is sent.

responseRequested

Specifies if a response is required from the call user interaction SCF, and any action the SCF should take.

Returns**assignmentID**

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

Errors**Method** **sendInfoRes ()**

This asynchronous method informs the application about the start or the completion of a sendInfoReq(). This response is called only if the application has required a response.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

response

Specifies the type of response received from the user.

Returns**Errors****Method** **sendInfoErr ()**

This asynchronous method indicates that the request to send information was unsuccessful.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

error

Specifies the error which led to the original request failing.

Returns

Errors

Method **sendInfoAndCollectReq()**

This asynchronous method plays an announcement or sends other information to the user and collects some information from the user. The announcement usually prompts for a number of characters (for example, these are digits or text strings such as "YES" if the user's terminal device is a phone).

Direction Application to Network

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

infoID

Specifies ~~the ID of~~ the information to send to the user.

variableInfo

Defines the variable part of the information to send to the user.

criteria

Specifies additional properties for the collection of information, such as the maximum and minimum number of characters, end character, first character timeout and inter-character timeout.

responseRequested

Specifies if a response is required from the call user interaction SCF, and any action the SCF should take.

Returns

assignmentID

Specifies the ID assigned by the generic user interface

Errors

Method **sendInfoAndCollectRes()**

This asynchronous method returns the information collected to the application.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

response

Specifies the type of response received from the user.

info

Specifies the information collected from the user.

Returns

Errors

Method **sendInfoAndCollectErr ()**

This asynchronous method indicates that the request to send information and collect a response was unsuccessful.

Direction Network to Application

Parameters **userInteractionSessionID**
Specifies the user interaction session ID of the user interaction.

assignmentID

Specifies the ID assigned by the generic user interaction interface for a user interaction request.

error

Specifies the error which led to the original request failing.

Returns

Errors

Method **release ()**

This method requests that the relationship between the application and the user interaction object be released. It causes the release of the used user interaction resources and interrupts any ongoing user interaction.

Direction Application to Network

Parameters **userInteractionSessionID**
Specifies the user interaction session ID of the user interaction.

Returns

Errors

Method **userInteractionFaultDetected ()**

This method indicates to the application that a fault has been detected in the user interaction.

Direction Network to Application

Parameters **userInteractionSessionID**
 Specifies the interface and sessionID of the user interaction SCF in which the fault has been detected.

fault
 Specifies the fault that has been detected.

Returns .

Errors

7.5.2 Call User Interaction

The Call User Interaction service capability feature is used by applications to interact with end users participating to a call. It consists of two interface classes:

1. User Interaction Manager, containing management functions for User Interaction related issues. This class is the same as the one defined in section 7.5.1.
2. Call User Interaction, extending Generic User Interaction for call-specific user interaction. It provides functions to send information to, or gather information from, a user (or call party) in a call.

The Call User Interaction service capability feature is described in terms of the methods in the Call User Interaction interface classes.

The following table gives an overview of the Call User Interaction methods and to which interface classes these methods belong.

User Interaction Manager	Call User Interaction
<i>As defined for the Generic User Interaction SCF</i>	<i>Inherits from Generic User Interaction and adds:</i>
	abortActionReq
	abortActionRes
	abortActionErr

Table 43 Overview of Call User Interaction interface classes and their methods

Method **abortActionReq()**
 This asynchronous method aborts a user interaction operation, e.g. a `sendInfoCall_Req()`. The call and call leg are otherwise unaffected. The call user interaction SCF interrupts the indicated action.

Direction Application to Network

Parameters **userInteractionSessionID**
 Specifies the user interaction session ID of the user interaction.

assignmentID : TAssignmentID
 Specifies the user interaction request to be cancelled.

Returns

Errors**Method** **abortActionRes ()**

This asynchronous method confirms that the request to abort a user interaction operation on a call leg was successful.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID : TAssignmentID

Specifies the user interaction request to be cancelled.

Returns**Errors****Method** **abortActionErr ()**

This asynchronous method indicates that the request to abort a user interaction operation on a call leg resulted in an error.

Direction Network to Application

Parameters **userInteractionSessionID**

Specifies the user interaction session ID of the user interaction.

assignmentID : TAssignmentID

Specifies the user interaction request to be cancelled.

error

Specifies the error which led to the original request failing.

Returns**Errors**

7.6 User Profile Management

User Profile information may be distributed between the Home Environment and the Home Environment Value-Added Services Providers. The HE-VASP may manage information specific to the services supported by their OSA applications. For this, they may use models and mechanisms, which are out of the scope of OSA release 99.

Home Environment User Profile information consists of various interface and service related information. Of particular interest in the context of release 99 is the following information:

- list of services to which the end-user is subscribed
- service status (active/inactive)
- privacy status with regards to network service capabilities (e.g. user location, user interaction)
- terminal capabilities

Home Environment user profile information may be stored centrally, or the information may be distributed over relevant physical entities.

Terminal capabilities may be accessed by OSA applications through the network Terminal Capabilities SCF.

History

Date	Version	Comment
July 1999	0.1.0	Initial Draft produced in Hazlet, New Jersey, USA
September 1999	0.2.0	Version presented to S2 plenary in Bonn, Germany (not including all agreed changes yet from VHE/OSA adhoc session)
September 1999	0.2.1	Output of Bonn meeting (Presented to SA for information, since V1.0.0 was not available due to 3GPP e-mail exploder problems).
October 1999	0.3.0	Version sent to S2 e-mail list and proposed to send to SA plenary
October 1999	0.3.1	Small editorial updates in Interface section (subclauses 6 and 7)
October 1999	1.0.0	Version 0.3.1 raised to V1.0.0 by S2 e-mail approval and sent to SA e-mail list for information
November 1999	1.1.0	Updated after comments in S2#9 according to S2-99C06 (S2-99B32, S2-99B33 and S2-99B36)
December 1999	1.1.1	Updated after drafting session in Munich, approved in S2#11
February 2000	1.2.0	Updated after S2#11 according to S2-000230 (S2-000081, S2-000146, S2-000148, S2-000172, S2-000187, S2-000188, S2-000189, S2-000202, S2-000203) and with various minor editorial changes
February 2000	1.3.0	Updated during OSA interim session in Stockholm (February 23-24) and consolidated the week after.
March 2000	1.4.0	Updated during OSA drafting session in S2#12 according to S2-000500 and S2-000355.
March 2000	2.0.0	Editorial changes compared to 1.4.0. Presented to SA#7 for approval.
March 2000	3.0.0	Output of SA#7. Minor editorial changes compared to v.2.0.0.
Rapporteur: Christophe Gourraud, Ericsson Email: christophe.gourraud@lmc.ericsson.se Telephone: +1 514 345 7900 (#5795)		

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 004

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
list expected approval meeting # here ↑

for approval
for information

strategic
non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
(at least one should be marked with an X)

Source: Ericsson **Date:** 22.5.2000

Subject: Removal of data-related parameters in call control SCF

Work item: VHE/OSA

Category: <small>(only one category shall be marked with an X)</small>	F Correction	<input type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input checked="" type="checkbox"/>		Release 98	<input type="checkbox"/>
D Editorial modification	<input type="checkbox"/>	Release 99	<input checked="" type="checkbox"/>		
			Release 00	<input type="checkbox"/>	

Reason for change: During the joint meeting between N5 and VHE/OSA S2 experts in Stockholm (May 10th), it was agreed that, though technically feasible, it was not desirable to have OSA supporting data (e.g. GPRS) related charging via the call control SCF. From a service developer perspective, it is better to have data sessions and voice calls capabilities supported by different APIs. As a consequence, it is proposed to remove data-specific parameters from call control-related interfaces.

Clauses affected: 7.1.2

Other specs affected:	Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
	Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
	MS test specifications	<input type="checkbox"/>	→ List of CRs:	
	BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
	O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



<----- double-click here for help and instructions on how to create a CR.

7.1.2 Call

The generic call interface class provides a structure to allow simple and complex call behaviour to be used.

Method **routeCallToDestination_Req()**

This asynchronous method requests routing of the call (and inherently attached parties) to the destination party (specified in the parameter `TargetAddress`). The destination party is attached to the call via a passive leg. This means that the call is not automatically released if the destination party disconnects from the call; only the leg with which the destination party was attached to the call is released in that case. .

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

responseRequested

Specifies the set of observed events that will result in a `routeCallToDestination_Res()` being generated.

targetAddress

Specifies the destination party to which the call should be routed.

originatingAddress

Specifies the address of the originating (calling) party.

originalDestinationAddress

Specifies the original destination address of the call, i.e. the address as specified by the originating party. This parameter should be equal to the `originalDestinationAddress` as received by the application in the `eventInfo` parameter of the `callEventNotify` method.

redirectingAddress

Specifies the last address from which the call was redirected.

appInfo

Specifies application-related information pertinent to the call (such as alerting method, tele-service type, service identities and interaction indicators).

assignmentID

Specifies the ID assigned by the network SCS. The same ID will be returned in the `routeCallToDestinationRes` or `Err`. This allows the application to correlate the request and the result.

Returns -

Errors **USER_NOT_SUBSCRIBED**

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **routeCallToDestination_Res()**

This asynchronous method indicates that the request to route the call to the destination was successful, and indicates the response of the destination party (for example, the call was answered, not answered, refused due to busy, etc.).

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

eventReport

Specifies the result of the request to route the call to the destination party. It also includes the mode that the call object is in and other related information.

Returns -

Errors -

Method **routeCallToDestination_Err()**

This asynchronous method indicates that the request to route the call to the destination party was unsuccessful - the call could not be routed to the destination party (for example, the network was unable to route the call, the parameters were incorrect, the request was refused, etc.).

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

errorIndication

Specifies the error which led to the original request failing.

Returns -

Errors -

Method **release()**

This method requests the release of the call and associated objects.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

cause

Specifies the cause of the release.

Returns -

Errors -

Method **deassignCall()**

This method requests that the relationship between the application and the call and associated object be de-assigned. It leaves the call in progress, however, it purges the specified call object so that the application has no further control of call processing. If a call is de-assigned that has event reports or call information reports requested, then these reports will be disabled and any related information discarded.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

Returns -

Errors -

Method **getCallInfo_Req()**

This asynchronous method requests information associated with the call to be provided at the appropriate time (for example, to calculate charging). This method must be invoked before the call is routed to a target address. The call object will exist after the call is ended if information is required to be sent to the application at the end of the call. The call information will be sent after any call event reports.

Note: At the end of the call, the call information must be sent before the call is deleted.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoRequested
Specifies the call information that is requested.

Returns -

Errors -

Method **getCallInfo_Res()**

This asynchronous method reports all the necessary information requested by the application, for example to calculate charging.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoReport
Specifies the call information requested.

Returns -

Errors -

Method **getCallInfo_Err ()**

This asynchronous method reports that the original request was erroneous, or resulted in an error condition.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **superviseCall_Req ()**

The application calls this method to supervise a call. The application can set a granted connection time for this call. If an application calls this function before it calls a `routeCallToDestination_Req ()` or a user interaction function the time measurement will start as soon as the call is answered by the B-party or the user interaction system.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

time
Specifies the granted time in milliseconds for the connection. ~~When specified as 0, volume based supervision is applied. Either bytes (volume) or time should be specified.~~

treatment
Specifies how the network should react after the granted connection time expired.

bytes
~~Specifies the granted number of bytes that can be transmitted for the connection. When the quantity is specified as 0, time based supervision is applied. Either bytes (volume) or time should be specified.~~

Returns -

Errors -

Method **superviseCall_Res ()**

This asynchronous method reports a call supervision event to the application.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

report

Specifies the situation, which triggered the sending of the call supervision response.

usedTime

Specifies the used time for the call supervision (in milliseconds).

usedVolume

~~Specifies the used volume for the call supervision (in the same units as specified in the request).~~

Returns -

Errors -

Method **superviseCall_Err()**

This asynchronous method reports a call supervision error to the application.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **callFaultDetected()**

This method indicates to the application that a fault has been detected in the call.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call object in which the fault has been detected.

fault
Specifies the fault that has been detected.

Returns -

Errors -

Method **setAdviceOfCharge()**

This method allows the application to the charging information that will be send to the end-users handset.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

aOCInfo

Specifies two sets of Advice of Charge parameter according to GSM

tariffSwitch

Specifies the tariff switch that signifies when the second set of AoC parameters becomes valid.

Returns -

Errors -

Method **setCallChargePlan()**

Allows an application to include charging information in network generated CDR.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

callDetailRecordInfo

Free Format string containing the application specific charging information

Returns -

Errors -

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 005

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
 list expected approval meeting # here ↑

for approval
 for information

strategic
 non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
 (at least one should be marked with an X)

Source: Ericsson, Nokia, Siemens **Date:** 22.5.2000

Subject: Replacement of "Camel" by "Network" in Network User Location SCF parameter names

Work item: VHE/OSA

Category: <small>(only one category shall be marked with an X)</small>	F Correction	<input checked="" type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input type="checkbox"/>		Release 98	<input type="checkbox"/>
D Editorial modification	<input type="checkbox"/>	Release 99	Release 99	<input checked="" type="checkbox"/>	
			Release 00	<input type="checkbox"/>	

Reason for change: The Network User Location SCF is independent from the underlying network technology used to provide this location information, even if it is CAMEL in R99. As a consequence, the string "Camel" should not appear in the "appLocationCamel" parameter name, which should be changed to "appNetworkLocation".

Additionally, for alignment between stage 2 and stage 3, "appNetworkLocation" is proposed to be used as parameter name in two other methods similar to locationReportReq.

Clauses affected: 7.2

Other specs affected:

Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
MS test specifications	<input type="checkbox"/>	→ List of CRs:	
BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



help.doc

<----- double-click here for help and instructions on how to create a CR.

7.2 Network User Location

The Network User Location service capability feature provides terminal location information, based on network-related information, such as a VLR Number, Location Area Identification, or Cell Global Identification. It may also provide geographical location information, if the network is able to support the corresponding capability.

It consists of a single interface class, permitting an application to perform the following:

- User location requests.
- Requests for starting (or stopping) the generation by the network of periodic user location reports.
- Requests for starting (or stopping) the generation by the network of user location reports based on location changes.

Method **locationReportReq()**

Request for mobile-related location information on one or several users.

Direction Application to network

Parameters **appNetworkLocationCamel**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface()` method (refer to Authentication interface).

users

Specifies the user(s) for which the location shall be reported.

Returns **assignmentId**

Specifies the assignment ID of the location-report request.

Errors **INVALID_PARAMETER_VALUE**

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method **locationReportRes ()**

Delivery of a mobile location report. The report is containing mobile-related location information for one or several users.

Direction Network to application

Parameters **assignmentId**
Specifies the assignment ID of the location-report request.

locations
Specifies the location(s) of one or several users.

Returns -

Errors **INVALID_PARAMETER_VALUE**
A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID
The assignment ID does not correspond to one of a valid assignment.

Method **locationReportErr ()**

This method indicates that the location report request has failed.

Direction Network to application

Parameters **assignmentId**
Specifies the assignment ID of the failed location report request.

cause
Specifies the error that led to the failure.

diagnostic
Specifies additional information about the error that led to the failure

Returns -

Errors -

Method **periodicLocationReportingStartReq ()**

Request for periodic mobile location reports on one or several users.

Direction Application to network

Parameters **appNetworkLocation**
If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `obtainInterface ()` method (refer to

Authentication interface).

users

Specifies the user(s) for which the location shall be reported.

reportingInterval

Specifies the requested interval in seconds between the reports.

Returns

assignmentId

Specifies the assignment ID of the periodic location-reporting request.

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

periodicLocationReportingStop()

This method stops the sending of periodic mobile location reports for one or several users.

Direction

Application to network

Parameters

stopRequest

Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.

Returns

-

Errors

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method

periodicLocationReport()

Periodic delivery of mobile location reports. The reports are containing mobile-related location information for one or several users.

Direction Network to application

Parameters **assignmentId**
Specifies the assignment ID of the periodic location-reporting request.

locations
Specifies the location(s) of one or several users.

Returns -

Errors **INVALID_PARAMETER_VALUE**
A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID
The assignment ID does not correspond to one of a valid assignment.

Method **periodicLocationReportErr ()**

This method indicates that a requested periodic location report has failed. Note that errors only concerning individual users are reported in the ordinary periodicLocationReport() message.

Direction Network to application

Parameters **assignmentId**
Specifies the assignment ID of the failed periodic location reporting start request.

cause
Specifies the error that led to the failure.

diagnostic
Specifies additional information about the error that led to the failure.

Returns -

Errors -

Method **triggeredLocationReportingStartReq ()**

Request for user location reports, containing mobile related information, when the location is changed (the report is triggered by the location change, e.g. change of VLR number, change of Global Cell Identification).

Direction Application to network

Parameters **appNetworkLocation**
If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the obtainInterface() method (refer to Authentication interface).

users
Specifies the user(s) for which the location shall be reported.

triggers

Specifies the trigger conditions.

Returns**assignmentId**

Specifies the assignment ID of the triggered location-reporting request.

Errors**INVALID_PARAMETER_VALUE**

A method parameter has an invalid value.

NO_CALLBACK_ADDRESS_SET

The requested method has been refused, because no callback address is set.

RESOURCES_UNAVAILABLE

The required resources in the network are not available.
The application may try to invoke the method at a later time.

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method**triggeredLocationReportingStop()**

Request that triggered mobile location reporting should stop.

Direction

Application to network

Parameters**stopRequest**

Specifies how the assignment shall be stopped, i.e. if whole or just parts of the assignment should be stopped.

Returns

-

Errors**INVALID_ASSIGNMENT_ID**

The assignment ID does not correspond to one of a valid assignment

Method**triggeredLocationReport()**

Delivery of a report that is indicating that one or several user's mobile location has changed.

Direction

Network to application

Parameters**assignmentId**

Specifies the assignment ID of the triggered location-reporting request.

location

Specifies the location of the user.

criterion

Specifies the criterion that triggered the report.

Returns

-

Errors

INVALID_PARAMETER_VALUE

A method parameter has an invalid value.

INVALID_ASSIGNMENT_ID

The assignment ID does not correspond to one of a valid assignment.

Method

triggeredLocationReportErr ()

This method indicates that a requested triggered location report has failed. Note that errors only concerning individual users are reported in the ordinary triggeredLocationReport() message.

Direction

Network to application

Parameters

assignmentId

Specifies the assignment ID of the failed triggered location reporting start request.

cause

Specifies the error that led to the failure.

diagnostic

Specifies additional information about the error that led to the failure.

Returns

-

Errors

-

DRAFT

**3GPP Meeting SA2 #13
Berlin, Germany, 22-26 May 2000**

Document S2-000964

e.g. for 3GPP use the format TP-99xxx
or for SMG, use the format P-99-xxx

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 006R1

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
list expected approval meeting # here ↑

for approval
for information

strategic
non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
(at least one should be marked with an X)

Source: Ericsson **Date:** 18 May 2000

Subject: Introduction of improved notification mechanism

Work item: VHE/OSA

Category: <small>(only one category shall be marked with an X)</small>	F Correction	<input type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input checked="" type="checkbox"/>		Release 98	<input type="checkbox"/>
	D Editorial modification	<input type="checkbox"/>		Release 99	<input checked="" type="checkbox"/>
			Release 00	<input type="checkbox"/>	

Reason for change:
The mechanism for indicating that the event notification from the Call Control SCS to the application has been stopped was agreed in CN5 to be extended with a method indicating that the event notification has been started again. Proposed was to rename the callNotificationTerminated() method on the AppCallControlManager to callNotificationInterrupted() and add a method callNotificationContinued(). Because the same mechanism is applicable to User Interaction, proposed was to add the methods userInteractionTerminated() and userInteractionContinued() to the AppUIManager.

Clauses affected: 7.1, 7.1.1, 7.5.1

Other specs affected:	Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
	Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
	MS test specifications	<input type="checkbox"/>	→ List of CRs:	
	BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
	O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



<----- double-click here for help and instructions on how to create a CR.

7.1 Call Control

The Call control network service capability feature consists of two interface classes:

1. Call manager, containing management function for call related issues
2. Call, containing methods to control a call

A call can be controlled by one Call Manager only. A Call Manager can control several calls..




Figure 6 Call control classes usage relationship

The Call Control service capability features are described in terms of the methods in the Call Control interface classes. Table 1 gives an overview of the Call Control methods and to which interface classes these methods belong.

CallManager	Call
enableCallNotification	routeCallToDestinationReq
disableCallNotification	routeCallToDestinationRes
callEventNotify	routeCallToDestinationErr
callAborted	release
callNotificationInterruptedTerminated	deassignCall
callNotificationResumed	getCallInfoReq
	getCallInfoRes
	getCallInfoErr
	superviseCallReq
	SuperviseCallRes
	superviseCallErr
	callFaultDetected
	setAdviceOfCharge
	setCallChargePlan

Table 1_ Overview of Call Control interface classes and their methods

7.1.1 Call Manager

....

Method **callNotificationInterruptedTerminated()**

~~This method indicates to the application that all event notifications have been terminated (for example, due to faults detected).~~ This method indicates to the application that all event notifications have been temporary interrupted (for example, due to faults detected).
 Note that more permanent failures are reported via the Framework (integrity management).

Direction Network to application

Parameters -

Returns -

Errors -

Method **callNotificationContinued()**

This method indicates to the application that event notifications will again be possible.

Direction Network to application

Parameters =

Returns =

Errors =

7.5.1 Generic User Interaction

The Generic User Interaction service capability feature is used by applications to interact with end users. It consists of two interfaces:

1. User Interaction Manager, containing management functions for User Interaction related issues
2. Generic User Interaction, containing methods to interact with an end-user

The Generic User Interaction service capability feature is described in terms of the methods in the Generic User Interaction interfaces.

The following table gives an overview of the Generic User Interaction methods and to which interfaces these methods belong.

User Interaction Manager	Generic User Interaction
createUI	sendInfoReq
createUICall	sendInfoRes
enableUINotification	sendInfoErr
disableUINotification	sendInfoAndCollectReq
userInteractionEventNotify	sendInfoAndCollectRes
userInteractionAborted	sendInfoAndCollectErr
<u>userInteractionNotificationInterrupted</u>	release
<u>userInteractionNotificationContinued</u>	userInteractionFaultDetected

Table 2 Overview of Generic User Interaction interfaces and their methods

User Interaction Manager

...

Method **userInteractionNotificationInterrupted()**

This method indicates to the application that all event notifications have been temporary interrupted (for example, due to faults detected).

Note that more permanent failures are reported via the Framework (integrity management).

Direction Network to application

Parameters =

Returns =

Errors =

Method **userInteractionNotificationContinued()**

This method indicates to the application that event notifications will again be possible.

Direction Network to application

Parameters =

Returns =

Errors =

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 008R1

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
 list expected approval meeting # here ↑

for approval
 for information

strategic
 non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
 (at least one should be marked with an X)

Source: Siemens **Date:** 22.5.2000

Subject: Modification of call control

Work item: VHE/OSA

Category: <small>(only one category shall be marked with an X)</small>	F Correction	<input type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input checked="" type="checkbox"/>		Release 98	<input type="checkbox"/>
D Editorial modification	<input type="checkbox"/>	Release 99	<input checked="" type="checkbox"/>		
			Release 00	<input type="checkbox"/>	

Reason for change: The following changes are proposed for the call control SCF:

- rename routeCallToDestination to routeReq due to JAIN alignment.
- add changeCallNotification() and getCriteria() for a better means to modify call notification triggers.
- remove volume based charging, following the decision not to use the call interface for data sessions
- add clarification to superviseCall_Req
- align setCallChargePlan with N5 work.

Clauses affected: 7.1

Other specs affected:	Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
	Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
	MS test specifications	<input type="checkbox"/>	→ List of CRs:	
	BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
	O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



help.doc

<----- double-click here for help and instructions on how to create a CR.

7.1 Call Control

The Call control network service capability feature consists of two interface classes:

1. Call manager, containing management function for call related issues
2. Call, containing methods to control a call

A call can be controlled by one Call Manager only. A Call Manager can control several calls..




Figure 6 Call control classes usage relationship

The Call Control service capability features are described in terms of the methods in the Call Control interface classes. Table 1 gives an overview of the Call Control methods and to which interface classes these methods belong.

CallManager	Call
enableCallNotification	routeReq
disableCallNotification	routeRes
callNotificationTerminated	routeErr
callEventNotify	release
callAborted	deassignCall
callNotificationTerminated	getCallInfo_Req
changeCallNotification	getCallInfo_Res
getCriteria	getCallInfo_Err
	superviseCall_Req
	SuperviseCall_Res
	superviseCall_Err
	callFaultDetected
	setAdviceOfCharge
	setCallChargePlan

Table 1 Overview of Call Control interface classes and their methods

7.1.1 Call Manager

The generic call manager interface class provides the management functions to the generic call Service Capability Features. The application programmer can use this interface class to create call objects and to enable or disable call-related event notifications.

Method **enableCallNotification()**

This method is used to enable call notifications to be sent to the application.

Direction Application to network

- Parameters** **appInterface**
If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `setCallback()` method.
- eventCriteria**
Specifies the event specific criteria used by the application to define the event required. Examples of events are “incoming call attempt reported by network”, “answer”, “no answer”, “busy”.
- Returns** **assignmentID**
Specifies the ID assigned by the generic call control manager object for this newly-enabled event notification.
- Errors** **USER_NOT_SUBSCRIBED**
Returned if the end-user is not subscribed to the application
- APPLICATION_NOT_ACTIVATED**
Returned if the end-user has de-activated the application
- USER_PRIVACY_VIOLATION**
Returned if the requests violates the end-user’s privacy setting
- Method** **changeCallNotification()**
This method is used to change the notification criteria initially set with `enableCallNotification()`.
- Direction** Application to network
- Parameters** **eventCriteria**
Overrides the set of event criteria initially defined with `enableCallNotification()`.
- assignmentID**
Specifies the ID returned with `enableCallNotification()`.
- Returns**
- Errors** **USER_NOT_SUBSCRIBED**
Returned if the end-user is not subscribed to the application
- APPLICATION_NOT_ACTIVATED**
Returned if the end-user has de-activated the application
- USER_PRIVACY_VIOLATION**
Returned if the requests violates the end-user’s privacy setting
- Method** **disableCallNotification()**
This method is used by the application to disable call notifications.
- Direction** Application to network
- Parameters** **eventCriteria**

Specifies the event specific criteria used by the application to define the event to be disabled. Examples of events are “incoming call attempt reported by network”, “answer”, “no answer”, “busy”.

assignmentID

Specifies the assignment ID given by the generic call control manager object when the previous `enableNotification()` was called.

Returns

-

Errors

INVALID_ASSIGNMENTID

Returned if the assignment ID does not correspond to one of the valid assignment IDs.

Method

getCriteria()

This method is used to retrieve the call event notification criteria set with `enableCallNotification()` or `changeCallNotification()`.

Direction

Application to network

Parameters

assignmentID

Specifies the assignment ID given by the generic call control manager object when the previous `enableNotification()` was called.

Returns

eventCriteria

Specifies the event specific criteria currently set.

Errors

INVALID_ASSIGNMENTID

Returned if the assignment ID does not correspond to one of the valid assignment IDs.

Method

callEventNotify()

This method notifies the application of the arrival of a call-related event.

Direction

Network to application

Parameters

callReference

Specifies the reference to the call object to which the notification relates.

eventInfo

Specifies data associated with this event. These data include `originatingAddress`, `originalDestinationAddress`, `redirectingAddress` and `AppInfo` (see for more explanation on these data the `routeReq()` method).

assignmentID

Specifies the assignment ID which was returned by the `enableNotification()` method. The application can use assignment ID to associate events with event-specific criteria and to act accordingly.

appInterface

Specifies a reference to the application object which implements the callback interface for the new call.

Returns -**Errors** -**Method** **callAborted()**

This method indicates to the application that the call object has aborted or terminated abnormally. No further communication will be possible between the call object and the application.

Direction Network to application**Parameters** **call**

Specifies the call object that has aborted or terminated abnormally.

callSessionID

Specifies the call session ID of the call that has aborted or terminated abnormally.

Returns -**Errors** -**Method** **callNotificationTerminated()**

This method indicates to the application that all event notifications have been terminated (for example, due to faults detected).

Direction Network to application**Parameters** -**Returns** -**Errors** -

7.1.2 Call

The generic call interface class provides a structure to allow simple and complex call behaviour to be used.

Method **routeReq()**

This asynchronous method requests routing of the call to the destination party (specified in the parameter `TargetAddress`).

Direction Application to network**Parameters** **callSessionID**

Specifies the call session ID of the call.

responseRequested

Specifies the set of observed events that will result in a `routeRes()` being generated.

targetAddress

Specifies the destination party to which the call should be routed.

originatingAddress

Specifies the address of the originating (calling) party.

originalDestinationAddress

Specifies the original destination address of the call, i.e. the address as specified by the originating party. This parameter should be equal to the `originalDestinationAddress` as received by the application in the `eventInfo` parameter of the `callEventNotify` method.

redirectingAddress

Specifies the last address from which the call was redirected.

appInfo

Specifies application-related information pertinent to the call (such as alerting method, tele-service type, service identities and interaction indicators).

assignmentID

Specifies the ID assigned by the network SCS. The same ID will be returned in the `routeRes` or `Err`. This allows the application to correlate the request and the result.

Returns

-

Errors**USER_NOT_SUBSCRIBED**

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method**routeRes ()**

This asynchronous method indicates that the request to route the call to the destination was successful, and indicates the response of the destination party (for example, the call was answered, not answered, refused due to busy, etc.).

Direction

Network to application

Parameters**callSessionID**

Specifies the call session ID of the call.

eventReport

Specifies the result of the request to route the call to the destination party. It also includes the mode that the call object is in and other related information.

Returns

-

Errors

-

Method**routeErr ()**

This asynchronous method indicates that the request to route the call to the destination party was unsuccessful - the call could not be routed to the destination party (for example, the network was unable to route the call, the parameters were incorrect, the request was refused, etc.).

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **release()**
This method requests the release of the call and associated objects.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

cause
Specifies the cause of the release.

Returns -

Errors -

Method **deassignCall()**
This method requests that the relationship between the application and the call and associated object be de-assigned. It leaves the call in progress, however, it purges the specified call object so that the application has no further control of call processing. If a call is de-assigned that has event reports or call information reports requested, then these reports will be disabled and any related information discarded.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

Returns -

Errors -

Method **getCallInfo_Req()**
This asynchronous method requests information associated with the call to be provided at the appropriate time (for example, to calculate charging). This method must be invoked before the call is routed to a target address. The call object will exist after the call is ended if information is required to be sent to the application at the end of the call. The call information will be sent after any call event reports.

Note: At the end of the call, the call information must be sent before the call is deleted.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoRequested
Specifies the call information that is requested.

Returns -

Errors -

Method **getCallInfo_Res ()**

This asynchronous method reports all the necessary information requested by the application, for example to calculate charging.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoReport
Specifies the call information requested.

Returns -

Errors -

Method **getCallInfo_Err ()**

This asynchronous method reports that the original request was erroneous, or resulted in an error condition.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **superviseCall_Req ()**

The application calls this method to supervise a call. The application can set a granted connection time for this call. If an application calls this function before it calls a `routeReq ()` or a user interaction function the time measurement will start as soon as the call is answered by the B-party or the user interaction system.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

time

Specifies the granted time in milliseconds for the connection.

treatment

Specifies how the network should react after the granted connection time expired.

Returns -

Errors -

Method **superviseCall_Res()**

This asynchronous method reports a call supervision event to the application.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

report

Specifies the situation, which triggered the sending of the call supervision response.

usedTime

Specifies the used time for the call supervision (in milliseconds).

Returns -

Errors -

Method **superviseCall_Err()**

This asynchronous method reports a call supervision error to the application.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

errorIndication

Specifies the error which led to the original request failing.

Returns -

Errors -

Method **callFaultDetected()**

This method indicates to the application that a fault has been detected in the call.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call object in which the fault has been detected.

fault

Specifies the fault that has been detected.

Returns -

Errors -

Method **setAdviceOfCharge()**

This method allows the application to the charging information that will be send to the end-users handset.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

aOCInfo
Specifies two sets of Advice of Charge parameter according to GSM

tariffSwitch
Specifies the tariff switch that signifies when the second set of AoC parameters becomes valid.

Returns -

Errors -

Method **setCallChargePlan()**

Allows an application to include charging information in network generated CDR.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

callDetailRecordInfo
Free Format string containing the application specific charging information
Specifies the charge plan.

Returns -

Errors -

Sequence Diagrams

The following section will describe some scenarios to illustrate the use of the methods described above.

Enable Call notification

The first task to perform in order to allow applications to provide call control related services to certain users is to enable call-related events for these users to trigger the application. This is done with the method `enableCallNotification()`.




Figure 7 Enable call notification

Number translation

The example in figure 8 shows a simple number translation application.

After the call is triggered (according to the criteria in a previous `enableCallNotification()`), the SCS notifies the application with an `eventCallNotify()` message. This allows the application to perform the needed actions and continue the call set-up via a `routeReq()` message. The SCS relays the result of the call set-up (both positive and negative) to the application, which ends after that.




Figure 8 Simple number translation

Call barring

The next example (Figure 9) shows how a call barring application can be implemented:




Figure 9 Call barring application

Pre-paid with advice of charge

The next example shows how a pre-paid application can be implemented:

With a pre-paid application it is the application that will determine the charging for the call. This means that the application will hold the whole tariffing scheme needed and needs to control the whole call. For the call shown the following conditions apply:

- It is a long call
- Two tariff changes take place during the call.
- The application will inform the user about the applicable charging (the methods needed for this are described in section 7.5.2).

After the application has been triggered, it sends a superviseCall_Req() message indicating that the application will be responsible for charging the call. Before the call is be routed to the requested destination(5), the application sends the allowed time for the call (4) and informs the user about the charging applicable (using the Advice of Charge functionality in the core network) for this call (3). The sent information consists of two sets of AoC information and a tariff switch. The application will be notified via the superviseCall_Res() message if the tariff switch expired during the supervised period. This allows the application to send a new set of AoC information and a new tariff switch.

The application is notified of the expiration of the allowed time (7) and determines if the user has enough account left to continue with the call.

- 1 If there is enough account left a new time slot is allowed
- 2 Is there not enough account, the user will be notified and the call terminated after some time in order to allow the user to finish the call gracefully.




Figure 10 Pre-paid with AoC

EMBED

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 009

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
list expected approval meeting # here ↑

for approval
for information

strategic
non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
(at least one should be marked with an X)

Source: Lucent, Siemens **Date:** 22.5.2000

Subject: Data Session Control

Work item: VHE/OSA

Category: <small>(only one category shall be marked with an X)</small>	F Correction	<input type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input checked="" type="checkbox"/>		Release 98	<input type="checkbox"/>
D Editorial modification	<input type="checkbox"/>	Release 99	<input checked="" type="checkbox"/>		
			Release 00	<input type="checkbox"/>	

Reason for change: SA has asked S2 and CN to continue to study the issues reported as open, see SP-000155. Charging for GPRS is one of these issues.

The following contribution merges the CR-S2-00968 from Siemens and an additional CR of Lucent which introduces additional charging functionality to the data session control SCF.

Furthermore, the new sequence diagrams related to the new SCF are introduced.

Clauses affected:

Other specs affected:

Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
MS test specifications	<input type="checkbox"/>	→ List of CRs:	
BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



<----- double-click here for help and instructions on how to create a CR.

7.2 Data Session Control

The Data Session control network service capability feature consists of two interfaces:

1. Data Session manager, containing management functions for data session related issues.
2. Data Session, containing methods to control a session.

A session can be controlled by one Data Session Manager only. Data Session Manager can control several sessions.




Figure 10 Data Session control interfaces usage relationship

Note: The term "data session" is used in a broad sense to describe a data connection/session. For example, it comprises a PDP context in GPRS.

The Data Session Control service capability features are described in terms of the methods in the Data Session Control interfaces. Table 1 gives an overview of the Data Session Control methods and to which interfaces these methods belong.

Data Session Manager	Data Session
enableDataSessionNotification	connectReq
disableDataSessionNotification	connectRes
dataSessionNotificationInterrupted	connectErr
dataSessionNotificationContinued	release
dataSessionEventNotify	superviseDataSessionReq
dataSessionAborted	superviseDataSessionRes
	superviseDataSessionErr
	dataSessionFaultDetected
	setAdviceofCharge
	setDataSessionChargePlan

Table 1 Overview of Data Session Control interfaces and their methods

7.2.1 Data Session Manager

The session manager interface provides the management functions to the data session service capability features. The application programmer can use this interface to enable or disable data session-related event notifications.

Method **enableDataSessionNotification()**

This method is used to enable data session-related notifications to be sent to the application.

Direction Application to network

Parameters **appInterface**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the setCallback() method.

eventCriteria

Specifies the event specific criteria used by the application to define the event required. Individual addresses or address ranges may be specified for destination and/or origination. Examples of events are "Data Session set up"

Returns

assignmentID

Specifies the ID assigned by the Data Session Manager object for this newly-enabled event notification.

Errors

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

disableDataSessionNotification()

This method is used by the application to disable data session notifications.

Direction

Application to network

Parameters

assignmentID

Specifies the assignment ID given by the data session manager object when the previous enableDataSessionNotification() was done.

Returns

-

Errors

INVALID_ASSIGNMENTID

Returned if the assignment ID does not correspond to one of the valid assignment Ids.

Method

dataSessionEventNotify()

This method notifies the application of the arrival of a data session-related event.

Direction

Network to application

Parameters

dataSessionReference

Specifies the session ID and the reference to the Data Session object to which the notification relates.

eventInfo

Specifies data associated with this event. This data includes the destination address provided by the end-user.

assignmentID

Specifies the assignment id which was returned by the `enableDataSessionNotification()` method. The application can use assignment ID to associate events with event-specific criteria and to act accordingly.

appInterface

Specifies a reference to the application object which implements the callback interface for the new data session.

Returns -**Errors** -**Method** **dataSessionAborted()**

This method indicates to the application that the Data Session object has aborted or terminated abnormally. No further communication will be possible between the Data Session object and the application.

Direction Network to application**Parameters** **dataSessionID**

Specifies the session ID of the data session that has aborted or terminated abnormally.

Returns -**Errors** -**Method** **dataSessionNotificationInterrupted()**

This method indicates to the application that event notifications will no longer be sent (for example, due to faults detected).

Direction Network to application**Parameters** -**Returns** -**Errors** -**Method** **dataSessionNotificationContinued()**

This method indicates to the application that all event notifications will be sent again.

Direction Network to application**Parameters** -**Returns** -**Errors** -

7.2.2 Data Session

The Data Session interface provides basic methods for applications to control data sessions.

Method **connectReq ()**

This asynchronous method requests the connection of a data session with the destination party (specified in the parameter TargetAddress). The Data Session object is not automatically deleted if the destination party disconnects from the data session.

Direction Application to network

Parameters **dataSessionID**
Specifies the session ID.

responseRequested
Specifies the set of observed data session events that will result in a connectRes() being generated.

targetAddress
Specifies the address of destination party.

assignmentID
Specifies the ID assigned to the request. The same ID will be returned in the connectRes or Err. This allows the application to correlate the request and the result.

Returns -

Errors **USER_NOT_SUBSCRIBED**
Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED
Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION
Returned if the requests violates the end-user's privacy setting

Method **connectRes ()**

This asynchronous method indicates that the request to connect a data session with the destination party was successful, and indicates the response of the destination party (e.g. connected, disconnected).

Direction Network to application

Parameters **dataSessionID**
Specifies the session ID of the data session.

eventReport
Specifies the result of the request to connect the data session. It includes the network event, date and time, monitoring mode and event specific information such as release cause.

Returns -

Errors -

Method **connectErr ()**

This asynchronous method indicates that the request to connect a data session with the destination

party was unsuccessful, e.g. an error detected in the network or the data session was abandoned.

Direction Network to application

Parameters **dataSessionID**
Specifies the session ID.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **release()**
This method requests the release of the data session.

Direction Application to network

Parameters **dataSessionID**
Specifies the session.

cause
Specifies the cause of the release.

Returns -

Errors -

Method **superviseDataSessionReq()**
The application calls this method to supervise a data session. The application can set a granted data volume for this data session. If an application calls this function before it calls a connectReq() or a user interaction function the time measurement will start as soon as the data session is connected. The Data Session object will exist after the data session has been terminated if information is required to be sent to the application at the end of the data session.

Direction Application to network

Parameters **dataSessionID**
Specifies the data session.

treatment
Specifies how the network should react after the granted data volume has been sent.

bytes
Specifies the granted number of bytes that can be transmitted for the data session.

Returns -

Errors -

Method **superviseDataSessionRes()**

This asynchronous method reports a data session supervision event to the application.

Direction Network to application

Parameters **dataSessionID**
Specifies the data session.

report
Specifies the situation, which triggered the sending of the data session supervision response.

usedVolume
Specifies the used volume for the data session supervision (in the same unit as specified in the request).

Returns -

Errors -

Method **superviseDataSessionErr ()**

This asynchronous method reports a data session supervision error to the application.

Direction Network to application

Parameters **dataSessionID**
Specifies the data session ID.

errorIndication
Specifies the error which led to the original request failing.

Returns -

Errors -

Method **dataSessionFaultDetected ()**

This method indicates to the application that a fault in the network has been detected which can't be communicated by a network event, e.g., when the user aborts before any establishment method is called by the application.

The system purges the Data Session object. Therefore, the application has no further control of data session processing. No report will be forwarded to the application.

Direction Network to application

Parameters **dataSessionID**
Specifies the data session ID of the Data Session object in which the fault has been detected.

fault
Specifies the fault that has been detected.

Returns -

Errors -

Method **setDataSessionChargePlan()**
Allows an application to include charging information in network generated CDR.

Direction Application to network

Parameters **dataSessionID**
Specifies the session ID of the data session.

dataSessionChargePlan
Specifies the charge plan used.

Returns -

Errors -

Method **setAdviceOfCharge()**
This method allows the application to determine the charging information that will be send to the end-users terminal.

Direction Application to network


Parameters **dataSessionID**
Specifies the session ID of the data session.

aoCInfo
Specifies two sets of Advice of Charge parameter according to GSM

tariffSwitch
Specifies the tariff switch that signifies when the second set of AoC parameters becomes valid.

Returns -

Errors -



Sequence Charts

Figure 1: Enable Data Session Notification




Figure 2: Address translation with charging

CHANGE REQUEST

Please see embedded help file at the bottom of this page for instructions on how to fill in this form correctly.

23.127 CR 0010

Current Version: **3.0.0**

GSM (AA.BB) or 3G (AA.BBB) specification number ↑

↑ CR number as allocated by MCC support team

For submission to: **SA#8**
list expected approval meeting # here ↑

for approval
for information

strategic
non-strategic (for SMG use only)

Form: CR cover sheet, version 2 for 3GPP and SMG The latest version of this form is available from: <ftp://ftp.3gpp.org/Information/CR-Form-v2.doc>

Proposed change affects: (U)SIM ME UTRAN / Radio Core Network
(at least one should be marked with an X)

Source: Ericsson, Siemens **Date:** 24.6.2000

Subject: Modification of call control SCF

Work item: VHE/OSA

Category: (only one category shall be marked with an X)	F Correction	<input type="checkbox"/>	Release:	Phase 2	<input type="checkbox"/>
	A Corresponds to a correction in an earlier release	<input type="checkbox"/>		Release 96	<input type="checkbox"/>
	B Addition of feature	<input type="checkbox"/>		Release 97	<input type="checkbox"/>
	C Functional modification of feature	<input checked="" type="checkbox"/>		Release 98	<input type="checkbox"/>
D Editorial modification	<input type="checkbox"/>	Release 99	<input checked="" type="checkbox"/>		
			Release 00	<input type="checkbox"/>	

Reason for change:

To improve the reporting on call ending, the Parlay group decided to introduce an additional operation, callEnded(). This operation will be invoked when the call has ended in the network. The operation contains an indication on the reason why the call has been ended and an indication on the party that caused the call to be ended.

Previously, termination of the call due to actions of the calling party would be reported with a routeRes() operation that corresponded to a routeReq() operation for the called party. Introduction of the callEnded() operation will also fix this. Furthermore, the operation will always be invoked when the call has ended and not only when the application has expressed its interest in this event with routeReq().

Clauses affected: 7.1

Other specs affected:	Other 3G core specifications	<input type="checkbox"/>	→ List of CRs:	
	Other GSM core specifications	<input type="checkbox"/>	→ List of CRs:	
	MS test specifications	<input type="checkbox"/>	→ List of CRs:	
	BSS test specifications	<input type="checkbox"/>	→ List of CRs:	
	O&M specifications	<input type="checkbox"/>	→ List of CRs:	

Other comments:



help.doc

<----- double-click here for help and instructions on how to create a CR.

7.1 Call Control

The Call control network service capability feature consists of two interface classes:

1. Call manager, containing management function for call related issues
2. Call, containing methods to control a call

A call can be controlled by one Call Manager only. A Call Manager can control several calls..




Figure 6 Call control classes usage relationship

The Call Control service capability features are described in terms of the methods in the Call Control interface classes. Table 1 gives an overview of the Call Control methods and to which interface classes these methods belong.

CallManager	Call
enableCallNotification	routeCallToDestination_Req
disableCallNotification	routeCallToDestination_Res
callNotificationTerminated	routeCallToDestination_Err
callEventNotify	release
callAborted	deassignCall
callNotificationTerminated	getCallInfo_Req
	getCallInfo_Res
	getCallInfo_Err
	superviseCall_Req
	SuperviseCall_Res
	superviseCall_Err
	callFaultDetected
	callEnded
	setAdviceOfCharge
	setCallChargePlan

Table 1 Overview of Call Control interface classes and their methods

7.1.1 Call Manager

The generic call manager interface class provides the management functions to the generic call Service Capability Features. The application programmer can use this interface class to create call objects and to enable or disable call-related event notifications.

Method enableCallNotification()

This method is used to enable call notifications to be sent to the application.

Direction Application to network

Parameters **appInterface**

If this parameter is set (i.e. not NULL) it specifies a reference to the application interface, which is used for callbacks. If set to NULL, the application interface defaults to the interface specified via the `setCallback()` method.

eventCriteria

Specifies the event specific criteria used by the application to define the event required. Examples of events are “incoming call attempt reported by network”, “answer”, “no answer”, “busy”.

Returns

assignmentID

Specifies the ID assigned by the generic call control manager object for this newly-enabled event notification.

Errors

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user’s privacy setting

Method

disableCallNotification()

This method is used by the application to disable call notifications.

Direction

Application to network

Parameters

eventCriteria

Specifies the event specific criteria used by the application to define the event to be disabled. Examples of events are “incoming call attempt reported by network”, “answer”, “no answer”, “busy”.

assignmentID

Specifies the assignment ID given by the generic call control manager object when the previous `enableNotification()` was called.

Returns

-

Errors

INVALID_ASSIGNMENTID

Returned if the assignment ID does not correspond to one of the valid assignment Ids.

Method

callEventNotify()

This method notifies the application of the arrival of a call-related event.

Direction

Network to application

Parameters

callReference

Specifies the reference to the call object to which the notification relates.

eventInfo

Specifies data associated with this event. These data include `originatingAddress`, `originalDestinationAddress`, `redirectingAddress` and `AppInfo` (see for more explanation on these data the `routeCallToDestination()` method).

assignmentID

Specifies the assignment id which was returned by the `enableNotification()` method. The application can use assignment ID to associate events with event-specific criteria and to act accordingly.

appInterface

Specifies a reference to the application object which implements the callback interface for the new call.

Returns -**Errors** -**Method** **callAborted()**

This method indicates to the application that the call object has aborted or terminated abnormally. No further communication will be possible between the call object and the application.

Direction Network to application**Parameters** **call**

Specifies the call object that has aborted or terminated abnormally.

callSessionID

Specifies the call session ID of the call that has aborted or terminated abnormally.

Returns -**Errors** -**Method** **callNotificationTerminated()**

This method indicates to the application that all event notifications have been terminated (for example, due to faults detected).

Direction Network to application**Parameters** -**Returns** -**Errors** -

7.1.2 Call

The generic call interface class provides a structure to allow simple and complex call behaviour to be used.

Method **routeCallToDestination_Req()**

This asynchronous method requests routing of the call (and inherently attached parties) to the destination party (specified in the parameter `TargetAddress`). The destination party is attached

to the call via a passive leg. This means that the call is not automatically released if the destination party disconnects from the call; only the leg with which the destination party was attached to the call is released in that case. .

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

responseRequested

Specifies the set of observed events that will result in a `routeCallToDestination_Res()` being generated.

targetAddress

Specifies the destination party to which the call should be routed.

originatingAddress

Specifies the address of the originating (calling) party.

originalDestinationAddress

Specifies the original destination address of the call, i.e. the address as specified by the originating party. This parameter should be equal to the `originalDestinationAddress` as received by the application in the `eventInfo` parameter of the `callEventNotify` method.

redirectingAddress

Specifies the last address from which the call was redirected.

appInfo

Specifies application-related information pertinent to the call (such as alerting method, tele-service type, service identities and interaction indicators).

assignmentID

Specifies the ID assigned by the network SCS. The same ID will be returned in the `routeCallToDestinationRes` or `Err`. This allows the application to correlate the request and the result.

Returns

-

Errors

USER_NOT_SUBSCRIBED

Returned if the end-user is not subscribed to the application

APPLICATION_NOT_ACTIVATED

Returned if the end-user has de-activated the application

USER_PRIVACY_VIOLATION

Returned if the requests violates the end-user's privacy setting

Method

routeCallToDestination_Res()

This asynchronous method indicates that the request to route the call to the destination was successful, and indicates the response of the destination party (for example, the call was answered, not answered, refused due to busy, etc.).

Direction

Network to application

Parameters	<p>callSessionID Specifies the call session ID of the call.</p> <p>eventReport Specifies the result of the request to route the call to the destination party. It also includes the mode that the call object is in and other related information.</p>
Returns	-
Errors	-
Method	routeCallToDestination_Err()
	This asynchronous method indicates that the request to route the call to the destination party was unsuccessful - the call could not be routed to the destination party (for example, the network was unable to route the call, the parameters were incorrect, the request was refused, etc.).
Direction	Network to application
Parameters	<p>callSessionID Specifies the call session ID of the call.</p> <p>errorIndication Specifies the error which led to the original request failing.</p>
Returns	-
Errors	-
Method	release()
	This method requests the release of the call and associated objects.
Direction	Application to network
Parameters	<p>callSessionID Specifies the call session ID of the call.</p> <p>cause Specifies the cause of the release.</p>
Returns	-
Errors	-
Method	deassignCall()
	This method requests that the relationship between the application and the call and associated object be de-assigned. It leaves the call in progress, however, it purges the specified call object so that the application has no further control of call processing. If a call is de-assigned that has event reports or call information reports requested, then these reports will be disabled and any related information discarded.
Direction	Application to network
Parameters	callSessionID

Specifies the call session ID of the call.

Returns -

Errors -

Method **getCallInfo_Req()**

This asynchronous method requests information associated with the call to be provided at the appropriate time (for example, to calculate charging). This method must be invoked before the call is routed to a target address. The call object will exist after the call is ended if information is required to be sent to the application at the end of the call. The call information will be sent after any call event reports.

Note: At the end of the call, the call information must be sent before the call is deleted.

Direction Application to network

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoRequested
Specifies the call information that is requested.

Returns -

Errors -

Method **getCallInfo_Res()**

This asynchronous method reports all the necessary information requested by the application, for example to calculate charging.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

callInfoReport
Specifies the call information requested.

Returns -

Errors -

Method **getCallInfo_Err()**

This asynchronous method reports that the original request was erroneous, or resulted in an error condition.

Direction Network to application

Parameters **callSessionID**
Specifies the call session ID of the call.

errorIndication

Specifies the error which led to the original request failing.

Returns -

Errors -

Method **superviseCall_Req()**

The application calls this method to supervise a call. The application can set a granted connection time for this call. If an application calls this function before it calls a `routeCallToDestination_Req()` or a user interaction function the time measurement will start as soon as the call is answered by the B-party or the user interaction system.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

time

Specifies the granted time in milliseconds for the connection. treatment

Specifies how the network should react after the granted connection time expired.

Returns -

Errors -

Method **superviseCall_Res()**

This asynchronous method reports a call supervision event to the application.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

report

Specifies the situation, which triggered the sending of the call supervision response.

usedTime

Specifies the used time for the call supervision (in milliseconds).

Returns -

Errors -

Method **superviseCall_Err()**

This asynchronous method reports a call supervision error to the application.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call.

errorIndication

Specifies the error which led to the original request failing.

Returns -

Errors -

Method **callFaultDetected()**

This method indicates to the application that a fault has been detected in the call.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call object in which the fault has been detected.

fault

Specifies the fault that has been detected.

Returns -

Errors -

Method **callEnded()**

This method indicates to the application that the call has terminated in the network. However, the application may still receive some results (e.g. getCallInfoRes) related to the call. The application is expected to deassign the call object after having received the callEnded.

Note that the event that caused the call to end might also be received separately if the application was monitoring for it.

Direction Network to application

Parameters **callSessionID**

Specifies the call session ID of the call object for the call.

report

Specifies the reason why the call was terminated.

Returns -

Errors -

Method **setAdviceOfCharge()**

This method allows the application to the charging information that will be send to the end-users handset.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

aOCInfo

Specifies two sets of Advice of Charge parameter according to GSM

tariffSwitch

Specifies the tariff switch that signifies when the second set of AoC parameters becomes valid.

Returns -

Errors -

Method **setCallChargePlan()**

Allows an application to include charging information in network generated CDR.

Direction Application to network

Parameters **callSessionID**

Specifies the call session ID of the call.

callDetailRecordInfo

Free Format string containing the application specific charging information

Returns -

Errors -

Sequence Diagrams

The following section will describe some scenarios to illustrate the use of the methods described above.

Enable Call notification

The first task to perform in order to allow applications to provide call control related services to certain users is to enable call-related events for these users to trigger the application. This is done with the method `enableCallNotification()`.




Figure 7 Enable call notification

Number translation

The example in figure 8 shows a simple number translation application.

After the call is triggered (according to the criteria in a previous `enableCallNotification()`), the SCS notifies

the application with an `eventCallNotify()` message. This allows the application to perform the needed actions and continue the call set-up via a `routeCallToDestination_Req()` message. The SCS relays the result of the call set-up (both positive and negative) to the application, which ends after that.




Figure 8 Simple number translation

Call barring

The next example (Figure 9) shows how a call barring application can be implemented:




Figure 9 Call barring application

Pre-paid with advice of charge

The next example shows how a pre-paid application can be implemented:

With a pre-paid application it is the application that will determine the charging for the call. This means that the application will hold the whole tariffing scheme needed and needs to control the whole call. For the call shown the following conditions apply:

- It is a long call
- Two tariff changes take place during the call.
- The application will inform the user about the applicable charging (the methods needed for this are described in section 7.5.2).

After the application has been triggered, it sends a `superviseCall_Req()` message indicating that the application will be responsible for charging the call. Before the call is be routed to the requested destination(5), the application sends the allowed time for the call (4) and informs the user about the charging applicable (using the Advice of Charge functionality in the core network) for this call (3). The sent information consists of two sets of AoC information and a tariff switch. The application will be notified via the `superviseCall_Res()` message if the tariff switch expired during the supervised period. This allows the application to send a new set of AoC information and a new tariff switch.

The application is notified of the expiration of the allowed time (7) and determines if the user has enough account left to continue with the call.

- 1 If there is enough account left a new time slot is allowed
- 2 Is there not enough account, the user will be notified and the call terminated after some time in order to allow the user to finish the call graciously.




Figure 10 Pre-paid with AoC